



Sheet 1/2
















Board: Rear MCN Breakout


Drawn by Victor Brechbill Revision date: 03/27/15


Last modified date: 3/27/2015 11:52:17 PM

Version 1.3

Sheet 2/2


REAR_BRK_PRES_MCN





		GND	
SPARE1_5V	R3 	R4 10kW	SPARE1_5V_MCN
±12V	R5 	DE RE 10k	12V_SENSE_MCN
12V_STANDRY	R7 	R8 WM 10k	12V_STANDBY_MCN

MCN Signal Routing		
REAR_SUSP	AIN-1	
REAR_BRK_PRES	AIN-2	
12V_SHUNT	AIN-3	
DC_DC_TEMP	AIN-5	
SPARE1_5V	AIN-6	
SPARE2_3V	AIN-7	
SPARE3_3V	AIN-8	
12V_SENSE	AIN-9	
12V_STANDBY	AIN-10	
REAR_WSS	GP0	
FRAME_FAULT	GP1	



REAR_BRK_PRES



GND

Board: Rear MCN Breakout Version 1.3

Drawn by Victor Brechbill Revision date: 03/27/15

Last modified date: 3/27/2015 11:52:17 PM