




Sheet 1/2
















Board: Rear MCN Breakout


Drawn by Victor Brechbill Revision date: 04/02/15


Last modified date: 4/3/2015 12:14:02 AM

Version 1.0

Sheet 2/2


REAR_BRK_PRES_MCN





		GND		
SPARE1_5V	R3 5.6k	DND 10K	SPARE1_5V_	MCN
±12V	R5 	DNS R6	12V_SENSE_	<u>MCN</u>
12V_STANDBY	R7 WW 36k		V_STANDBY_	_MCN

MCN Signal Ro	MCN Signal Routing				
REAR_SUSP	AIN-1				
REAR_BRK_PRES	AIN-2				
12V_SHUNT	AIN-3				
DC_DC_TEMP	AIN-5				
SPARE1_5V	AIN-6				
SPARE2_3V	AIN-7				
SPARE3_3V	AIN-8				
12V_SENSE	AIN-9				
12V_STANDBY	AIN-10				
REAR_WSS	GP0				
FRAME_FAULT	GP1				



REAR_BRK_PRES



Board: Rear MCN Breakout Version 1.0

Drawn by Victor Brechbill Revision date: 04/02/15

Last modified date: 4/3/2015 12:14:02 AM