




Δ Generador principal, va hacia el acoplador direccional




Δ poner capacitores de desacople cerca de los pines: 6 (Vp), 10 (AVDD), 16, 17 (VVCO), 19 (TEMP), 23 (VCOM), 24 (VREF), 28 DVDD, 32 SDVDD

Title		
ADF4351 (Gen RF) izquierdo		
Size	Number	Revision
A4		
Date:	10/02/2026	Sheet of
File:	C:\Users\...\ADF4351_izq.SchDoc	Drawn By:








Title			
Mezclador			
Size	Number		Revision
A4			
Date:	10/02/2026		Sheet of
File:	C:\Users\...\Mixer ADL5802.SchDoc		Drawn By:



Title Acoplador Direccional			
Size A4	Number		Revision
Date:	10/02/2026		Sheet of
File:	C:\Users\...\Acop Direccional.SchDoc		Drawn By:



Title		
Etapla FI		
Size	Number	Revision
A4		
Date:	10/02/2026	Sheet of
File:	C:\Users\...\Restador.SchDoc	Drawn By:



Title		
Atenuadores		
Size	Number	Revision
A4		
Date:	10/02/2026	Sheet of
File:	C:\Users\...\Reg & Atenuadores.SchDoc	Drawn By: