


SAMPLING & QUANTIZATION



SAMPLING

- Sampling is the process of taking a sufficient number of discrete values at points on a waveform that will define the shape of the waveform.
- The more samples can be taken, the more accurately the signal can be defined.
- Sampling converts an analog signal into a series of impulses, each representing the amplitude of the signal at a given instant in time.



SAMPLING THEOREM


- In order to recover a continuous signal, the sampling rate must be greater than twice the highest frequency in the signal.

$$f_{sample} \geq 2f_m$$

where f_{sample} = sampling frequency, and the frequency f_m is known as the Nyquist frequency .

- If the signal is sampled less than this, the recovery process will produce frequencies that are entirely different than in the original signal.
- The frequency $2f_m$ is called the Nyquist rate.

CONTD..



EFFECT OF SAMPLING IN THE FREQUENCY DOMAIN

- Let $g_a(t)$ be a continuous-time signal that is sampled uniformly at $t = nT$, generating the sequence $g[n]$

$$g[n] = g_a(nT), -\infty < n < \infty$$

where with T being the sampling period

- The reciprocal of T is called the sampling frequency F_T

$$F_T = 1/T$$

- The frequency-domain representation of $g_a(t)$ is given by its continuous-time Fourier transform (CTFT)

$$G_a(j\Omega) = \int_{-\infty}^{\infty} g_a(t) e^{-j\Omega t} dt$$

- The frequency-domain representation of $g[n]$ is given by DTFT

$$G(e^{j\omega}) = \sum_{n=-\infty}^{\infty} g[n] e^{-j\omega n}$$



CONTD..

- To establish the relation between $G_a(j\Omega)$ and $G(e^{j\omega})$, the sampling operation mathematically as a multiplication of $g_a(t)$ by a periodic impulse train $p(t)$

$$p(t) = \sum_{n=-\infty}^{\infty} \delta(t - nT)$$


- $p(t)$ consists of a train of ideal impulses with a period T
- The multiplication operation yields an impulse train signal

$$g_p(t) = g_a(t)p(t) = \sum_{n=-\infty}^{\infty} g_a(nT)\delta(t - nT)$$




CONTD..

- $g_p(t)$ is a continuous-time signal consisting of a train of uniformly spaced impulses with the impulse at $t = nT$ weighted by the sampled value $g_a(nT)$ of $g_a(t)$ at that instant



TYPES OF SAMPLING

- **Overs sampling** - The sampling frequency is higher than the Nyquist rate.
- **Under sampling** - The sampling frequency is lower than the Nyquist rate.
- **Critical sampling** - The sampling frequency is equal to the Nyquist rate .
- *A sampling rate of 44.1 kHz is used in mp3 decoding*




EXAMPLE

- Consider the three signals $g_1(t) = \sin(6\pi t)$, $g_2(t) = \sin(14\pi t)$, $g_3(t) = \sin(26\pi t)$
- $\omega_1 = 6\pi$, $2\pi f_1 = 6\pi$, $f_1 = 3$
 $\omega_2 = 14\pi$, $2\pi f_2 = 14\pi$, $f_2 = 7$
 $\omega_3 = 26\pi$, $2\pi f_3 = 26\pi$, $f_3 = 13$
- $f_m = \max(f_1, f_2, f_3) = 13$


$$f_s \geq 2 * f_m \geq 2 * 13 \geq 26$$

QUANTIZATION


- The process of converting an analog value to a code is called **quantization**.
- During the quantization process, the ADC converts each sampled value of the analog signal to a binary code.
- The more bits that are used to represent a sampled value, the more accurate is the representation.



CONTD..



| Sample Interval | Quantization Level | Code |
|-----------------|--------------------|------|
| 1 | 0 | 00 |
| 2 | 1 | 01 |
| 3 | 2 | 10 |
| 4 | 1 | 01 |
| 5 | 1 | 01 |
| 6 | 1 | 01 |
| 7 | 1 | 01 |
| 8 | 2 | 10 |
| 9 | 3 | 11 |
| 10 | 3 | 11 |
| 11 | 3 | 11 |
| 12 | 3 | 11 |
| 13 | 3 | 11 |



REFERENCES

- John G. Proakis, Digital Signal Processing: Principle, algorithms and applications, Pearson , 2006.
- Kumar A. Anand , Fundamentals of Digital Circuits, PHI, 2010.
- Albert Paul Malvino, Digital principles and applications, TATA McGraw Hill, 2016.