

Concrete

Lecture - 3

Course Coordinator

Dr. Raju Sharma

Assistant Professor

Department of Civil Engineering

Thapar Institute of Engineering and Technology

Patiala, Punjab

Content

1

Slump Test

2

Compacting Factor Test

3

Vee Bee Test

4

Flow Table Test

Workability

☞ *Workability can be measure*


Slump Test

**Compacting
Factor Test**

Flow Test


**Vee Bee
Consistometer Test**

Slump Test




True Slump

Shear




7/27/2020

Collapse




All dimensions are in centimetres

Procedure to Conduct Slump Test




Apply 25 strokes on each stage. During Stage III, Fill cone to overflowing and again rod 25 times with rod just penetrating into it, but not through, the second layer Distributed Strokes evenly.


Procedure to Conduct Slump Test



Stage IV



Stage IV



Stage VI

Strike off excess concrete from top of the cone with the steel rod so the cone is exactly full

Immediately after stage IV lift the mould within 5 ± 2 sec. Time duration from filling the mould to removing the mould must be completed in 2-1/2 min.

Place the steel rod horizontally and measure the distance steel road to the centre of the displaced concrete

Compacting Factor Test




TABLE I ESSENTIAL DIMENSIONS OF THE COMPACTING FACTOR APPARATUS FOR USE WITH AGGREGATE NOT EXCEEDING 38 mm NOMINAL MAXIMUM SIZE

(Clause 5.2.2.1)

DETAIL (see FIG. 2)

Upper hopper, A

Top internal diameter
Bottom internal diameter
Internal height

Lower hopper, B

Top internal diameter
Bottom internal diameter
Internal height

Cylinder, C

Internal diameter
Internal height

Distance between bottom of upper hopper and top of lower hopper

Distance between bottom of lower hopper and top of cylinder

**DIMENSION
cm**


25.4
12.7
27.9

22.9
12.7
22.9

15.2
30.5
20.3




20.3

Vee Bee Test



Slump cone is placed inside the sheet metal cylindrical pot of the consistometer. The glass disc attached to the swivel arm is turned and placed on the top of the concrete in the pot. The electrical vibrator is then switched on and simultaneously a stop watch started. The vibration is continued till such a time as the conical shape of the concrete disappears and the concrete assumes a cylindrical shape. This can be judged by observing the glass disc from the top for disappearance of transparency. Immediately when the concrete fully assumes a cylindrical shape, the stop watch is switched off. The time required for the shape of concrete to change from slump cone shape to cylindrical shape in seconds is known as Vee Bee Degree. This method is very suitable for very dry concrete whose slump value cannot be measured by Slump Test, but the vibration is too vigorous for concrete with a slump greater than about 50 mm.


Flow Table Test



- The mould should be wet and clean
- The mould should be placed at the centre of the table
- The mould should be filled in two layers and each layer subjected to 25 strokes with 16 mm diameter metal road.
- The excess concrete which has overflowed the mould shall be removed and the area of the table outside the mould again cleaned. The mould shall be immediately removed from the concrete by the steady upward pull.
- The table shall then be raised and dropped 12.5 mm, 15 times in about 15 seconds. The diameter of the spread concrete shall be the average of six symmetrically distributed caliper measurements read to the nearest 5 mm.

$$\text{Flow (\%)} = \frac{\text{spread diameter in cm} - 25}{25} \times 100$$

Flow Table Test



Indian Standard Code to Determine Workability



IS : 1199 - 1959
(Reaffirmed 1999)

Indian Standard
METHODS OF SAMPLING AND
ANALYSIS OF CONCRETE
(Twelfth Reprint JANUARY 2000)

UDC 666.97 : 620.11

Slump Test

**Compacting
Factor Test**

**Vee Bee
Consistometer Test**

Flow Test

© Copyright 1959

BUREAU OF INDIAN STANDARDS
MANAK BHAVAN, 9 BAHADUR SHAH ZAFAR MARG
NEW DELHI 110002

Summary

👉 *Slump Test*

👉 *Compacting Factor Test*

👉 *Vee Bee Test*

👉 *Flow Table Test*

THANK YOU