

Mass Transfer-I

Mass Transfer Coefficients



DEPARTMENT OF CHEMICAL ENGINEERING
Thapar Institute of Engineering & Technology
Patiala (Punjab), INDIA-147004

Dr. Avinash Chandra
(Ph.D., IIT Kanpur)
Associate Professor

Web: <http://www.thapar.edu/faculties/view/Dr-Avinash-Chandra/ODU=/Mg==>

Mass Transfer Coefficient

The Mass Transfer Coefficient

We know that

(Mass per unit time per unit area) \propto Driving Force **{Fick's 1st Law}**

(Rate per unit area) \propto Driving Force

(Rate / Area) \propto Driving Force

The mass transfer coefficient is defined on the following 'phenomenological basis'.

Rate of mass transfer \propto Concentration driving force (i.e. the difference in concentration)
Rate of mass transfer \propto Area of contact between the phases

In case of Mass transfer: Driving force is the concentration difference

For binary solutions

The mass transfer flux in case of steady state molecular diffusion in fluids under stagnant and laminar flow conditions is defined as follows: (for binary solutions):

$$N_A = \frac{N_A}{N_A + N_B} \frac{D_{ABC}}{Z} \ln \frac{N_A/(N_A + N_B) - c_{A2}/c}{N_A/(N_A + N_B) - c_{A1}/c}$$

Movement of the bulk fluid particles in the turbulent condition is not yet thoroughly understood. Specifically for gases, it is fairly well known as a molecular diffusion since it is described in terms of kinetic theory.

The rate of mass transfer from the interface to the turbulent zone in the same manner can be useful for molecular diffusion. Thus the term $\frac{D_{ABC}}{Z}$ of above equation is replaced by F , which is a characteristic of molecular diffusion

$$N_A = \frac{N_A}{N_A + N_B} F \ln \frac{N_A/(N_A + N_B) - c_{A2}/c}{N_A/(N_A + N_B) - c_{A1}/c}$$

Source: *Mass Transfer Operations*, 3rd ed. Robert E. Treybal (1981)

Cont...

- F is called mass transfer coefficient and the value of F depends on the fluid kinematics (local nature of fluid motion).
- It is a local mass transfer coefficient defined for a particular location at the interphase (phase boundary surface)

We know that

Flux \propto Driving Force


Flux = Coefficient \times Driving Force

In case of Mass transfer: Driving force is the concentration difference

The mass transfer coefficient is defined on the following "phenomenological basis"

- Rate of mass transfer \propto Concentration driving force (i.e. difference in concentration)
- Rate of mass transfer \propto Contact area between phases

ti
5

Cont...**Where**

N_A = Flux at interface
 k_g, k_L, k_c, k_x, k_y = Mass transfer coefficients
 C_{Ai} = Concentration mass (mole)
 x_{Ai}, y_{Ai} = Concentration mass (mole) friction
 p_{Ai} = Concentration partial Pressure
 i = interface level i.e., 1, 2, ...

Mass transfer in liquid phase

$$N_A = k_x(x_{A1} - x_{A2}) = k_L(C_{A1} - C_{A2})$$

Mass transfer in gas phase

$$N_A = k_g(p_{A1} - p_{A2}) = k_y(y_{A1} - y_{A2}) = k_c(C_{A1} - C_{A2})$$

Source: Mass Transfer, From Fundamentals to Modern Industrial Applications. Koichi Asano (2006)

ti
7

Dr. Avinash Chandra

Cont...

Imagine we are interested in the transfer of mass from some interface into a well-mixed solution. We expect that the amount transferred is proportional to the concentration difference and the interfacial area:

$$N_A = k (C_{Ai} - C_A)$$

$$k = \frac{N_A}{(C_{Ai} - C_A)} = \frac{N_A}{\Delta C_A}$$

$$k_c = \frac{N_A}{\Delta C_A} = \frac{\text{molar flux}}{\text{concentration driving force}}$$

Remark: The flux includes both convection and diffusion

Where

N_A = Flux at interface
 k, k_c = Mass transfer coefficient
 C_{Ai} = Concentration at interface
 C_A = Concentration at bulk of the solution

Concentration (C) is defined in number of ways and standards have not been established we have variety of Mass transfer coefficients for each situation:

Source: Mass Transfer Operations, 3rd ed. Robert E. Treybal (1981)

ti
6

Dr. Avinash Chandra

Cont...

Relationships between various definitions of concentration in a multicomponent system.

	mass fraction $\omega_A [-]$	mole fraction $x_A [-]$	partial density $\rho_A [\text{kg m}^{-3}]$	molar density $c_A [\text{kmol m}^{-3}]$	partial pressure $p_A [\text{kPa}]$
mass fraction	ω	$\frac{x_A M_A}{\sum_i x_i M_i}$	$\frac{\rho_A}{\sum_i \rho_i}$	$\frac{c_A M_A}{\sum_i c_i M_i}$	$\frac{p_A M_A}{\sum_i p_i M_i}$
mole fraction	$x_A [-]$	x_A	$\frac{\rho_A / M_A}{\sum_i (\rho_i / M_i)}$	$\frac{c_A}{\sum_i c_i}$	$\frac{p_A}{\sum_i p_i}$
partial density	$\rho \omega_A$	$\frac{\rho x_A M_A}{\sum_i x_i M_i}$	ρ_A	$c_A M_A$	$\frac{M_A p_A}{R T}$
molar density	$\frac{\rho \omega_A}{M_A}$	$c x_A$	$\frac{\rho_A}{M_A}$	c_A	$\frac{p_A}{R T}$
partial pressure	$\frac{(\omega_A / M_A) P}{\sum_i (\omega_i / M_i)}$	$P x_A$	$\frac{R T \rho_A}{M_A}$	$c_A R T$	p_A

Mixture: $\sum_i x_i = 1$, $\sum_i \omega_i = 1$, $\rho = \sum_i \rho_i$, $c = \sum_i c_i$, $P = \sum_i p_i$

$$M = \sum_i M_i x_i = \left(\sum_i \frac{\omega_i}{M_i} \right)^{-1}$$

Source: Mass Transfer. From Fundamentals to Modern Industrial Applications. Koichi Asano (2006)

ti
8

Cont...

Dr. Avinash Chandra

Mass transfer coefficient	Unit	Definition	Driving force	Phase
k_y	[kmol m ⁻² s ⁻¹]	$N_A^* = k_y (y_i - y_\infty)$	Δy	Gas phase
k_G	[kmol m ⁻² s ⁻¹ kPa ⁻¹]	$N_A^* = k_G (p_i - p_\infty)$	Δp	
k_Y	[kmol m ⁻² s ⁻¹]	$N_A^* = k_Y (Y_i - Y_\infty)$	ΔY	
k	[m s ⁻¹]	$N_A = \rho_G k (\omega_{G,i} - \omega_{G,\infty})$	$\Delta \omega_G$	
k_H	[kg m ⁻² s ⁻¹]	$N_A = k_H (H_i - H_\infty)$	ΔH	
k_L	[m s ⁻¹]	$N_A^* = k_L (c_i - c_\infty)$	Δc	Liquid phase
k_x	[kmol m ⁻² s ⁻¹]	$N_A^* = k_x (x_i - x_\infty)$	Δx	
k_X	[kmol m ⁻² s ⁻¹]	$N_A^* = k_X (X_i - X_\infty)$	ΔX	
k	[m s ⁻¹]	$N_A = \rho_L k (\omega_{L,i} - \omega_{L,\infty})$	$\Delta \omega_L$	

c = molar density [mol m⁻³], H = absolute humidity [-], M_A = molecular weight [kg kmol⁻¹],
 N_A = mass flux [kg m⁻² s⁻¹], N_A^* = N_A/M_A = molar flux [kmol m⁻² s⁻¹], p = partial pressure
[kPa], x, y = mole fraction [-], $X = x/(1-x)$ [-], $Y = y/(1-y)$ [-], ω = mass fraction [-].

Source: Mass Transfer. From Fundamentals to Modern Industrial Applications. Koichi Asano (2006)

ti

9

Dr. Avinash Chandra

Relations between mass transfer coefficients

For Gas Phase

$$\begin{aligned} \because c_A &= y_A \rho_M \\ \therefore k_y &= \frac{J_A}{y_{Ai} - y_A} \\ &= \frac{J_A}{\bar{c}_{Ai}/\rho_M - c_A/\rho_M} \\ &= \rho_M \frac{J_A}{\bar{c}_{Ai} - c_A} \\ \therefore k_y &= \rho_M \cdot k_c = \frac{k_c P}{RT} \end{aligned}$$

For Liquid Phase

$$\begin{aligned} \because c_A &= x_A \rho_M \\ \therefore k_x &= \frac{J_A}{x_{Ai} - x_A} \\ &= \frac{J_A}{\bar{c}_{Ai}/\rho_M - c_A/\rho_M} \\ &= \rho_M \frac{J_A}{\bar{c}_{Ai} - c_A} \\ \therefore k_x &= \rho_M \cdot k_c = \frac{k_c \rho_x}{M} \end{aligned}$$

ti

10

Different types of Mass transfer coefficients

Dr. Avinash Chandra

Diffusion of A through non-diffusing B		Equimolar counterdiffusion of A and B		Unit of the mass transfer coefficient
Flux, N_A	Mass transfer coefficient	Flux, N_A	Mass transfer coefficient	
<i>Gas-phase mass transfer</i>				
$k_G(p_{A1} - p_{A2})$	$k_G = \frac{D_{AB}P}{RT \delta p_{BM}}$	$k'_G(p_{A1} - p_{A2})$	$k'_G = \frac{D_{AB}}{\delta RT}$	mol (time)(area)(Δp_A)
$k_y(y_{A1} - y_{A2})$	$k_y = \frac{D_{AB}P^2}{RT \delta p_{BM}}$	$k'_y(y_{A1} - y_{A2})$	$k'_y = \frac{D_{AB}P}{\delta RT}$	mol (time)(area)(Δy_A)
$k_c(C_{A1} - C_{A2})$	$k_c = \frac{D_{AB}P}{\delta p_{BM}}$	$k'_c(C_{A1} - C_{A2})$	$k'_c = \frac{D_{AB}}{\delta}$	mol (time)(area)(ΔC_A)
<i>Liquid-phase mass transfer.</i>				
$k_L(C_{A1} - C_{A2})$	$k_L = \frac{D_{AB}}{\delta x_{BM}}$	$k'_L(C_{A1} - C_{A2})$	$k'_L = \frac{D_{AB}}{\delta}$	mol (time)(area)(ΔC_A)
$k_x(x_{A1} - x_{A2})$	$k_x = \frac{CD_{AB}}{\delta x_{BM}}$	$k'_x(x_{A1} - x_{A2})$	$k'_x = \frac{CD_{AB}}{\delta}$	mol (time)(area)(Δx_A)
<i>Conversion</i>				
$k_G RT = \frac{RT}{P} k_y = k_c$		$k'_G RT = \frac{RT}{P} k'_y$		$k'_L = \frac{k'_x}{C_{av}}$

Source: Principles of Mass Transfer. And Separation Processes: Binay K. Dutta (2007)

ti

11

Example

Show the mutual relationship between the mass transfer coefficients k , k_H , k_c , k_y , and k_G .

Solution

From the definitions of mass transfer coefficients

$$N_A = \rho k (\omega_s - \omega_\infty) = k_H (H_s - H_\infty) \quad (A)$$

$$N_A/M_A = N_A^* = k_c (c_s - c_\infty) = k_y (y_s - y_\infty) = k_G (p_s - p_\infty) \quad (B)$$

$$H = \frac{\omega}{1-\omega}, \quad c = \frac{p}{RT}, \quad \gamma = \frac{p}{P} = \frac{(M_B/M_A)\omega_A}{1 + \{M_B/M_A - 1\}\omega_A} \quad (C)$$

c = molar density [mol m⁻³], H = absolute humidity [-], M_A = molecular weight [kg kmol⁻¹],
 N_A = mass flux [kg m⁻² s⁻¹], N_A^* = N_A/M_A = molar flux [kmol m⁻² s⁻¹], p = partial pressure
[kPa], x, y = mole fraction [-], $X = x/(1-x)$ [-], $Y = y/(1-y)$ [-], ω = mass fraction [-].

Source: Mass Transfer. From Fundamentals to Modern Industrial Applications. Koichi Asano (2006)

ti

12

Cont...

Substituting these equations into Eq. (A) or (B), we obtain the following equations:

$$k = \frac{k_H}{\rho(1-\omega_s)(1-\omega_\infty)} \quad (\text{D})$$

$$\begin{aligned} k_y &= k_G P = k_c (P/RT) \\ &= \left(\frac{\rho k}{M_A}\right) \left\{1 + \left(\frac{M_B}{M_A} - 1\right) \omega_s\right\} \left\{1 + \left(\frac{M_B}{M_A} - 1\right) \omega_\infty\right\} \left(\frac{M_A}{M_B}\right) \\ &\approx ck \left\{1 + \left(\frac{M_B}{M_A}\right) \omega_s\right\} \end{aligned} \quad (\text{E})$$


Source: Mass Transfer: From Fundamentals to Modern Industrial Applications. Koichi Asano (2006)

13



Dr. Avinash Chandra

Overall Mass Transfer Coefficients



Concentration profiles near the gas-liquid interface and overall mass transfer coefficient

$$N_A^* = k_y (y_\infty - y_s) = k_x (x_s - x_\infty) = K_y (y_\infty - y^*) = K_x (x^* - x_\infty)$$

Source: Mass Transfer: From Fundamentals to Modern Industrial Applications. Koichi Asano (2006)

14



Dr. Avinash Chandra

Typical "Order of magnitude" of Mass Transfer coefficients and film thickness

The "order of magnitude" of the mass transfer coefficient and film thickness for typical *gas-liquid separation equipment* are

Gas-phase mass transfer coefficient, $k_c \sim 10^{-2}$ m/s; film thickness, $\delta \sim 1$ mm

Liquid-phase mass transfer coefficient, $k_L \sim 10^{-5}$ m/s; film thickness, $\delta \sim 0.1$ mm

Once these typical values are noted, it is rather easy to determine the orders of magnitude of other types of mass transfer coefficients. For example, at $T = 298$ K and at a 'low concentration',

$$k_G = \frac{k_c}{RT} \sim \frac{10^{-2} \text{ m/s}}{0.08317 [(\text{m}^3/\text{bar})/(\text{kmol})(\text{K})](298 \text{ K})} \Rightarrow k_G \sim 4 \times 10^{-4} \text{ kmol}/(\text{m}^2)(\text{s})(\Delta p, \text{ bar})$$

Source: Principles of Mass Transfer: And Separation Processes: Binay K. Dutta (2007)

15



Cont...

For liquid-phase mass transfer in a 'dilute' aqueous solution,

$$k_x = k_L (\rho/M)_{av} \sim (10^{-5} \text{ m/s})(1000/18 \text{ kmol/m}^3) \Rightarrow k_x \sim 5 \times 10^{-4} \text{ kmol}/(\text{m}^2)(\text{s})(\Delta x)$$

Since the liquid-phase diffusivity of common solutes, $D \sim 10^{-9} \text{ m}^2/\text{s}$,

$$\text{liquid film thickness, } \delta \sim D/k_L \Rightarrow \delta \sim 10^{-4} \text{ m or } 0.1 \text{ mm}$$

Source: Principles of Mass Transfer: And Separation Processes: Binay K. Dutta (2007)

16



Important Dimensionless groups in Mass transfer

Dimensionless groups and their physical significance

$$\text{Reynolds number, } \text{Re} = \frac{\rho v}{\mu} = \frac{Iv}{v} = \frac{\text{inertial forces}}{\text{viscous forces}}$$

$$\text{Schmidt number, } \text{Sc} = \frac{\mu}{D} = \frac{v}{D} = \frac{\text{momentum diffusivity}}{\text{molecular diffusivity}}$$

$$\text{Sherwood number*, } \text{Sh} = \frac{k_L I}{(D/I)\Delta C} = \frac{k_L \Delta C}{\text{diffusive flux across a layer of thickness } I}$$

$$\text{Stanton number, } \text{St}_M = \frac{\text{Sh}}{(\text{Re})(\text{Sc})} = \frac{k_L}{v} = \frac{k_L \Delta C}{v \Delta C} = \frac{\text{convective mass flux}}{\text{flux due to bulk flow of the medium}}$$

$$\text{Peclat number, } \text{Pe}_M = (\text{Re})(\text{Sc}) = \frac{Iv}{D} = \frac{v \Delta C}{(I/I)\Delta C} = \frac{\text{flux due to bulk flow of the medium}}{\text{diffusive flux across a layer of thickness } I}$$

$$\text{Colburn factor, } j_D = \text{St}_M (\text{Sc})^{2/3} = \frac{\text{Sh}}{(\text{Re})(\text{Sc})^{1/3}}$$

$$\text{Grashof number, } \text{Gr} = \frac{l^3 \Delta \rho g}{\mu v}$$

$$\text{Lewis number, } \text{Le} = \text{Sc}/\text{Pr}$$

* The Sherwood number for gas-phase mass transfer is defined in Eq. (3.16). The suffix *M* or *D* refers to mass transfer, *H* to heat transfer. The Grashof number is the analogue of Reynolds number in free convection mass transfer. Pr = Prandtl number; Nu = Nusselt number; I = characteristic length; $v = \mu/\rho$ = momentum diffusivity; $\alpha = k/\rho c_p$ = thermal diffusivity; $\Delta \rho$ = difference in density because of a difference in concentration or temperature.

Source: Principles of Mass Transfer: And Separation Processes: Binay K. Dutta (2007)

Dr. Avinash Chandra

Analogous groups in heat transfer

The same

$$\text{Pr} = \frac{c_p \mu}{k} = \frac{\mu / \rho}{k / \rho c_p} = \frac{v}{\alpha} = \frac{\text{momentum diffusivity}}{\text{thermal diffusivity}}$$

$$\text{Nu} = \frac{hI}{(D/I)\Delta C} = \frac{h \Delta T}{\text{conduction heat flux across a layer of thickness } I}$$

$$\text{St}_H = \frac{\text{Nu}}{(\text{Re})(\text{Pr})} = \frac{h \Delta T}{v \Delta T} = \frac{\text{convective heat flux}}{\text{heat flux due to bulk flow}}$$

$$\text{Pe}_H = (\text{Re})(\text{Pr}) = \frac{(v \rho c_p) \Delta T}{(k/I) \Delta T} = \frac{\text{heat flux due to bulk flow}}{\text{conduction flux across a thickness } I}$$

$$j_H = \text{St}_H (\text{Pr})^{2/3} = \frac{\text{Nu}}{(\text{Re})(\text{Pr})^{1/3}}$$


The same

See Chapter 10

17

Mass transfer resistance

The inverse to mass transfer coefficient ($\frac{1}{K}$) is termed as a **resistance to mass transfer** or **mass transfer resistance**



ti
18

Molecular mass transfer resistance

$$R_D = \frac{L}{D_{AB}}$$


Convective mass transfer resistance in gas phase

$$R_g = \frac{1}{K_g}$$

Convective mass transfer resistance in liquid phase

$$R_L = \frac{1}{K_L}$$

References



Mass Transfer
Theories for Mass Transfer Coefficients
Lecture 9, 15.11.2017, Dr. K. Wegner

- Lecture notes/ppt of Dr. Yahya Banat (ybanat@qu.edu.qa)

ti
19