
Wiring Diagram for PAM Adaptor - for RS232



9 Pin Whip	Wire Color	Connectors on PAM PCB		Your Device		
		9 PinOUT	9 PinIN	Wire Color	Pin#	Signal Name
pin 5	Orange	pin 5	pin 5	Black		GND
pin 7	Blue	pin 8	pin 7	Yellow		RS232 Tx
pin 8	Gray	pin 7	pin 8	Blue		RS232 Rx
pin 9	Brown	pin 9	pin 9	Red		12V+