


Αριάδνη Καζδάγλη el1838, Βικέντιος Βιτάλης el18803 5^η Σειρά Ασκήσεων Εργαστηρίου Συστήματα Μικροϋπολογιστών Ακαδημαϊκό Έτος 2020-2021



Αρχικά δίνεται το περιεχόμενο του αρχείου μακροεντολών που χρησιμοποιήθηκε για τη μεταγλώττιση των προγραμμάτων.

macros.asm / emu8086 Code

```
G1; Character display
PRINTCH MACRO CHAR
PUSH AX
PUSH DX
MOU DL, CHAR
MOU AH, 2
INT 21H
POP DX
POP AX
FNDM
 09
10 ENDM
11
12 ;Dis
13 PRIN
14
15
16
17
           ;Display of string
PRINTSTR MACRO STRING
PUSH AX
PUSH DX
MOU DX.OFFSET STRING
MOU AH.9
INT 21H
POP DX
POP AX
  18
 19
20
21
22
23
24
25
26
27
28
29
30
            ENDM
          ;Change of line
PRINTLN MACRO
PUSH AX
PUSH DX
MOU DL,13
MOU AH,2
INT 21H
MOU DL,10
MOU AH,2
INT 21H
POP DX
POP AX
ENDM
  31
32
33
  34
35
36
37
38
39
           ENDM
         FESOXI
PRINTTAB MACRO
PUSH AX
PUSH DX
MOU DL,9
MOU AH,2
INT 21H
POP DX
POP AX
  40
  41
42
```

```
066
067
       ; Some extra macros
068
       ŘEAD MACRO
069
              MOU AH,01
INT 21H
070
071
072
073
      ENDM
074
075
076
077
      PRINT MACRO CHAR
PUSH AX
PUSH DX
MOU DL, CHAR
MOU AH, 2
INT 21H
POP DX
078
079
ดลด
081
              POP AX
      ENDM
083
084
085
      PRINT_STRING MACRO STRING
              PUSH AX
PUSH DX
087
DRR.
              MOU DX,OFFSET STRING
MOU AH,9
INT 21H
POP DX
POP AX
089
091
092
093
094
      ENDM
095
096
097
      ŘEAD_WITHOUT_PRINT MACRO
MOU AH,08
INT 21H
098
099
100 ENDM
101 ;
102
```

1η Άσκηση

Το πρόγραμμα αρχικά αποθηκεύει τους αριθμούς 128, 127, 126, ..., 3, 2, 1 σε 128 διαδοχικές 8-bit θέσεις μνήμης (δομή TABLE). Στη συνέχεια σαρώνει τον πίνακα TABLE για να βρει τους περιττούς αριθμούς (διαιρώντας τους με το 2 – μεταβλητή TWO), τους οποίους αθροίζει και μετρά και βρίσκει το μέγιστο και το ελάχιστο των αριθμών συγκρίνοντάς τους σειριακά με τον 1ο και τον τελευταίο αριθμό της σειράς αντίστοιχα. Τέλος, τυπώνει το ακέραιο μέρος του μέσου όρου (16 bit) σε δεκαδική μορφή και σε νέα γραμμή το μέγιστο και ελάχιστο με ένα κενό μεταξύ τους, σε δεκαεξαδική μορφή. Με την εκτέλεση του προγράμματος προκύπτει:



Ask1.asm / emu8086 Code

```
; Microcomputer Systems - Roh Y [6th Semester]
; 5th Series of Exercises
; Kazdagli Ariadni - 03118838
; Vitalis Vikentios - 03118803
005
иие
      INCLUDE macros.asm
007
009
010
      DATA_SEG
                          SEGMENT
             TABLE DB 128 DUP(?)
AVERAGE DB ?
012
Ø13
                          DB ?
DB ?
             MIN
014
             MAX
015
             NEWLINE DB OAH, ODH, '$'
016
017
     DATA_SEG
018
019
020
021
      CODE_SEG
                          SEGMENT
022
             ASSUME CS:CODE_SEG, DS:DATA_SEG
024
025
026
     MAIN PROC FAR
027
             028
030
031
             ; in this part data is stored MOU AL,128 ; initialize counter MOU DI,0 ; initialize index
032
Ø33
034
035 STORE:
             MOU [TABLE+DI],AL
DEC AL
INC DI
CMP DI,128
036
037
038
039
             JNE STORE
040
041
             ; in this part average is calculated
MOV DX.0 ; initialize counter to store the sum
MOV DI.0 ; initialize index to 0
MOV AX.1 ; temporary register
043
044
Ø45
046
                                 ; temporary register
     SUM:
             MOU AL,[TABLE+DI]
ADD DX,AX
048
049
050 CONT:
             ADD DI.2
CMP DI.128
JNE SUM
052
053
      END_COUNT:
                                 ; sum of all peritton in DX
             MOU AX,DX
MOU DX,1
MOU CX,64
DIU CX
055
056
057
058
                                 ; divide the sum by 64
059
060
             MOU AUERAGE, DL ; average is now calculated and stored
062
             ; in this part min and max are calculated MOV MAX.1 ; initializations MOV MIN.128 MOV DI.0
063
064
065
066
068 MIN_MAX:
069 MOU AL,[TABLE+DI]
070 CMP MIN,AL
071 JNA GO_MAX
072 MOU MIN,AL
                                              ; MIN =< AL ?
                                             ; if yes, then go see for max; else update minimum data
     GO_MAX:
CMP MAX.AL
JAE ITS_MAX
MOU MAX.AL
073
074
075
                                              ; MAX >= AL ?
                                             ; if yes, then continue
; else update maximum data
076
```

```
077 ITS_MAX:
078 INC
079 CMP
             INC DI
CMP DI 128
JNE MIN_MAX
080
081
082
             ; in this part, demanded data is printed MOV CX.1 MOV AL.AUERAGE MOV DL.10
085
087
      LD:
089
             MOU AH,0
DIU DL
PUSH AX
CMP AL,0
JE PRINT_AVERAGE
INC CX
JMP LD
090
092
093
094
095
096
997

998 PRINT_AUERAGE:

999 POP AX

100 MOU AL,AH

101 MOU AH,Ø

102 ADD AX,'Ø'

103 PRINT AL
104
             LOOP PRINT_AVERAGE
105
             PRINTLN NEWLINE
106
107
108
109
110
111
112
113
             MOU AL, MIN
                                             ; PRINT MINIMUM DATA
             SAR AL,4
AND AL,0FH
CMP AL,0
                                  ; isolate 4 MSB
             JE NEXT_DIGIT
ADD AL,30H
CMP AL,39H
JLE OK2
ADD AL,07H
114
115
                                  ; ASCII code it
116
117
118
119 OK2:
                                  ; if it's a letter, fix ASCII
      PRINT AL
NEXT_DIGIT:
MOU AL,MIN
AND AL,0FH
119
120
121
122
123
124
125
126
                                  ; print the first hex digit
                                    isolate 4 LSB
             ADD AL,30H
CMP AL,39H
JLE OK3
                                    ASCII code it
             ADD AL,07H
                                  ; if it's a letter, fix ASCII
128 OK3:
129
             PRINT AL
PRINT 'h'
                                  ; print the second hex digit
130
131
132
             PRINT ''
133
134
            MOU AL, MAX
SAR AL, 4
AND AL, OFH
ADD AL, 30H
CMP AL, 39H
JLE OK4
                                               ; PRINT MAXIMUM DATA
135
136
                                     isolate 4 MSB
                                  ; ASCII code it
138
139
             ADD AL,07H
140
                                  ; if it's a letter, fix ASCII
141
      OK4:
             PRINT AL
142
                                  ; print the first hex digit
143
144
             MOU AL, MAX
145
             AND AL, OFH
                                      isolate 4 LSB
             ADD AL,30H
CMP AL,39H
JLE OK5
146
                                  ; ASCII code it
147
148
149
             ADD AL,07H
                                  ; if it's a letter, fix ASCII
150 OK5:
151
             PRINT AL
                                  ; print the second hex digit
             PRINT 'h'
153
154
155
156
157
             EXIT
158 MAIN
                   ENDP
159
160 CODE_SEG
                          ENDS
             END MAIN
161
```

2η Άσκηση

Το πρόγραμμα δέχεται 2 διψήφιους δεκαδικούς αριθμούς, Ζ και W, από το πληκτρολόγιο και τους εμφανίζει στην οθόνη. Στη συνέχεια υπολογίζει το άθροισμα Z+W και τη διαφορά τους Ζ-W και τα εμφανίζει σε δεκαεξαδική μορφή στην επόμενη γραμμή. Το πρόγραμμα είναι συνεχούς λειτουργίας. Παρακάτω παραθέτουμε μερικά παραδείγματα εκτέλεσης:

```
600 emulator screen (80x37 chars)
                                                                                                           Z+W=43 Z-W=-B
 =01 W=99
+W=64 Z-W=-62
 =00 W=99
+W=63 Z-W=-63
  =80 W=45
+W=7D Z-W=23
```

ask2.asm / emu8086 Code

```
;Gia tis dekades
                               RT: ;Construction, display and storage of Z
PRINTSTR MSGZ
CALL READ_DEC_DIGIT ;1st decimal digit
MUL TEN
LEA DI Z
GOU IDI J.AL
CALL READ_DEC_DIGIT ;2nd unit digit
ADD [DI],AL
;Storage of second digit
                               PRINTLN
                               PRINTLN

MOU AL,[DI] ;W
LEA DI,Z ;Z
ADD AL,[DI] ;Sum
PRINTSTR MSGSUM
CALL PRINT_NUM8_HEX ;Summary display
                               PRINTCH ' '
                               MOU AL.[DI] ;Subtraction ;Z
LEA DI.W ;W
                        CMP AL.BL
JB MINUS
SUB AL.BL
PRINTSTR MSGSUB
JMP SHOWSUB
MINUS:
SUB BL.AL
MOU AL.BL
PRINTSTR MSGMINUS
SHOWSUB:
                                                                 ;Z>W or W>Z ?
                                                                 ;if Z>W
                                                                 ;if Z<W
                 PRINTSTR MSGMINUS
SHOWSUB:
CALL PRINT_NUMB_HEX ;Subtraction result display
PRINTLN
PRINTLN
JMP START
MAIN ENDP
                 ; Instertion and display of decimal digit in AL register READ_DEC_DIGIT PROC NEAR READ: _
                                READCH
CMP AL,48
JB READ
CMP AL,57
                                                                  ;<0 ?
                                                                  ;>9 ?
```

```
JA READ
PRINTCH AL
SUB AL, 48
RET

READ_DEC_DIGIT ENDP

READ_DEC_DIGIT ENDP

READ_DEC_DIGIT ENDP

PRINT_NUMB_HEX PROC NEAR

MOU DL, AL
AND DL, OFOH
MOU CL, 4
ROR DL, CL
CMP DL, 0
SKIPZERO
CALL PRINT_HEX
SKIPZERO:
MOU DL, AL
AND DL, OFH
CALL PRINT_HEX
RET

PRINT_NUMB_HEX ENDP

PRINT_HEX PROC NEAR
CMP DL, 9
JG LETTER
ADD DL, 48
JMP SHOW
LETTER:
ADD DL, 55
SHOW:
PRINT_HEX ENDP

PRINT_HEX ENDP

PRINT_HEX ENDP

PRINT_HEX PROC NEAR
CMP DL, 9
JG LETTER
ADD DL, 55
SHOW:
PRINT_HEX ENDP

PRINT_HEX ENDP

PRINT_HEX ENDP

PRINT_HEX PROC NEAR
CMP DL, 9
JG LETTER
ADD DL, 55
SHOW:
PRINTCH DL
RET

PRINT_HEX ENDP

PRINT_HEX ENDP

PRINT_HEX ENDP

CODE ENDS
END MAIN
```

3η Άσκηση

Το πρόγραμμα δέχεται έναν 12-bit δεκαεξαδικό αριθμό από τον BX και τον εμφανίζει σε δεκαδική, οκταδική και δυαδική μορφή. Ανάμεσα στα αποτελέσματα τοποθετεί ένα =, ενώ αν δοθεί ο χαρακτήρας Τ τερματίζεται. Το πρόγραμμα είναι συνεχούς λειτουργίας. Στο παρακάτω παράδειγμα εκτέλεσης τρέξαμε με τους αριθμούς AAA, BBB, ABC και προέκυψε το εξής αποτέλεσμα:

```
emulator screen (80x25 chars)

2730=101010101010=5252
3003=1011110111=5673
2748=101010111100=5274
```

Ask3.asm / emu8086 Code


```
; Microcomputer Systems - Roh Y [6th Semester]
; 5th Series of Exercises
; Kazdagli Ariadni - 03118838
; Vitalis Vikentios - 03118803
                                           | 902 ; 5th Series of E |
903 ; Kazdagli Ariadn |
904 ; Vitalis Vikenti |
905 |
906 |
907 |
908 | PRINT MACRO CHAR |
909 |
909 | PUSH AX |
909 |
9010 | MOU DL, CHAR |
9011 | MOU AH, 2 |
9012 | INT 21H |
9014 |
9015 | POPP AX |
9016 |
9017 | READ MACRO |
9018 | FOR AR |
9019 | PUSH AX |
9021 |
9022 | PUSH AX |
9024 |
9025 | MOU AH, 9 |
9026 |
9026 | MOU AH, 9 |
9026 |
9027 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
9028 |
902
                                               003
                                                                                                                                                                                                                          ;MACRO to print a character
;Char must be defined ;before translation
                                                                                                                                                                                                                                 ;MACRO to read from keyboard;The value of ASCII char is returned;through AL
                                                                                                                                                                                                                    ;MACRO to print new line
                                           ;Get first hex digit
;If it's T then end
;Else store its value to BH
;BX will have the 12 bit number
;Get second hex digit
                                                                                                                                                                                                                                ;Store its value to BL
                                                                                                                                                                                                                               ;Rotate the value to 4 MSB ;Get third hex digit
                                                                                                                                                                                                                                ;BL has the 2nd and 3rd digit
                                                                   PRINT_OCT PROC NEAR
PUSH AX
MOU BX,8
MOU CX,0
                                                                                                                                                                                                                       ;Print 12bit number in octal
                                                                                                                                                                                                                          ;We have to divide number with 8
;Initialise counter
```

```
076 GETOCT:
077 MOU DX, 0
078 DIU BX
079 PUSH DX
080 INC CL
                                                                  ;DX will have the remainder of the division ;Divide number with 8 ;Save the remainder to the stack ;Increase counter ;If quotient is 0 then there isnt any digit left
078 DIU BX
079 PUSH DX
080 INC CL
081 CMP AX.0
082 JNE GETOCT
083 PRINTOCT:
084 POP AX
085 ADD AL.48
086 PRINT AL
                                                                  Read one digit from the stack Calculate ASCII code and print the corresponding character on the screen
086
087
                  PRINT
                  LOOP PRINTOCT
POP AX
 088
089 RET
090 PRINT_OCT ENDP
091
092
093
094
095
       PRINT_BIN PROC NEAR
PUSH AX
MOU BX,2
MOU CX,0
                                                                ;Print 12bit number in binary
                                                                  ;We have to divide number with 2;We follow the same process as above;but instead of dividing by 8;we divide number with 2
096
097
098
099
100
        GETBIN:
       GETBIN:
MOU DX.0
DIU BX
PUSH DX
INC CL
CMP AX.0
JNE GETBIN
PRINTBIN:
 101
102
103
                  POP AX
ADD AL,48
PRINT AL
 104
                                                                  ;Calculate ASCII code and print the ;corresponding character on the screen
 106
                            PRINTBIN
109
                                                                 ;Print 12bit number in decimal
                                                                  ;We have to divide number with 10;We follow the same process as above;but instead of dividing by 2;we divide number with 10
                                                                          divide number with
                                                                  ;Calculate ASCII code and print ;the corresponding character on the screen
 130 PRINT_DEC ENDP
133
134 HEX_KEYB PROC NEAR
135
                                                                 ;Read a hex digit from the keyboard ;and store it in AL
        I GNORE:
                  READ
                                                                  Read from keyboard
138
139
                  CMP AL, 'T'
JE ADDR2
CMP AL, 30H
                                                                          char is T
                                                                                                 then end routine
                                                                 ;Check if char is a digit
;If it isn't then wait for a valid input
;Check if char is a digit greater than 9
;If it is then check if its A,B,C,D,E or F
;Export the correct number from its ASCII value
 140
                  CMP AL, 30H
JL IGNORE
CMP AL, 39H
JG ADDR1
SUB AL,30H
JMP ADDR2
141
142
143
144
145
146 ADDR1:
                  CMP AL,'A'
JL IGNORE
CMP AL,'F'
JG IGNORE
147
148
                                                                     ;Check if char is a valid hex digit; If it isn't then wait for a valid input
149
150
                   SUB AL,37H
                                                                     Export the correct number from its ASCII value
        ADDR2:
RET
154 HEX_KEYB ENDP
155 CODE_SEG ENDS
156 END MAIN
```


4η Άσκηση

Το πρόγραμμα δέχεται έως 20 πεζούς αγγλικούς (a-z) και αριθμητικούς (0-9) χαρακτήρες από το πληκτρολόγιο και τους εμφανίζει στην οθόνη σε μία γραμμή τον έναν δίπλα στον άλλο. Στην συνέχεια, με τη συμπλήρωση 20 χαρακτήρων ή όταν δοθεί ENTER, εμφανίζει στην επόμενη γραμμή την ίδια σειρά χαρακτήρων με τους αγγλικούς χαρακτήρες κεφαλαίους (A-Z). Το πρόγραμμα είναι συνεχούς λειτουργίας και τερματίζεται αν δοθεί =.

Επίσης ανάμεσα στους χαρακτήρες και στα νούμερα προστίθεται μία παύλα '-' όπως φαίνεται παρακάτω:



Στην περίπτωση που δοθεί '=' παρακάτω φαίνεται το μήνυμα τερματισμού:



Ask4.asm / emu8086 Code

```
901; Microcomputer Systems - Roh Y [6th Semester]
902; 5th Series of Exercises
903; Kazdagli Ariadni - 03118838
904; Uitalis Uikentios - 03118803
006
007 INCLUDE macros.asm
010
DATA_SEG SEGMENT
STRING DB 20 DUP(?)
NEWLINE DB OAH, ODH, '$'
DATA_SEG ENDS
O15
O16
O17
ASSUME CS:CODE_SEG, DS:DATA_SEG
018
019
020
       MAIN PROC FAR
               MOU AX,DATA_SEG
Й23
024
025
026
027
028
MOI
029
INITIALIZATION:
MOU [STRING+DI],0
032
INC DI ;Initialization with
033;0s in case we press ENTER mid-way and to delete everything from last run
LOOP INITIALIZATION
               MOU CX,20
MOU DI,0
MOU DX,0
036
037
038
                                                                     ;Loop for 20 chars
039
040
041
042
043
044
044
045
046
046
046
046
047
                                                                     ;Read char
043
044
045
046
047
                                                                     ;If enter go to auxiliary
;Else store in table String
                                                                     ; Loop
Й48
049 AUXILIARY:
050 MOU CX,DX
051 MOU DI,0
                                                                     ;DX has the number of chars
       DISPLAY:
PRINT [STRING+DI]
                                                                  ;Print the chars
               INC DI
LOOP DISPLAY
                                                                    ;Loop for the num of chars
               PRINTLN NEWLINE
               MOU CX,DX
INC CX
MOU DI,0
060
061
062
      CHARACTERS:
MOU AL, [STRING+DI]
INC DI
DEC CX
CMP CX, 00H
JZ CONTINUE
CMP AL, 'a'
                                                                    ;Load the chars
068
069
070
071
072
073
074
075
                                                                     ; If we reached 0 then stop
               JZ CONTINUE
CMP AL, AL
JL CHARACTERS
CMP AL, '2'
JG CHARACTERS
SUB AL, 20H
PRINT AL
                                                                     ; If the char is a letter
                                                                     ;Subtract 20H to make it upper ;Print it
076
```

```
JMP CHARACTERS
        CONTINUE:
                                                                          ;Now for the numbers
                PRINT '-'
MOU DI 0
MOU CX DX
INC CX
      NUMBERS:

MOU AL, [STRING+DI]
INC DI
DEC CX
CMP CX, 00H
JZ CONTINUE2
CMP AL, 30H
II NUMBERS
                                                                              :If char is num then print it
                GMP AL, 30H
JL NUMBERS
CMP AL
                CMP AL, 39H
JG NUMBERS
PRINT AL
JMP NUMBERS
997 PRINT |
998 JMP NU|
999 CONTINUE2:
101 PRINTL
102 PRINTL
103 JMP ST
104
105 QUIT:
                PRINTLN NEWLINE
       QUIT:
EXIT
MAIN ENDP
       GET_CHAR PROC NEAR IGNORE:
                ORE:
READ
CMP AL, 3DH
JE QUIT
CMP AL, ØDH
JE OK
CMP AL, ØBH
JL IGNORE
CMP AL, 39H
JG CHECK_LETTER
JMP OK
                                                                          ; If char is = then quit
                                                                          :Char must be either ENTER or Number or small letter
       CHECK_LETTER:

CMP AL,'a'

JL IGNORE

CMP AL,'z'

JG IGNORE
130 OK:
                INC DX
                                                                           ; Num of chars read
       GET_CHAR ENDP
       CODE_SEG ENDS
END MAIN
```

5η Άσκηση

Για την υλοποίηση προγραμματιστικά των συναρτήσεων χρησιμοποιήθηκε η εντολή DIV που δίνει πηλίκο, άρα τα αποτελέσματα των υλοποιήσεων αυτών είναι τα ακέραια μέρη των ζητούμενων αριθμών και αποθηκεύονται στον ΑΧ. Από το υπόλοιπο της διαίρεσης, που αρχικά τοποθετείται στον DX, προκύπτει το μονοψήφιο κλασματικό μέρος των αριθμών. Οι συναρτήσεις των 2 κλάδων και ο τρόπος υπολογισμού των κλασματικών μερών φαίνονται παρακάτω:

```
Πρώτος κλάδος: T = 800V/4095
Δεύτερο κλάδος T = (3200V/4095) – 1200
Κλασματικό μέρος = (10 * υπόλοιπο)/4095
```

Τ είναι η ζητούμενη θερμοκρασία και V η τάση εξόδου του ADC. Επισημαίνεται ότι το κλασματικό μέρος είναι ίδιο και για τους 2 κλάδους, αφού έχουν τον ίδιο διαιρέτη στη συνάρτησή τους.

```
START(Y,N):Y

7FF 399,9

BFF 1199,8

C00 ERROR
3E8 195,3

BB8 1144,3

B00 100,5

FFF ERROR

C01 ERROR
```

ask5.asm / emu8086 Code

```
001 INCLUDE macros.asm
DATA SEGMENT
STARTPROMPT DB "START(Y,N):$";Starting message
ERRORMSG DB "ERROR$"; Error message
                 CODE SEGMENT
ASSUME CS:CODE, DS:DATA
009
010
011
012
013
014
015
016
017
                                       MAIN PROC FAR
MOV AX,DATA
MOV DS,AX
                                                           PRINTSTR STARTPROMPT
START: ;Instertion of starting character
                                                                                READCH
                                                         READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH

READCH
                                                                                                                                                                                   ; = N ?
; EndΓ
; = Y ?
019
020
021
022
023
024
025
026
                                                                                                                                                                                   Function
                                                                                                                                                                                   ;Display of starting character
027
028
029
030
031
032
033
034
035
                                                                                                                                                                                  ;3 Hex digits
                                                                                                                                                                                   ;Insertion of digit
;Check for ending
                                                                                JE FINÍSH
                                                                                                                                           ;Union of digits in DX register
                                                                               PUSH CX
DEC CL
ROL CL,2
MOU AH,0
ROL AX,CL
OR DX,AX
POP CX
                                                                                                                                                                                 ;Shifting
                                                                                                                                                                                   ;Left shift 8, 4, 0 digits ;Addition of digit in the number
                                                                                LOOP READTEMP
                                                                                PRINTTAB
                                                                              PRINTIAB
MOU AX, DX
CMP AX, 2047
JBE BRANCH1
CMP AX, 3071
JBE BRANCH2
PRINTSTR ERRORMSG
PRINTLN
JMP NEWTEMP
                                                                                                                                                                                   ;U<=2 ?
047
048
049
050
051
052
053
                                                                                                                                                                                  ;U<=3 ?
                                                                                                                                                                             :0>3
                                                           BRANCH1:
                                                                                                                                         ;1st branch: U<=2, T=(800*U) div 4095
                                                                               NCH1:
MOU BX,800
MUL BX
MOU BX,4095
DIU BX
JMP SHOWTEMP
056
057
058
059
060
061
062
063
                                                                                                                                            ;2nd branch: 2\langle V\langle =3, T=\langle (3200*V) div 4095\rangle-1200
                                                            BRANCH2:
                                                           BRANCH2: ;2nd :
MOU BX,3200
MUL BX
MOU BX,4095
DIU BX
SUB AX,1200
SHOWTEMP:
CALL PRINT_DEC16
                                                                                                                                            EC16 ;Display of whole part in (AX) register
;Fraction part = ( remainrder *10 ) div 4095
                                                                               MOU AX,DX
MOU BX,10
MUL BX
MOU BX,4095
DIU BX
                                                                                PRINTCH ','
                                                                                                                                                                                 ;comma
```

```
076
077
078
079
080
                               ADD AL, 48
PRINTCH AL
PRINTLN
                                                                       Code ASCII
                                                                       ;Display of fraction part
                               JMP NEWTEMP
081
082
                       FINISH:
PRINTCH AL
               EXIT
083
084
085
086
                                                       ;Instert hex digit in AL register
               HEX_KEYB PROC NEAR READ:
087
088
                      READCH
CMP AL,'N'
JE RETURN
CMP AL,48
JL READ
CMP AL,57
JG LETTER
PRINTCH AL
SUB AL,48
JMP RETURN
LETTER:
CMP AL,'A'
JL READ
CMP AL,'F'
JG READ
PRINTCH AL
SUB AL,55
RETURN:
                               READCH
089
090
091
092
093
094
                                                                       ;=N ?
                                                                       ;<0 ?
                                                                       ;>9 ?
095
096
097
098
                                                                      ;Code ASCII
                                                                      ;A...F
;<A ?
099
100
101
102
                                                                      ;>F ?
103
104
                                                                      ;Code ASCII
105
106
107
108
               RET HEX_KEYB ENDP
109
111
112
113
114
115
116
117
                                                               ;Display of 16-bit hex numver from AX register
               PRINT_DEC16 PROC NEAR PUSH DX
                       MOU BX.10
MOU CX.0
GETDEC:
MOU DX.0
DIU BX
PUSH DX
INC CL
CMP AX.0
JNE GETDEC
PRINTDEC:
                                                                       ;Decimal => divisions with 10
;Digit counter
                                                       ;Digit export
;Number mod 10 (remainder)
;Division with 10
;Temporary storage
                                                                       ;Number div 10 = 0 ? ( quotient )
                       PRINTDEC: ;I
POP DX
ADD DL, 48
PRINTCH DL
LOOP PRINTDEC
                                                       ;Digit display
                                                                      ;Code ASCII
                               POP DX
                PRINT_DEC16 ENDP
       CODE
       CODE ENDS
END MAIN
133
```