UEFI Basic Tutorial (IV) - Running the First DXE Driver



This article details how to create and run a UEFI DXE stage driver from scratch. It includes the entire process of writing source code, configuring INF and FDF files, compiling to generate EFI files, and running on QEMU. It also compares the differences between UEFI DXE and PEIM, providing practical guidance for UEFI driver developers.

The summary is generated in C Know, supported by DeepSeek-R1 full version, go to experience>

1. Write source code

1. Write C:\edkii\OvmfPkg\MyHelloWorldDXEDriver\MyHelloWorldDXEDriver.c

```
Al generated projects
                                                                                                                                  登录复制
   #include <uefi.h>
   #include <Library/UefiLib.h>
   #include <Library/BaseLib.h>
    #include <Library/DebugLib.h>
    #include <Library/BaseMemoryLib.h>
    #include <Library/UefiDriverEntryPoint.h>
    #include <Library/UefiBootServicesTableLib.h>
 8
    EFI STATUS
    EFIAPI
10
11
    MyHelloWorldDXEDriverEntry(
12
      IN EFI HANDLE
                           ImageHandle,
13
      IN EFI SYSTEM TABLE *SystemTable
14
15
```

2. Write C:\edkii\OvmfPkg\MyHelloWorldDXEDriver\MyHelloWorldDXEDriver.inf

C Al generated projects 登录复制 run

收起 へ

```
[Defines]
       INF VERSION = 0 \times 00010006
       BASE NAME = MyHelloWorldDXEDriver
       FILE GUID = 6AE7DE6E-F0AF-485f-9937-EB70FDCFC82F
       MODULE_TYPE = UEFI_DRIVER
       VERSION STRING = 1.0
       ENTRY POINT = MyHelloWorldDXEDriverEntry
  8
  9
      [Sources]
 10
       MyHelloWorldDXEDriver.c
 11
 12 [Packages]
 13
       MdePkg/MdePkg.dec
       ShellPkg/ShellPkg.dec
 14
 15
       MdeModulePkg/MdeModulePkg.dec
 16
     [LibraryClasses]
 17
       UefiDriverEntryPoint
 18
 19
       BaseLib
 20
       BaseMemoryLib
       DebugLib
twen
twen
       DevicePathLib
twen
       UefiBootServicesTableLib
       MemoryAllocationLib
twen
 25
       UefiLib
 26
 27
     [depex]
 28
       TRUE
4
```

3. Modify C:\edkii\OvmfPkg\OvmfPkgX64.dsc

 C
 Al generated projects
 登录复制 run

 1 [Components]
 ...

 2 ...
 ...

 3 #
 4 # DXE Phase modules

 5 #
 6 OvmfPkg/MyHelloWorldDXEDriver/MyHelloWorldDXEDriver.inf

 7 ...
 Al generated projects
 登录复制 run

1 [FV.DXEFV]
2 ...
3 #
4 # DXE Phase modules
5 #
6 INF OvmfPkg/MyHelloWorldDXEDriver/MyHelloWorldDXEDriver.inf
7 ...

2. Compile and generate EFI files

Run and edksetup.bat compile the entire OvmfPkg Package

3. Run HelloWorld DXE Driver

1. Copy C:\edkii\Build\OvmfX64\DEBUG_VS2013x86\FV\OVMF.fd to C:\qemu

2. Execute as follows setup-gemu-x64.bat | findstr MyHelloWorldDXEDriver

```
C:\qemu>setup-qemu-x64.bat | findstr MyHelloWorldDXEDriver
WARNING: Image format was not specified for 'HDD_BOOT.img' and probing guessed raw.
Automatically detecting the format is dangerous for raw images, write operations on block 0 will be restricted.

Specify the 'raw' format explicitly to remove the restrictions.
Loading driver at 0x0000FA65000 EntryPoint=0x0000FA65374 MyHelloWorldDXEDriver.efi
MyHelloWorldDXEDriverEntry Start..
MyHelloWorldDXEDriverEntry Endt..
```

IV. Summary

UEFI DXE UEFI PEIM The difference between and

- 1. MODULE TYPE in INF file is different (PEIM, UEFI DRIVER)
- FDF The placement in the file is different.
 PEIM It needs to be placed at [FV.PEIFV] the bottom, but DXE in the [FV.DXEFV] middle

DXEDriver DEMO source code

1元买摇钱树课!TikTok爆单全靠这招?

大佬绝不外传的流量分析法→ 抓紧薅秃!

bout Careers Business Seeking coverage 400-660- 1018 Wefu@csdn.net Customer Service Service Security Registration Number 11010502030143 Beijing ICP No. 19004658 Beijing Internet Publishing House [2020] No. 1039-165 Commercial website registration information Beijing Internet Illegal and Harmful Information Reporting Center Parental Control Online 110 Alarm Service China Internet Reporting Center Chrome Store Download Account Management Specifications Copyright and Disclaimer Copyright Complaints Publication License Business license

广告