AV312 - Lecture 12

Vineeth B. S.

Department of Avionics, Indian Institute of Space Science and Technology.

Figures from "Communication Systems" by Haykin and "An Intro. to Analog and Digital Commn." by Haykin and Moher

August 24, 2016

VBS AV312 August 24, 2016 1 / 19


Review of last classes

- Analog modulation and demodulation
- Sampling
- ► Introduction to PAM

Today's class

- ▶ Pulse amplitude modulation
- Quantization
- Pulse code modulation
- ▶ Today's scribes are Litu Rout and Manasvi Bhat


Pulse amplitude modulation



- Message signal m(t) is finite energy and bandlimited
- \triangleright Sampling frequency is f_s which is greater than or equal to the Nyquist rate
- ▶ PAM signal $s(t) = \sum_{n=-\infty}^{\infty} m(nT_s)h(t-nT_s)$

VBS AV312 August 24, 2016 4 / 19


Pulse amplitude modulation and demodulation system



- $ightharpoonup s(t) = \sum_{n=-\infty}^{\infty} m(nT_s)h(t-nT_s)$
- We can represent s(t) in an alternate way
- ► Consider $m_{\delta}(t) \star h(t)$?

VBS AV312 August 24, 2016 5 / 19


Pulse amplitude modulation and demodulation system



- \triangleright $s(t) = \sum_{n=-\infty}^{\infty} m(nT_s)h(t-nT_s)$
- \blacktriangleright We can represent s(t) in an alternate way
- ► Consider $m_{\delta}(t) \star h(t)$?
- $m_{\delta}(t) \star h(t) = \sum_{n=-\infty}^{\infty} m(nT_s) \int_{-\infty}^{\infty} h(t-\tau) \delta(\tau nT_s) d\tau$
- So s(t) is obtained by $m(t) \rightarrow \text{Inst. sampling} \rightarrow m_{\delta}(t) \rightarrow h(t) \rightarrow s(t)$

VBS AV312 August 24, 2016 5 / 19

Pulse amplitude modulation and demodulation system



- We can represent s(t) in an alternate way
- ▶ Consider $m_{\delta}(t) \star h(t)$?

- ▶ So s(t) is obtained by $m(t) o ext{Inst.}$ sampling $o m_\delta(t) o h(t) o s(t)$
- ▶ The equalizer has to compensate for h(t)
- ▶ The effect due to the h(t) block is called aperture effect
- ▶ If channel has a known impulse response c(t), then equalizer has to compensate for that too


VBS AV312 August 24, 2016 5 / 19

Analysis of PAM modulation and demodulation

Suppose

$$h(t) = \begin{cases} 1, 0 < t < T, \\ 1/2, t = 0 \text{ or } t = T, \\ 0, \text{ otherwise.} \end{cases}$$

► What is H(f)? $H(f) = T sinc(fT) e^{-j\pi fT}$



6 / 19

VBS AV312 August 24, 2016


PAM demodulation

- ▶ To compensate for the effect of H(f) the equalizer should be $\frac{1}{H(f)}$.
- ▶ However, if the equalizer is placed after the LPF, we only need to compensate using $\frac{1}{H(f)}$ for $f \in [-W, W]$
- ▶ If C(f) is known, then the equalizer should be designed to be $\frac{1}{C(f)H(f)}$ within the band of interest

VBS AV312 August 24, 2016 7 / 19

Why is PAM used?

- Using a discrete time signal allows for time division multiplexing
- Read Sections 3.4 (PWM, PPM) and 3.9 (TDM) from the textbook "Communication Systems"



VBS AV312 August 24, 2016 8 / 19

Quantization

- ▶ We are now moving to digital transmission of analog signals time has been discretized by sampling, amplitude is discretized using quantization.
- \blacktriangleright m(t) be a finite energy bandlimited signal and $m(nT_s)$ denotes its samples
- Quantization is a mapping g(.); $v(nT_s) = g(m(nT_s))$
- ▶ The value of sample is mapped by g(.) to a discrete set
- ▶ For brevity, let us drop the time index nT_s

VBS AV312 August 24, 2016 9 / 19


Quantization function g(.)



- ▶ The mapping g(.) is specified as follows:
 - ▶ Let I_k be the interval $(m_k, m_{k+1}]$
 - ▶ The amplitude m is represented by the index k if $m_k < m \le m_{k+1}$
 - ▶ The index k is converted to a representation v_k . All $m \in (m_k, m_{k+1}]$ is represented using v_k .
- $ightharpoonup m_k$ are called decision levels or thresholds
- v_k are called representation or reconstruction levels
- ▶ The spacing between two reconstruction levels, i.e., $v_k v_{k-1}$ is called quantum or step size
- ▶ We are doing scalar quantization a memoryless transformation

VBS AV312 August 24, 2016 10 / 19


More about Quantization function g(.)



VBS AV312 August 24, 2016


11 / 19

Pulse code modulation



VBS AV312 August 24, 2016 12 / 19


Pulse code modulation - Sampling



► Antialiasing filter + sampling at more than the Nyquist rate

VBS AV312 August 24, 2016 13 / 19

Pulse code modulation - Quantization




▶ If the input signal is voice, then non-uniform quantization is usually used

VBS AV312 August 24, 2016 14 / 19


Pulse code modulation - Companding

- ▶ Instead of using a non-uniform quantizer, we can transform the signal and then use a uniform quantizer
- If the signal is compressed using a function c(.), i.e., $m_1(t) = c(m(t))$ then it has to be expanded using an inverse function $c^{-1}(.)$
- The combination of compression and expanding is called companding.
- Usually two standard ways of compression (and therefore expansion) are used
- \triangleright μ -law and A-law (Find out the transformation function from the text)



AV312 August 24, 2016 15 / 19

Pulse code modulation - Encoding




- ► The quantizer output, i.e., the representation level is encoded using a binary code. Usually this is just a binary representation of the index *k* that we had seen before.
- Usually a binary code is used because it is easy to distinguish between two levels in noise.

VBS AV312 August 24, 2016

16 / 19


Pulse code modulation - Binary code as signals



- ► The binary code is sent over the channel (line) by first converting it into a voltage signal
- ► There is a mapping from binary {0,1} to pulse shapes. Several possibilities are shown

VBS AV312 August 24, 2016 17 / 19


Pulse code modulation - Regeneration



- We equalize or compensate for the effects of the channel
- ▶ The line code is resampled and passed through a decision device to obtain the binary code back
- ▶ The binary code is used to regenerate the PCM line code again
- Errors might occur during regeneration.

VBS AV312 August 24, 2016 18 / 19

Pulse code modulation - Receiver



- ▶ We obtain the binary code by sampling the line code
- ▶ Then the binary code is mapped back to the representative levels v_k and to an impulse train
- Then a reconstruction filter as in the case of PAM is used

VBS AV312 August 24, 2016

19 / 19