
NWEN 242

Pipelining hazards / data hazards 1





Agenda

- Hazards
 - Structural hazards
 - Data hazards
 - Control hazards
- Data hazards
 - Fixing hazards



Hazards

Situations that prevent starting the next instruction in the next cycle



- Structural hazards
 - A required resource is busy
- Data hazards
 - Need to wait for previous instruction to complete its data read/write
- Control hazards
 - Deciding on control action depends on previous instruction

Structural hazards



- Conflicting demands for use of a resource
- In MIPS we use Instruction memory and Data memory
 - Two hardware resources dedicated to accessing
 - Instructions and Data
 - What if only one resource was used?
 - Single cycle would cope ok
 - Pipelined datapaths will try using the same resource twice
- Hence, pipelined datapaths require separate hardware for accessing instruction/data memories

Data hazards



Where an instruction depends on the result of a previous instruction.

```
add$s0, $t0, $t1
sub$t2, $s0, $t3
```

Control Hazards

Branch hazards

- The branch determines control flow
 - Fetching next instruction depends on branch outcome
 - Pipeline can't always fetch correct instruction
 - Identifying a branch instruction ==> ID (Instruction Decode)
 - Next instruction is already in ====> IF (Instruction Fetch)

Data hazards

Consider this sequence:


```
sub $2, $1,$3
and $12,$2,$5
or $13,$6,$2
add $14,$2,$2
sw $15,100($2)
```

Where are the data hazards?


Data hazards in multiple-clock-cycle pipeline diagram

Recall:

- An R-type instruction writes ALU result into register file during WB (fifth) stage
- Register file is read in the ID (second) stage



Data hazards in single-clock-cycle pipeline diagram



Question for you


- Hazards make computation in a pipelined datapath unreliable
- The problem is aggravated if the Register File is read at the start and written at the end of a cycle
- What to do?
 - a) Give up and abandon the pipelined datapath
 - b) To consider hazard prevention techniques
 - -> Bubbles/stalls/nops are sometimes inevitable




Insert bubbles / stalls / nops



```
sub $2, $1,$3
and $12, $2,$5
or $13, $6,$2
add $14, $2,$2
sw $15, 100($2)
```



```
sub $2, $1, $3
nop
nop
and $12, $2, $5
or $13, $6, $2
add $14, $2, $2
sw $15, 100 ($2)
```



No Operation (do nothing)

Prevention of hazards

- Who should be responsible for detecting (and presumably correcting) them?
- It's probably not fair to ask the programmers to do this, because that means he/she needs to be knowledgeable about the intricacies of the pipeline
- So, the compiler or assembler can be programmed to know about the pipeline and do the detection



Compiler prevention of hazards


- Let's assume first that the compiler does the detection
 - It has a table telling it which instructions are potentially at risk.
 - This table says something like 'the result of an R-type instruction will not be available within 3 cycles, so make sure that those three cycles don't need to read from the register file'.
- Once the compiler has detected a hazard it can fix the hazard by inserting nop instructions. "nop" stands for 'no operation'
 - It can be a real operation like or \$0, \$0, \$0, which does nothing, or
 - A pseudo instruction just like nop
 - nops act like bubbles




Compiler prevention of data hazards



```
sub $2, $1,$3
and $12, $2,$5
or $13, $6,$2
add $14, $2,$2
sw $15, 100($2)
```



```
sub $2, $1, $3
nop
nop
and $12, $2, $5
or $13, $6, $2
add $14, $2, $2
sw $15, 100 ($2)
```



No Operation (do nothing)

using nops == 3 cycle bubble

Hardware prevention of data hazards

- 34 min

- Hardware detects hazard in AND instruction:
 - AND is stalled
 - bubbles (nops) are inserted in the pipeline until hazard goes away
 - bubbles move through pipeline just as ordinary instructions
- Detection occurs in ID stage
 - Instruction wants to read a register to be written by an instruction in the EX, MEM, or WB stages
 - Hazard clears when conflicting instruction leaves WB stage

```
sub $2, $1, $3
and $12, $2, $5
or $13, $6, $2
add $14, $2, $2
sw $15, 100 ($2)
```


R/W behavior of register file


- From now on, when considering hardware detection and prevention of hazards, we shall assume that our pipelined datapath contains a special register file
- Register file is special in the sense that it is written in the first half, and read in the second half of a processor clock
- The consequence is that data written by an instruction being in the WB stage, will be read by an instruction being in the ID stage during the same clock cycle
- So, only two bubbles will be needed between two consecutive Rtype instructions


Data hazards in multiple-clock-cycle pipeline diagram


Recall:

- An R-type instruction writes ALU result into register file during WB (fifth) stage
- Register file is read in the ID (second) stage










Pipeline after the hazard





How to create a nop / bubble?

ID stage detects a hazard



- PC is prevented from being updated
 - So IF stage will fetch the same instruction again
 - No new instructions can enter the pipeline
- IF/ID register is prevented from being updated
 - So ID stage will decode the same instruction again
- The EX, MEM and WB control fields of ID/EX register is zeroed to create the bubble
 - Control values are all 0
 - No registers or memories are written
- We keep stalling until the hazard has gone

Stalling a pipeline



- A simple solution
- Performance penalty
- There are cases that you have to stall
- You may want to avoid stalling when you can
- Forwarding

using stalling == 2 cycle bubble

Forwarding



- Forwarding the data as soon as it is available to any units that need it before it is available to read from the register file
- Forwarding is an alternative approach to address data hazards
 - It means short-circuiting the loop from the output of the ALU to the register file,
 - Normally this loop takes in the MEM and WB stages
- We need bigger multiplexors on the ALU inputs
- We need new datapaths from MEM (and WB) directly into EX


Data Hazards


Consider this sequence:

```
sub $2, $1,$3
and $12,$2,$5
or $13,$6,$2
add $14,$2,$2
sw $15,100($2)
```

We can resolve hazards with forwarding

Dependencies & Forwarding





What forwarding needs?

- Forwarding needs:
 - Hazard detection, and then
 - Feeding ALU output from MEM or WB stage to ALU inputs
 - Pipeline registers contain addresses of destination registers
 - rd
- So, forwarding doesn't require any delay (nops) between two successive R-type instructions
- It passes the second instruction directly to EX stage

using forwarding == 0 cycle bubble between two R-types

using forwarding == 1 cycle bubble between lw and R-type

Summary

- Three types of hazards:
 - Structural hazards
 - Data hazards
 - Control hazards
- Register file is written in the first half, and read in the second half of a clock cycle
- The use of nops / bubbles to prevent data hazards
 - Compiler (software) / hardware solutions
- Stalls/nops cause performance penalty
- Forwarding