✓ 100 XP

# Blocos de construção do projeto

6 minutos

# Introdução

Vamos examinar os blocos de construção do código que são usados no projeto.

# Bloco de construção 1

#### Declarações, definições e protótipos

Usamos este código para criar declarações, definições e protótipos:

```
C
/* ProjectPriorityInversion.c Priority Inversion Problem
  Create three threads, one byte pool, one mutex, two timers.
  This project contains a Priority Inversion problem;
  your task is to run it as-is and record observations.
  Then eliminate Priority Inversion by first incorporating
  Priority Inheritance, and then Preemption-Threshold,
  each time recording your results. */
   Declarations, Definitions, and Prototypes
   /******************/
#include
          "tx_api.h"
#include
         <stdio.h>
          STACK_SIZE
#define
                            1024
#define
         BYTE POOL SIZE
                            9120
         DISPLAY_INTERVAL
#define
                            5001
#define
          UPDATE INTERVAL
                            200
/* Define the ThreadX object control blocks */
TX THREAD
             Urgent thread;
TX THREAD
             Important_thread;
TX_THREAD
             Routine_thread;
TX MUTEX
             my mutex;
```

```
TX_BYTE_POOL
              my_byte_pool;
TX TIMER
               stats timer, update timer;
/* Define variables for Routine thread performance info */
      resumptions_Routine;
ULONG
       suspensions_Routine;
ULONG
       solicited_preemptions_Routine;
/* Define variables for Urgent thread performance info */
ULONG resumptions_Urgent;
ULONG suspensions_Urgent;
/* Define variables for use with mutex performance information */
ULONG mutex_puts;
ULONG mutex gets;
/* Define variable for time analysis */
ULONG current_time;
/* Define prototypes */
     Urgent_thread_entry(ULONG thread_input);
void
       Important thread entry(ULONG thread input);
void
       Routine_thread_entry(ULONG thread_input);
void
void
       print_stats(ULONG), print_update(ULONG);
```

#### ① Observação

Você não fará nenhuma alteração nesse código ao trabalhar com o arquivo de projeto no Visual Studio.

# Bloco de construção 2

#### Ponto de entrada principal

Usamos este código para o ponto de entrada principal.

#### ① Observação

Esse bloco de construção é idêntico aos projetos em módulos anteriores. Não há necessidade de alteração nesse código ao trabalhar com o arquivo de projeto no Visual Studio.

# Bloco de construção 3

### Definições de aplicativo

Usamos este código para criar definições de aplicativo:

```
C
/*****************/
             Application Definitions
                                                 */
/* Define what the initial system looks like.
       tx_application_define(void* first_unused_memory)
void
{
   CHAR* Urgent_stack_ptr, * Important_stack_ptr,
       * Routine_stack_ptr;
   /* Create a memory byte pool from which to allocate
      the thread stacks */
   tx_byte_pool_create(&my_byte_pool, "my_byte_pool",
       first_unused_memory, BYTE_POOL_SIZE);
   /* Put system definition stuff in here, e.g., thread
      creates and other assorted create information */
   /* Allocate the stack for the Urgent_thread */
   tx_byte_allocate(&my_byte_pool, (VOID**)&Urgent_stack ptr,
       STACK_SIZE, TX_NO_WAIT);
    /* Create the Urgent thread. */
   tx thread create(&Urgent thread, "Urgent thread",
       Urgent_thread_entry, 0, Urgent_stack_ptr,
       STACK_SIZE, 10, 10, TX_NO_TIME_SLICE,
       TX AUTO START);
    /* Allocate the stack for the Important_thread. */
   tx byte allocate(&my byte pool, (VOID**)&Important stack ptr,
       STACK SIZE, TX NO WAIT);
   /* Create the Important thread. */
   tx_thread_create(&Important_thread, "Important_thread",
       Important_thread_entry, 0, Important_stack_ptr,
```

```
STACK_SIZE, 15, 15, TX_NO_TIME_SLICE,
       TX AUTO START);
   /* Allocate the stack for the Routine thread.
   tx_byte_allocate(&my_byte_pool, (VOID**)&Routine_stack_ptr,
       STACK_SIZE, TX_NO_WAIT);
   /* Create the Routine_thread.
      **** for PREEMPTION-THRESHOLD, change 20,20 to 20,10 */
   tx_thread_create(&Routine_thread, "Routine_thread",
       Routine_thread_entry, 1, Routine_stack_ptr,
       STACK SIZE, 20, 20,
       TX NO TIME SLICE, TX AUTO START);
   /* Create the mutex used by both threads
      **** for PRIORITY INHERITANCE change to TX INHERIT */
   tx_mutex_create(&my_mutex, "my_mutex", TX_NO_INHERIT);
   /* Create and activate the display timer */
   tx_timer_create(&stats_timer, "stats_timer", print_stats,
       0x1234, DISPLAY_INTERVAL, 0, TX_AUTO_ACTIVATE);
   /* Create and activate the update timer */
   tx_timer_create(&update_timer, "update_timer", print_update,
       0x1234, UPDATE INTERVAL, UPDATE INTERVAL, TX AUTO ACTIVATE);
}
```

#### ( Observação

Na próxima unidade, faça essas alterações nas linhas de código realçadas:

- Empregue a herança de prioridades para evitar o problema de inversão de prioridades. Quando o mutex foi criado, a herança de prioridades não estava habilitada. Para habilitar a herança de prioridades, você altera a opção mutex de TX\_NO\_INHERIT para TX\_INHERIT. Depois de experimentar essa alteração e registrar seus resultados, você pode alterar a opção de volta para TX\_NO\_INHERIT.
- Quando o thread Rotina foi criado, o limite de preempção foi definido como 20. Na próxima unidade, você vai experimentar a alteração do limite de preempção para
   10. Em seguida, você realizará experimentos e registrará seus resultados

# Bloco de construção 4

Não há necessidade de alteração no código a seguir ao trabalhar com o arquivo de projeto no Visual Studio.

### Função de entrada do thread Urgente

Usamos este código para criar a função de entrada do thread urgente:

```
C
Function Definitions
/* Entry function definition of the Urgent thread
  it has the highest priority */
void Urgent_thread_entry(ULONG thread_input)
{
   while (1)
   {
      /* Processing, then Urgent Thread needs mutex */
      tx thread sleep(4);
      /* Get the mutex with suspension */
      tx_mutex_get(&my_mutex, TX_WAIT_FOREVER);
      tx_thread_sleep(3);
      /* Release the mutex */
      tx_mutex_put(&my_mutex);
   }
}
```

### Função de entrada do thread Importante

Usaremos este código para criar a função de entrada do thread Importante:

```
}
```

# Função de entrada do thread de rotina

Usamos este código para criar a função de entrada do thread de rotina:

```
C
/* Entry function definition of the Routine thread
   it has the lowest priority */
void Routine thread entry(ULONG thread input)
   CHAR letter;
   ULONG kount;
   while (1)
       /* Routine thread and Urgent thread compete for the mutex. */
       /* Get the mutex with suspension */
       tx_mutex_get(&my_mutex, TX_WAIT_FOREVER);
       /* Simulate work by Routine thread */
       for (kount = 1; kount < 100000000; kount++) letter = 'A';</pre>
       /* Release the mutex */
       tx_mutex_put(&my_mutex);
       /* Processing time */
       tx_thread_sleep(1);
   }
}
```

### Função de temporizador de aplicativo print\_stats

Usamos este código para criar a função de temporizador de aplicativo print\_stats:

```
/*******************************
/* print statistics at specified times */
void print_stats(ULONG invalue)
{
    /* Retrieve performance information on Routine thread */
    tx_thread_performance_info_get(&Routine_thread, &resumptions_Routine,
&suspensions_Routine,
    &solicited_preemptions_Routine, TX_NULL, TX_NULL,
    TX_NULL, TX_NULL, TX_NULL, TX_NULL);
```

```
/* Retrieve performance information on Urgent thread */
   tx thread performance info get(&Urgent thread, &resumptions Urgent,
&suspensions_Urgent,
        TX_NULL, TX_NULL, TX_NULL, TX_NULL, TX_NULL, TX_NULL, TX_NULL);
    /* Retrieve performance information on my mutex */
    tx_mutex_performance_info_get(&my_mutex, &mutex_puts, &mutex_gets, TX_NULL,
        TX_NULL, TX_NULL, TX_NULL);
    printf("\nProjectPriorityInversion: 3 threads, 1 byte pool, 1 mutex, and 2
timers\n\n");
    printf("
              Routine thread resumptions: %lu\n", resumptions_Routine);
   printf("
              Routine thread suspensions: %lu\n", suspensions Routine);
    printf("Routine solicited preemptions: %lu\n\n",
solicited_preemptions_Routine);
               Urgent thread resumptions: %lu\n", resumptions_Urgent);
    printf("
    printf("
               Urgent thread suspensions: %lu\n\n", suspensions_Urgent);
    printf("
                              mutex puts: %lu\n", mutex puts);
    printf("
                              mutex gets: %lu\n\n", mutex_gets);
   tx timer deactivate(&update timer);
}
```

## Unidade seguinte: Exercício – compilar e depurar

Continuar >