CleanBot Robotic Vacuum Cleaner FAQ

1. Product Overview

CleanBot offers a range of robotic vacuum cleaners to suit different cleaning needs. Our current lineup includes:

- CB-100 (Basic)
- CB-200 (Smart Navigation)
- CB-300 (Self-Emptying)

Each model is designed to provide efficient and hassle-free cleaning.

2. Technical Specifications

CB-100 (Basic)

Battery Life: 90 minutes

Suction Power: 2000Pa

Dustbin Capacity: 0.5L

Noise Level: 60dB

Weight: 3.5kg

CB-200 (Smart Navigation)

Battery Life: 90 minutes

Suction Power: 2000Pa

Dustbin Capacity: 0.5L

Noise Level: 60dB

Weight: 3.5kg

CB-300 (Self-Emptying)

Battery Life: 90 minutes

Suction Power: 2000Pa

Dustbin Capacity: 0.5L

Noise Level: 60dB

Weight: 3.5kg

3. Key Features

- Efficient Cleaning: High suction power and multiple cleaning modes.
- Smart Navigation: Advanced sensors for better navigation and cleaning.
- Self-Emptying: Automatically empties its dustbin for hands-free maintenance.

4. Setup and Installation

Step-by-step instructions for setting up your CleanBot robotic vacuum cleaner:

- 1. Unbox the vacuum cleaner and charging dock.
- 2. Place the charging dock against a wall and plug it in.
- 3. Place the vacuum cleaner on the dock to charge.
- 4. Download the CleanBot app and follow the setup instructions.

5. Usage Instructions

Detailed guidelines on using various features and optimizing performance:

- Use the app to start, stop, and schedule cleaning sessions.
- Select different cleaning modes (e.g., auto, spot, edge) based on your needs.
- Monitor the cleaning progress and battery status through the app.

6. Maintenance and Care

Guidelines for keeping your robotic vacuum cleaner in top condition:

- Regularly empty the dustbin and clean the filters.
- Check and clean the brushes and sensors to ensure optimal performance.
- Keep the firmware updated for enhanced features and performance.

7. Troubleshooting

Common issues and their solutions:

Problem: Vacuum Cleaner Not Charging

Solution: Ensure the charging dock is plugged in and the vacuum is properly aligned with the dock.

Problem: Reduced Suction Power

Solution: Check for blockages in the suction path and clean the filters.

Problem: Random Navigation

Solution: Reset the navigation system through the app and ensure the sensors are clean.

8. Warranty Information

Comprehensive warranty details for your CleanBot robotic vacuum cleaner:

- Coverage period: 1 year from the date of purchase.
- Includes free repair and replacement for manufacturing defects.
- Excludes damage caused by misuse or unauthorized modifications.

9. Customer Support

Information on how to get support for your CleanBot robotic vacuum cleaner:

- Visit our online support portal for FAQs and troubleshooting guides.
- Contact our support team via phone or email for personalized assistance.
- Locate the nearest service center for in-person support.