# ViewMax Smart TV FAQ

#### 1. Product Overview

ViewMax offers a range of Smart TVs designed to deliver an immersive viewing experience. Our current lineup includes:

- VM-055 (OLED)
- VM-Q65 (QLED)
- VM-L50 (LED)

Each model is equipped with advanced technology and smart features to enhance your entertainment.

# 2. Technical Specifications

# **VM-055 (OLED)**

Screen Size: 55 inches

Resolution: 4K Ultra HD (3840 x 2160)

Refresh Rate: 120Hz

HDR: Dolby Vision, HDR10+

Smart Platform: ViewMax OS

Connectivity: HDMI x 4, USB x 2, Wi-Fi, Ethernet

#### VM-Q65 (QLED)

Screen Size: 55 inches

Resolution: 4K Ultra HD (3840 x 2160)

Refresh Rate: 120Hz

HDR: Dolby Vision, HDR10+

Smart Platform: ViewMax OS

Connectivity: HDMI x 4, USB x 2, Wi-Fi, Ethernet

## **VM-L50 (LED)**

Screen Size: 55 inches

Resolution: 4K Ultra HD (3840 x 2160)

Refresh Rate: 120Hz

HDR: Dolby Vision, HDR10+

Smart Platform: ViewMax OS

Connectivity: HDMI x 4, USB x 2, Wi-Fi, Ethernet

# 3. Key Features

• Stunning Picture Quality: Experience lifelike images with deep blacks and vibrant colors.

- Smart Features: Access popular streaming services, browse the internet, and use voice control.
- Advanced Audio: Enjoy immersive sound with Dolby Atmos support.

# 4. Setup and Installation

Step-by-step instructions for setting up your ViewMax Smart TV:

- 1. Unbox the TV and attach the stand or mount it on the wall.
- 2. Connect the TV to a power source and turn it on.
- 3. Follow the on-screen prompts to connect to Wi-Fi and sign in to your accounts.
- 4. Adjust picture and sound settings to your preference.

#### **5.** Usage Instructions

Detailed guidelines on using various features and optimizing performance:

- Use the home screen to access apps, live TV, and settings.
- Utilize the search function to quickly find content.
- Customize the picture and sound settings to suit different types of content.

#### 6. Maintenance and Care

Guidelines for keeping your Smart TV in top condition:

- Clean the screen regularly with a soft, dry cloth.
- Ensure proper ventilation to prevent overheating.

• Keep the firmware updated for optimal performance.

# 7. Troubleshooting

Common issues and their solutions:

#### **Problem: No Picture or Sound**

Solution: Check the power connection and ensure the TV is turned on. Verify the input source.

# **Problem: Poor Picture Quality**

Solution: Adjust the picture settings and check for any signal interference.

#### **Problem: Unable to Connect to Wi-Fi**

Solution: Restart the TV and router. Check if other devices can connect to the network.

# 8. Warranty Information

Comprehensive warranty details for your ViewMax Smart TV:

- Coverage period: 1 year from the date of purchase.
- Includes free repair and replacement for manufacturing defects.
- Excludes damage caused by misuse or unauthorized modifications.

## 9. Customer Support

Information on how to get support for your ViewMax Smart TV:

- Visit our online support portal for FAQs and troubleshooting guides.
- Contact our support team via phone or email for personalized assistance.
- Locate the nearest service center for in-person support.