

StrataOne

User Deployment Guide

Step-by-step dashboard guide for operators creating, validating, and running StrataOne deployments.

Field	Value
Audience	Deployment operators and platform users
Guide date	10 June 2026
Assumption	StrataOne is already installed and reachable
Primary UI	StrataOne dashboard at http://localhost:8088 or the configured enterprise URL

Golden rule

If Validate or Preflight fails, stop. Fix the data, credentials, network, or hardware condition before running deployment or lifecycle actions.

1. Sign In And Confirm Readiness

1. Open the StrataOne dashboard URL supplied by your administrator.
2. Sign in with your assigned username and password.
3. Confirm the sidebar shows Control plane online and the header shows API online.
4. Do not use the shared admin account unless explicitly instructed.

Check	Expected result
Control plane	Control plane online
API	API: online
User	Your named account is shown in the header
Role	Your role allows deployment or operator actions

2. Create A New Deployment

5. Go to Deployments > New Deployment.
6. Select a built-in deployment template or import a JSON/YAML template supplied by your team.
7. Review the template platform, node count, and use case before continuing.

Platform	Example templates
Azure Local	Branch, Edge Scale, Stretched
VMware vSphere	Management Cluster, Workload Cluster
Nutanix AHV	Edge, ROBO
Proxmox	Lab, Edge
Hyper-V	Cluster, Workload Scale
KVM	Libvirt Cluster, OpenStack Compute
OpenShift Virtualization	Private Cloud, Edge

3. Complete The Deployment Wizard

Wizard step	What to enter	Operator checks
Intent	Site name, location, deployment model, cluster name	Names match the change record and site standard.

Hardware	Hardware provider, node serials, BMC IPs, roles	Every physical node is listed once and BMC IPs are correct.
Platform	Target hypervisor/platform and provider fields	Correct Azure/vSphere/AHV/Proxmox/Hyper-V/KVM/OpenShift target selected.
Network	Management, storage, VM VLANs, DNS, NTP	Network values match the approved design.
Review	Generated desired-state YAML	Read it carefully before saving.

Common deployment blocker

Wrong BMC IPs, wrong VLANs, missing DNS/NTP values, and placeholder cloud IDs are the most frequent causes of failed readiness checks.

4. Save And Validate

8. Click Save Deployment.
9. Run Validate.
10. Read the result inspector output.
11. Fix any validation errors before moving on.

Result	Action
Succeeded	Continue to Inventory.
Warning	Review with deployment lead; continue only if accepted.
Failed	Stop and correct the deployment data.

5. Run Inventory

12. Run Inventory from the selected site or deployment detail page.
13. Provide transient BMC credentials only if your process allows it; otherwise use configured secret references.
14. Confirm every expected node is reachable or record an approved exception.

Failure symptom	What to check
BMC unreachable	IP address, routing, firewall, BMC power state.
Authentication failed	Secret reference, username, password, account lockout.
TLS/certificate error	Lab TLS option or BMC certificate trust.

Missing hardware data	OEM Redfish capability and firmware behavior.
-----------------------	---

6. Run Preflight

15. Run Preflight after inventory.
16. Resolve all failed checks.
17. Review warnings with the deployment lead.
18. Proceed only when the deployment is ready or an exception is approved.

7. Generate Artifacts

19. Run Artifacts.
20. Open the Artifacts page or the deployment detail Artifacts tab.
21. Download the ZIP bundle.
22. Attach the bundle to the change record or implementation evidence pack.

Artifact type	Purpose
Site desired state	Authoritative deployment input.
Deployment plan	Human-readable execution sequence.
Preflight report	Readiness evidence.
Terraform/Bicep/Ansible outputs	Handoff material for platform execution.
ZIP bundle	Single package for change evidence.

8. Register Or Select ISO Media

23. Go to Artifacts > ISO Registry if boot media is required.
24. Register an approved remote ISO URL or use Browse to select from the approved ISO library.
25. Validate the ISO entry where possible.
26. Use only media approved for the target platform and hardware.

ISO location

The default local ISO library is `.strataone/iso-library` on the host, mounted in the API/worker containers as `/app/.strataone/iso-library`.

9. Request Approval For Protected Actions

27. Run the protected action, such as Mount ISO, Deploy Azure Local, or Node Replacement.
28. If StrataOne returns approval-required, open Approvals.
29. Ask the required approver role to review and approve.
30. After approval, rerun the action or use Approve and Run when available.

Protected action	Why approval may be required
mount-iso	Can change boot media or next boot behavior.
deploy-azure-local	Can perform platform deployment actions.
node-replacement	Can affect existing site capacity and lifecycle state.
live provider actions	Can modify hardware, firmware, cluster, or platform state.

10. Monitor Orchestration Runs

31. Go to Orchestration Runs.
32. Open the job detail.
33. Watch status, progress events, logs, and result output.
34. If a job fails, read the error before retrying.
35. Export or copy the job report after completion.

11. Day-2 User Workflows

Area	Use it for
Sites	Review managed sites, selected site state, topology, and inventory.
Providers	Review provider capability and validation status.
Artifacts	Inspect generated bundles, ISO registry, and downloads.
Approvals	Review pending actions and approval status.
Lifecycle	Run drift detection or node replacement workflows when authorized.
Releases/About	Confirm product version and release notes.

12. Quick Troubleshooting

Problem	User action
API offline	Refresh once, then contact admin if still offline.
Login fails	Check username/password and account status with admin.
Templates unavailable	Refresh; if still unavailable, ask admin to restart/rebuild API.
Validate fails	Correct site, hardware, platform, or network values.
Inventory fails	Check BMC details with hardware/admin team.
Approval required	Open Approvals or contact an authorized approver.
Job failed	Open job detail, read error, do not repeatedly rerun blindly.