

Writing the Nodka Disk Image

1. In the BIOS goto Advanced TAB --> CPU Configuration --> Intel (VMX) Virtualization - Set to Disable
2. Goto Boot TAB - Select Boot Option #1 (Debian (Sandisk Portable SSD 6004))
3. Press F4 (Yes)
4. After booting enter the Installer Login **Username:amazon Password:Amazon**
5. `sudo su <Enter>`
6. `pv < Debian12.7Nodka012.img > /dev/sda <Enter>`
7. `poweroff <Enter>`
8. Remove external drive when Nodka IPC has shutdown
9. Power on and enter BIOS again
10. Goto Boot TAB - Select Boot Option #1 (debian (P0:SATA SSD))
11. Press F4 (Yes)
12. After booting enter the **Passphrase : IndustrialComputerAmazon! <Enter>**
13. `sudo rm -vf /etc/ssh/ssh_host_* <Enter>`
14. Enter the user password
15. `sudo ssh-keygen -A <Enter>`
16. `sudo systemd-cryptenroll --wipe-slot=tpm2 /dev/sda3 <Enter>`
17. `sudo reboot <Enter>`
18. After booting enter the **Passphrase**
19. `sudo systemd-cryptenroll --wipe-slot=tpm2 --tpm2-device=auto --tpm2-pcrs=0+7 /dev/sda3 <Enter>`
20. Enter the user **Password**
21. Enter the **Passphrase**
22. `sudo nano /etc/hosts <Enter>`
23. Change line 2 “battcash” to new hostname set above
24. CTRL-X
25. Yes
26. `<Enter>`
27. `hostnamectl set-hostname battcash-0001 <Enter>` (see chart for required naming convention)
28. Enter the user **Password**
29. `newgrp <Enter>`
30. `sudo reboot <Enter>`
31. Enter BIOS again

32. Change BIOS Password to **Passphrase**
33. `sudo nano /etc/network/interfaces.d/enp1s0.conf`
34. Enter the user **Password**
35. Change the IP address according to the list

```
#auto enpls0
#iface enpls0 inet dhcp
auto enpls0
iface enpls0 inet static
    address 10.0.0.x/24
    network 10.0.0.0
    netmask 255.255.255.0
#    broadcast
#    gateway
```

36. CTRL-X
37. Yes
38. `<Enter>`
39. `sudo reboot <Enter>`
40. Activate Codesys licences according to the list