



PES
UNIVERSITY

ELEMENTS OF ELECTRICAL ENGINEERING

Course Code : UE25EE141A/B

FACULTY CONTRIBUTED:

Department of EEE, RR Campus

Prof . Jyothi T N

Prof. Vadhira^J K P P

Prof. Kruthika N

Prof. Suma S

Prof. Pushpa K R

Prof. Sangeeta Modi

Department of ECE, EC Campus

Prof. Lokesh L

Prof. Dhanashree G Bhate

Dr. Renuka R Kajur

Prof. Rajesh Chandrashekhar

Prof. Sangam Kumar G H

ELEMENTS OF ELECTRICAL ENGINEERING (UE25EE141A/B)




Concept of phase lag and phase lead, Concept of phasor and phasor diagram; Mathematical representation of a phasor.

Jyothi T.N

Department of Electrical & Electronics Engineering

Concept of Phase Lag and Phase Lead




$f_1(t)=A\sin(\omega t)$ represents a reference sine wave.

$f_2(t)=A\sin(\omega t - \frac{\pi}{4})$ lags reference sine wave by $\frac{\pi}{4}$ rad.

$f_3(t)=A\sin(\omega t + \frac{\pi}{4})$ leads reference sine wave by $\frac{\pi}{4}$ rad.

Also, $f_2(t)$ lags $f_3(t)$ by $\frac{\pi}{2}$ rad.

Concept of Phase Lag and Phase Lead




In general, sinusoidal function is represented as

$A \sin(\omega t + \phi)$ where ϕ represents the phase angle.

If ϕ is positive, it leads the reference sine wave and lags if ϕ is negative.


Let us consider a rotating crank of length E_m lying at 0° position at $t = 0$ and rotating anticlockwise at an angular speed of ' ω ' rad/s.




At general time 't', it would be at an angle $\theta = \omega t$
Its vertical projection defines a sinusoidal function.

ELEMENTS OF ELECTRICAL ENGINEERING

Concept of Phasor



(a) Crank



(b) Sinusoidal waveform

Thus the above rotating crank represents a sinusoidal function of the form $E_m \sin(\omega t)$

Similarly, a sinusoidal function of the form $E_m \sin(\omega t + \phi)$ can be represented by another rotating crank of same length ' E_m ' and rotating with same angular speed ' ω ' rad/s anticlockwise but lying at an angle ' ϕ ' at $t = 0$.

Thus, any sinusoidal function can be represented by a rotating crank and it is called '**Phasor representation**' of a sinusoidal function.

A **Phasor** is a rotating vector which effectively represents a sinusoidal function.

When a number of sinusoidal functions are to be represented as phasors, it is represented using a diagram called **phasor diagram**.


While drawing a phasor diagram, all phasors must be represented corresponding to same point in time. It is usually preferred to represent them at a time $t = 0$. Then, angular position of each sinusoidal function corresponds to its phase angle.

Note: Only sinusoidal functions of same frequency can be represented together as a phasor diagram.
Also, the length of the phasor is its RMS value.

Consider the following sinusoidal functions

- i) $f_1(t) = 100\sin(100\pi t)$
- ii) $f_2(t) = 200\sin(100\pi t + 60^\circ)$
- iii) $f_3(t) = 100\cos(100\pi t - 60^\circ)$

Let us represent them using a phasor diagram.



Note: Convert a cosine function to sine form before representing as a phasor.

For instance,

$$\begin{aligned}f_3(t) &= 100\cos(100\pi t - 60^\circ) \\&= 100\sin(100\pi t - 60^\circ + 90^\circ) \\&= 100\sin(100\pi t + 30^\circ)\end{aligned}$$

Mathematical Representation of a Phasor

A phasor is mathematically represented as

Phasor = Magnitude \angle Phase Angle

Where, magnitude is the RMS value.

For instance, Consider these sinusoidal functions

- i) $f_1(t) = 100\sin(100\pi t)$ ii) $f_2(t) = 200\sin(100\pi t + 60^\circ)$
- iii) $f_3(t) = 100\cos(100\pi t - 60^\circ)$

Let us represent them using phasor representation.


$$f_1(t) = 100\sin(100\pi t) \Rightarrow \bar{F}_1 = \frac{100}{\sqrt{2}} \angle 0^\circ$$

$$f_2(t) = 200\sin(100\pi t + 60^\circ) \Rightarrow \bar{F}_2 = \frac{200}{\sqrt{2}} \angle 60^\circ$$

$$f_3(t) = 100\cos(100\pi t - 60^\circ) = 100\sin(100\pi t + 30^\circ)$$

$$\Rightarrow \bar{F}_3 = \frac{100}{\sqrt{2}} \angle 30^\circ$$

'j' operator in phasor representation is analogous to 'i' operator in complex mathematics.



In rectangular form, $j = (0 + j1)$

In polar form, $j = 1\angle 90^\circ$

Conversion between the forms

Polar to Rectangular conversion :

Let us consider a polar number $r\angle\theta$

It can be converted to rectangular form $(A + jB)$ using

$$A = r\cos\theta ; B = r\sin\theta$$

Rectangular to Polar conversion :

Let us consider a rectangular number $(A + jB)$

It can be converted to polar form $r\angle\theta$ using

$$r = \sqrt{A^2 + B^2} ; \theta = \tan^{-1}\left(\frac{B}{A}\right)$$

θ will be positive if 'B' is positive and it is negative if 'B' is negative.

Addition & Subtraction of Phasors:

Addition & subtraction of phasors would be easier in rectangular form.

For instance, let $\bar{F}_1 = (A_1 + jB_1)$ & $\bar{F}_2 = (A_2 + jB_2)$

$$\bar{F}_1 + \bar{F}_2 = (A_1 + A_2) + j(B_1 + B_2)$$

$$\bar{F}_1 - \bar{F}_2 = (A_1 - A_2) + j(B_1 - B_2)$$

Multiplication & Division of Phasors:

Multiplication & Division of phasors would be easier in Polar form.

For instance, let $\bar{F}_1 = r_1 \angle \theta_1$ & $\bar{F}_2 = r_2 \angle \theta_2$

$$\bar{F}_1 * \bar{F}_2 = r_1 * r_2 \angle (\theta_1 + \theta_2)$$

$$\frac{\bar{F}_1}{\bar{F}_2} = \frac{r_1}{r_2} \angle (\theta_1 - \theta_2)$$

j operator properties

'j' operator when multiplied to a phasor, does not change the magnitude of the phasor but rotates the phasor anticlockwise by 90°

For instance, if $\bar{F} = 3\angle 60^\circ$, then $j\bar{F} = 1\angle 90^\circ * 3\angle 60^\circ = 3\angle 150^\circ$

$$j^2 = 1\angle 90^\circ * 1\angle 90^\circ = 1\angle 180^\circ = \cos(180^\circ) + j\sin(180^\circ) = -1$$

Similarly, $j^3 = j^2 * j = -j$

And $j^4 = j^2 * j^2 = 1$

Text Book:

1. "Basic Electrical Engineering" S.K Bhattacharya, 1st Edition Pearson India Education Services Pvt. Ltd., 2017
2. "Basic Electrical Engineering", D. C. Kulshreshtha, 2nd Edition, McGraw-Hill. 2019
3. "Special Electrical Machines" E G Janardanan, PHI Learning Pvt. Ltd., 2014

Reference Books:

1. "Engineering Circuit Analysis" William Hayt, Jack Kemmerly, Jamie Phillips and Steven Durbin, 10th Edition McGraw Hill, 2023
2. "Electrical and Electronic Technology" E. Hughes (Revised by J. Hiley, K. Brown & I.M Smith), 12th Edition, Pearson Education, 2016.



THANK YOU

Jyothi T.N

Department of Electrical & Electronics Engineering
jyothitn@pes.edu