



Microprocessor & Computer Architecture (μ pCA)

UE24CS251B

Session -
5A

Microprocessor & Computer Architecture (μpCA)



UE24CS251B

Additional Programs

Program 1 : Convert a given 2 digit hexadecimal number to ASCII CODE and store the result in the memory location X and X+1 using ARM7TDM – ISA.

; ARM7TDM – ISA code:

Example: $(54)_{10}$ to ASCII code :

1. Mask the LS byte.
2. 54 and 0xF0 gives 50.
3. shift 50 right by 4 times
4. 50 will be 05.
5. Now, 05 && 0x30
6. Results in 0x35.
7. Repeat the same for the LS byte.
8. Mask the MS byte.
9. 54 and 0x0F gives 04.
10. Now, 04 && 0x30
11. Results in 0x34.

.TEXT

LDR R3, =X

MOV R1, #0x54

AND R0, R1, #0xF0

MOV R0, R0, LSR #4

ORR R0, R0, #0x30

STR R0, [R3]

AND R2, R1, #0x0F

ORR R2, R2, #0x30

ADD R3, R3, #4

STR R2, [R3]

.DATA

X: .WORD 0, 0

Program - 2: Write a program using ARM/TDM - ISA to find the largest 32 bit element stored in an array A.

. DATA

A: . WORD 10, 20, 30, 40, 50

. TEXT

LDR R1, =A

LDR R0, [R1] ; Initially , set first element as the largest element
(stored in register R0).

MOV R3, #0 ; Count Register

LOOP: LDR R2, [R1, #4]! ; Load the next element

CMP R0, R2 ; compare

BLT Less ; if the previous element is less than next

element then store the largest element in register R0.

L1: ADD R3, R3, #1

CMP R3, #4

BNE LOOP

B EXIT

Less: MOV R0, R2

B L1

EXIT: SW 0X011

```
C statement: while( save[i] == k)
                                i +=1;
```

. TEXT

```
LDR R1, =K ; ADDRESS K
LDR R0, [R1] ; VALUE of K
LDR R2, =SAVE ; SAVE is the starting address of the array
MOV R3, #0 ; VALUE of I
```

```

LOOP:  ADD R5, R2, R3, LSL #2    ; R5 = SAVE+I * 4
        LDR R6, [R5, #0]        ; R6 = [R5]

```

```
CMP R0, R6
BNE EXIT ; REPEAT if save[I]==K
```

```
ADD R3, R3, #1
CMP R3, #5
BNE LOOP
```

EXIT: SW 0X011

. DATA

```
K: . WORD 5
I: . WORD 0
```

SAVE: . WORD 5, 5, 5, 50, 35, 40

Program – 4: Consider the following c code snippet. Write the compiled ARM assembly code. Use ARM7TDM – ISA.

```
int example( int g, int h, int  
i, int j)  
{ int f;  
  f = (g+h)-(i+j);  
  return f;  
}
```

```
.TEXT  
LDR R4, =F  
MOV R0, #5 ; G  
MOV R1, #10 ; H  
MOV R2, #1 ; I  
MOV R3, #4 ; J
```

```
BL example  
STR R0, [R4]
```

```
SW 0X011
```

example:

```
SUB R13, R13, #12  
STR R6, [R13,#8]  
STR R5, [R13,#4]  
STR R4, [R13,#0]
```

```
ADD R5, R0, R1 ; G+H  
ADD R6, R2, R3 ; I+j  
SUB R4, R5, R6 ;F= (G+H)-(I+J)
```

```
MOV R0, R4 ;RETURNS F THROUGH R0.
```

```
LDR R4,[R13,#0]  
LDR R5,[R13,#4]  
LDR R6,[R13,#8]
```

```
ADD R13, R13, #12  
MOV PC, LR
```

```
.DATA  
F: .WORD 0
```

Program – 5: Consider the following c code snippet. Write the compiled ARM assembly code. Use ARM/TDM – ISA ; Note: Pass parameters to function on stack.

```
int example( int g, int h, int
l, int j)
{ int f;
  f = (g+h)-(i+j);
  return f;
}. TEXT
LDR R4, =F
MOV R0, #5 ; G
MOV R1, #10 ; H
MOV R2, #1 ; I
MOV R3, #4 ; J
; PASS PARAMETRS TO STACK
SUB R13, R13, #16
STR R0, [ R13, #12]
STR R1, [ R13, #8]
STR R2, [ R13, #4]
STR R3, [ R13, #0]
BL example
STR R0, [ R4]
SW 0X011
```

example:

```
LDR R5, [ R13, #0] ; J
LDR R6, [ R13, #4] ; I
LDR R7, [ R13, #8] ; H
LDR R8, [ R13, #12] ; G

ADD R9, R7, R8 ; G+H
ADD R10, R5, R6 ; I+j
SUB R11, R9, R10 ; F= ( G+H) -
(I +J)

MOV R0, R11 ; RETURNS F
THROUGH R0.

ADD R13, R13, #16
MOV PC, LR

. DATA
F: .WORD 0
```

1. Which instruction is used to mask the higher nibble of a byte in ARM?
 - A) ORR
 - B) EOR
 - C) AND
 - D) BIC

2. Which instruction converts a 4-bit hex digit into ASCII in Program-1?
 - A) AND
 - B) ADD
 - C) ORR
 - D) EOR

1. Which instruction is used to mask the higher nibble of a byte in ARM?
 - A) ORR
 - B) EOR
 - C) AND**
 - D) BIC

2. Which instruction converts a 4-bit hex digit into ASCII in Program-1?
 - A) AND
 - B) ADD**
 - C) ORR
 - D) EOR

3. What is the purpose of the instruction MOV PC, LR at the end of the example function?

- A) To copy the Program Counter to the Link Register.
- B) To restart the function from the beginning.
- C) To return to the calling instruction by restoring the return address into the PC.
- D) To exit the program and trigger a software interrupt.

4. How many bytes does .WORD reserve?

- A) 1
- B) 2
- C) 4
- D) 8

3. What is the purpose of the instruction MOV PC, LR at the end of the example function?

A) To copy the Program Counter to the Link Register.

B) To restart the function from the beginning.

C) To return to the calling instruction by restoring the return address into the PC.

D) To exit the program and trigger a software interrupt.

4. How many bytes does .WORD reserve?

A) 1

B) 2

C) 4

D) 8

THANK YOU



Team MPCA

Department of Computer Science and
Engineering