BEFORE START	STARTUP	START ENG	CONTROLS	RUNUP	BEFORE T.O.	TAKEOFF	CRUISE	
SetBelts LOCKEI Breaks SE Cowl Flap OPEI Radios OFI	Mixture RICH Prop HighRPM Throttle CLOSED AuxPump ON Throttle 10GPH AuxPump OFF	IgnitionSTART ThrottleAdvance IgnitionRelease ThrottleIDLE Oil PresCheck	Inst SET Radios SET ALT SEL SET HDG/TRK RUNWAY Trim TAKE-OFF Mixture RICH	Throttle 1700 Mags CHECK Prop CYCLE Prop HighRPM	Doors LOCKED FricLock ADJUST Flaps 0° - 20° RadCall DEPART Taxi TAKE-OFF	PowerFULL MixtureRICH Rollup60MPH Climb90MPH FlapsRETRACT	23in-2300RPM  Autopilot ON Mixture 16g/hr TRIM asREQ Cowl Flap asREQ	

LET DOWN	10 MIN OUT	BEFORLAND	APPROACH	GO AROUND	NORM LAND	AFTER LAND	SECURING	
VS Button PRESS UP-DN DN as Req Power as DESIR Mixture FOR ALT Cowl Flap CLOSE	<pre><who calling="" your=""></who></pre>	MixtureRICH PropHIGH	AirSpeed 80MPH Flaps 40° VS Button PRESS UP-DN DN as Req	GA Button PRESS Power FULL Flaps 20' AirSpeed 90MPH ALT SEL SET Flaps 0' Cowl Flap OPEN	MAINS Landing Roll LOWER GENTLY	<pre><who calling="" your=""> 75PJ</who></pre>		