
# **Biosafety Cabinets**

Biosafety Cabinets (BSCs) are enclosed workspaces with a ventilated hood designed to contain pathogenic microorganisms during microbiological processes.

- The primary purpose of biosafety cabinets is to protect the laboratory personnel and the environment from the pathogenic microorganism as aerosols might be formed during the processing of such microorganisms.
- Biosafety cabinets are only used for certain risk group organisms and for processes that might result in aerosol formation.
- These cabinets have HEPA filters that decontaminate the air moving out of the cabinet.
- Biosafety cabinets might be confused with the laminar hood as these pieces of equipment work as enclosed workspaces. However, a laminar hood only protects the sample and not the personnel and the environment, whereas biosafety cabinets protect all three.
- The use of biosafety cabinets or other such physical containment is not required in the biosafety level 1, but depending on the risk assessment, some processes might require such containment.
- BSCs are essential to biosafety as they minimize aerosol formation, protecting the environment, the pathogen, and the laboratory personnel.
- Besides, most BSCs also function to sterilize biological materials that are kept inside the cabinets.
- Biosafety cabinets are classified into three classes by the U.S. Center for Disease Control and Prevention (CDC), each with specific performance characteristics and applications.
- Class I and II Biosafety cabinets are used for **Biosafety levels** I and II but, when used correctly in conjunction with useful microbiological techniques, these provide an effective containment system for safe manipulation of moderate and high-risk microorganisms.
- Class III BSCs are most suitable for work with hazardous agents that require Biosafety Level 3 or 4.






## **Biosafety Cabinet Class I**

Class I is the most basic biosafety cabinet that protects the environment and the laboratory personnel. It doesn't, however, protect the product as the unsterilized room air is drawn over the work surface. Class I biosafety cabinets are typically used to either enclose specific equipment like centrifuges or for procedures like aerating cultures that might potentially generate aerosols. Biosafety cabinets of this class are either ducted (connected to the building exhaust system) or unducted (recirculating filtered exhaust back into the laboratory). In the Class I BSC, the room air is drawn in through the opening that also allows the entry of the operator's arm during work. The air inside the cabinet then takes in the aerosol particles that may have been generated and moves it away from the operator towards the HEPA filter. The air moving out of the cabinet is thus, sterilized via the HEPA filters before its discharge to the environment. In this way, the cabinets protect the operator and the environment from the aerosol but not the sample.

### **Biosafety Cabinet Class II**

BSC-Class II cabinets provide both kinds of protection (of the samples and the environment) since makeup air is also HEPA-filtered. The principle of operation of Class II cabinets involves a fan mounted on the top of the cabinet that draws a curtain of sterile air over the workstation where the biological products are being handled. The air then moves underneath the workstation and back up to the top of the cabinet before passing through the HEPA filters. The exhaust that moves out of the

facility consists of air being drawn into the front of the cabinet underneath the work surface. The air drawn in acts as a barrier against the potentially contaminated air coming back out to the operator. Class II BSCs are further divided into five types depending on the exhaust system and the mechanism of work (recirculation of the exhaust air); Type A1, Type A2, Type B1, Type B2, and Type C1.



#### a. Type A1

- The type A1 cabinets have a minimum inflow velocity of 75ft/min where the contaminate is divided just above the workstation and mixed with the inflow air.
- The mixed air is then drawn through a duct network so that it reaches the back of the cabinet.
- After this, air might be either recirculated after passing through the HEPA filters or exhausted out of the cabinet, also through a HEPA filter.
- This type of cabinet is not as widely used as it is not safe to work with hazardous chemical substances.




Figure 1: CLASS II TYPE A1 BIOLOGICAL SAFETY CABINET

#### b. Type A2

- The type A2 cabinets have a minimum inflow velocity of 100 ft/min.
- In Class II, Type A2 BSC air enters the chamber through the front aperture, which provides operator protection.
- The inflow air mixes with the downflow air (from the top of the cabinet) and enters the front intake grille and then passes over the workstation where the air splits.
- Approximately 60% to 70% of the contaminated air is recycled and pushed back into the
  workstation in the chamber through the downflow HEPA filter, while the remaining 30%
  to 40% is exhausted through the exhaust HEPA filter.
- However, if hazardous, volatile chemicals are to be used within the cabinet, along with
  the microbiological work, exhaust must be released into the atmosphere through the
  direct duct system.
- Because of the chances of the release of hazardous chemicals into the environment, A2
   type cabinets are also not extensively used.





Figure: Class II Type A2 Biosafety Cabinet. Image Source: Biobase.

#### c. Type B1


- Type B cabinets are different from Type A cabinets as they use single-pass airflow to control the flow of hazardous vapors.
- Type B1 cabinets divide the airflow so that the contaminated air is directed towards the exhaust system while the air between the operator and the workstation mixes with the inflow and is recirculated.
- The exhaust air dispersed out of the facility should be passed through the HEPA filters to protect the environment.
- These cabinets have a dedicated duct system that allows the release of the contaminated air out of the facility.
- In the case of Type B1 cabinets, 40% of the air is recirculated, whereas the remaining 60% is exhausted out of the facility.



(A) front opening; (B) sash; (C) exhaust HEPA filter; (D) supply HEPA filter; (E) negative pressure dedicated exhaust plenum; (F) blower; (G) additional HEPA filter for supply air. Note: The cabinet exhaust needs to be direct-connected to the building exhaust system.

### d. Type B2

- For a Type B2 BSC, like in Type A cabinets, the air is drawn in from the front opening creating an air barrier that protects the operator.
- Air is also drawn in from an opening at the top of the cabinet that supplies the downflow of air in the cabinet.
- The air then passes through a HEPA filter, where 100% of the air is exhausted through a dedicated duct system with an exhaust fan motor. The air moving out of the facility is thus sterilized before its release into the atmosphere.



(A) front opening;(B) sash;(C) exhaust HEPA filter;(D) supply HEPA filter;(E) negative pressure exhaust plenum. Note: The cabinet needs to be direct-connected to the building exhaust system.


#### **Biosafety Cabinet Class II B2**

- The advantage of this system is the removal of toxic vapors that are generated in the cabinet with no recirculation within the BSC.
- All of the contaminated airflow (100%) in a Type B2 cabinet is externally exhausted which means the air drawn into the cabinet is 100% exhausted into the atmosphere.
- As a result, none of the air drawn into the B2 from either inflow or downflow is recycled within the airflow system.
- Because none of the air is recirculated, these cabinets are the best to be used for tasks involving the release of chemical vapors.
- Type B2 cabinets, however, are expensive, and their use is limited to toxicology laboratories where protection against hazardous chemicals is imperative.

#### e. Type C1

• Type C1 cabinets are similar to Type B cabinets in their working mechanism, but these are designed to reduce operating costs add flexibility to the laboratories.

- These cabinets work by using the single-pass airflow system where the cabinets move the air by mixing it with the downflow air separated into columns for recirculation.
- The air above the workstation is drawn with a second fan which moves the contaminated air out through the exhaust system with a HEPA filter.
- In this way, the cabinets provide protection to the environment, the operator, and the workstation or the biological material.
- Type C cabinets are different from Type A cabinets as they use a single-pass airflow mechanism where the air is not circulated.
- These differ from Type B cabinets in that they don't require a dedicated ducted exhaust system, can work for an extended duration to increase operator protection in the case of exhaust failure, and can even run without the exhaust at all.



(A) front opening; (B) sash; (C) exhaust HEPA filter; (D) supply filter; (E) supply blower; (F) exhaust blower.

#### **Biosafety Cabinet Class III**

- Class III cabinets are leak-tight, totally enclosed but ventilated cabinets, where all air that either enters or leaves through the facility pass through a HEPA filter.
- The cabinets are provided with rubber gloves that are attached to the system to be used during operations in the cabinet. This is why these cabinets are also termed 'glove boxes'.

- The cabinet even has a transfer chamber that facilitates the sterilization of materials before they leave the glove box.
- Even though the gloves restrict the hand movement of the operator inside the cabinet, it prevents direct contact between the operator and the samples.
- The exhaust air is treated with double HEPA filters or HEPA filters in combination with incineration.
- These cabinets can be used for all four Biosafety levels (1, 2, 3, and 4). But these are the most important for the manipulation of biological materials in the Biosafety level 4.
- These cabinets are mostly custom-built for specific laboratories with lab equipment built inside the chamber.
- All of these structural and design features provide maximum protection to the operator, the environment, and the sample against the high-risk group 4 pathogenic organisms

# Laminar flow hood vs Biosafety cabinet

Aspect	Laminar Flow Hood	Biosafety Cabinet
Airflow Direction	Horizontal, unidirectional flow of clean air	Vertical, top-to-bottom flow of clean air
Applications	Sterile and dust-free workspace	Working with biological agents and hazardous materials
Protection Level	Provides protection against particulates	Provides protection against biological and chemical hazards
Common Uses	Tissue culture, sterile material preparation	Microbiology, virology, healthcare, hazardous material handling

- Laminar Flow Hood: For applications demanding the utmost cleanliness and particle control, the Laminar Flow Hood shines. Air flows steadily in one direction, providing a pristine environment for critical tasks such as cell culture and microelectronics assembly. It's a choice for maintaining productorsample purity.
- Biosafety Cabinet: When working with hazardous materials or biological agents, the Biosafety Cabinet takes center stage. It ensures the protection of both the operator and the environment. With three classes (I, II, and III) to choose from, you can match the cabinet to your specific containment requirements.

#### **Biosafety Cabinet Class III**

- Class III cabinets are leak-tight, totally enclosed but ventilated cabinets, where all air that either enters or leaves through the facility pass through a HEPA filter.
- The cabinets are provided with rubber gloves that are attached to the system to be used during operations in the cabinet. This is why these cabinets are also termed 'glove boxes'.
- The cabinet even has a transfer chamber that facilitates the sterilization of materials before they leave the glove box.
- Even though the gloves restrict the hand movement of the operator inside the cabinet, it prevent direct contact between the operator and the samples.
- The exhaust air is treated with double HEPA filters or HEPA filters in combination with incineration.
- These cabinets can be used for all four Biosafety levels (1, 2, 3, and 4). But these are the most important for the manipulation of biological materials in the Biosafety level 4.
- These cabinets are mostly custom-built for specific laboratories with lab equipment built inside the chamber.
- All of these structural and design features provide maximum protection to the operator, the environment, and the sample against the high-risk group 4 pathogenic organisms.



