

Asus X541UV-BH71-CB Battery Replacement

This guide will show the steps required to replace the battery of your Asus X541UV-BH71-CB.

Written By: Vivek Rana



INTRODUCTION

A battery is required to run and use laptops. Unfortunately, the battery of the Asus X541UV-BH71-CB laptop is poor compared to other laptops. The battery will quickly drain after going through excessive charging cycles. If the laptop battery is draining significantly quicker than normal or not charging, then the battery should be replaced. Before you begin the process of removing the battery, power off the laptop and disconnect the laptop from any external power source.



TOOLS:

- Phillips #00 Screwdriver (1)
- Prying and Opening Tool Assortment (1)

Step 1 — Battery



 Flip the laptop upside down so the back of the laptop faces you.

Step 2







 Use a Phillips #00 screwdriver to remove the ten 1.2 mm Phillips #00 screws attached to the back of the laptop.

Step 3







- Turn the laptop upright, then open the laptop so the screen faces you.
- Use a prying tool between the keyboard and bottom grooves to partially remove the laptop backing.
- Do not completely remove the laptop backing because there are ribbon cables connecting the two
 halves.
- It is recommended to use a plastic prying tool rather than a metal prying tool because it could potentially scratch or damage the laptop.

Step 4







- Flip the retaining flaps on both keyboard ribbon cable <u>ZIF</u> sockets, then carefully pull the ribbon cables out of their sockets.
- Carefully remove the keyboard panel from the base and set it aside.

Step 5








Remove the two 1.2 mm Phillips #00 screws holding the battery in place using the Phillips #00 screwdriver.

Step 6







Carefully remove the battery using a plastic opening tool.

To reassemble your device, follow these instructions in reverse order.