ESP32 Spa copilot firmware

Features

- MQTT command for following...
    - Operate Jet1.
    - Operate Jet2.
    - Operate Jet3.
    - Operate Jet 4.
    - Operate Light1.
    - Operate Blower1.
    - Retrieve current device status.
    - Reset Wi-Fi station credentials.
    - OTA firmware update.
    - Get/Set temperature limit.
    - Retrieve current temperature.
    - Get/Set heat mode.
    - Get/Set temperature range.
    - Get information about filter cycle.
    - Get/Set temperature scale.
    - Get current firmware version.
    - Set clock mode [Time format; 24H or 12H].
    - Set time (acceptable format: 24H).
    - Get setup info.
- Send error codes to the remote server using REST API.
    - API URL can be changed via MQTT.

MQTT messages

- Bootup message:
    - Sent on every bootup.
    - Contains current firmware version and mac id of the esp32 device.
- Setup Info message:
    - Sent on every bootup.
    - Contain Setup Info [Information about the connected devices like jet, blower etc.].