

### The list of V-BOX models


Signatur
----------

Series	Model	Description		
	V - BOX S -00	1 Ethernet port ,2 serial ,support WiFi		
	V - BOX S -4G	1 Ethernet port ,2 serial ,support WiFi ,4G		
C Corios	V - BOX S -AG	1 Ethernet port ,2 serial,support WiFi ,4G(global)		
S Series	V - BOX S -3N	3 Ethernet port ,1 serial ,support WiFi		
	V - BOX S -NG	3 Ethernet port ,1 serial ,support WiFi ,4G		
E Corios	V - BOX E -00	1 Ethernet port, 1 serial ,		
E Series	V - BOX E -4G	1 Ethernet port, 1 serial ,support 4G		
	V DOVII 00	3 Ethernet port ,1 serial,2 RS485 terminals,		
V - BOX H -00		2 input with optocoupler isolation ,2 relay output		
	V BOYLLWE	3 Ethernet port ,1 serial,2 RS485 terminals,WIFI ,		
	V - BOX H -WF	2 input with optocoupler isolation ,2 relay output		
	V - BOX H -4G	3 Ethernet port ,1 serial,2 RS485 terminals,4G ,		
		2 input with optocoupler isolation ,2 relay output		
H Series	V - BOX H -AG	3 Ethernet port ,1 serial,2 RS485 terminals,4G(global) ,		
		2 input with optocoupler isolation ,2 relay output		
	V - BOX H -SG	3 Ethernet port ,1 serial,2 RS485 terminals,4G,		
	V - BOX II -3G	2 input with optocoupler isolation ,2 relay output , GPS		










H-00 / H-WF / H-4G / H-AG Components description


1	LED	2	Micro-USB	3	Ethernet	4	COM
5	Power terminal	6	4G/WIFI antenna (optional)	7	Fixed buckle	8	SIM card slot (optional)
9	I/O port	10	RS 485 terminals				



• RS422

9♦ (female	e)	8針	(male)
1 TX+ -		2	RX+
6 TX		<del></del> 1	RX-
		-	TX+
			TX-
5 GND <b>-</b>		3	SG
0 (54321)	0		

• RS485



#### Navigation

- > 1 Manual
- > 2 Download
- √3 Demo
  - .
- Communication
- 2 Script
- > PLC Protocol
- Video



## 1 Communication

Last modified by Hunter on 2024/07/01 10:54

### **WECON**

#### **LX3V Serial**

Supported series: Wecon LX2V/ LX2E/ LX3V/LX3VP/LX3VE/LX3VM

#### 1) V-BOX setting

Item	Settings	Note
Protocol	WECON LX2V/ LX2E/ LX3V/LX3VP/LX3VE/LX3VM	
Connection	RS422/RS485	
Baud rate	9600	
Data bit	7	
Parity	EVEN	
Stop bit	1	
PLC station No.	1	



#### address list

Туре	Data Type	Function code and description			
		04 (Read Input Registers: Read the current binary value in one or more input registers)			
	3	06 (write single register: write a binary value to a holding register)			
		10 (write values to multiple addresses )			
		03 (read holding register: read current binary value in one or more holding registers)			
	4	06 (write single register: write a binary value to a holding register)			
Word		10 (write values to multiple addresses )			
		03 (read holding register: read current binary value in one or more holding registers)			
	W6	06 (write single register: write a binary value to a holding register)			
		10 (write values to multiple addresses )			
	W16	03 (read holding register: read current binary value in one or more holding registers)			
		10 (write values to multiple addresses )			





#### 2) Address List

) ngnaturi
V

Туре	Device registers	HMI registers	Format	Range	Note
	X	x	Xo	0~303237	
	Υ	Υ	Yo	0~303237	
Bit	М	М	M d	0~99999	
DIL	Т	Т	Td	0~99999	
	С	С	Cd	0~99999	
	S	S	Sd	0~99999	
	Х	х	Xo	0~303237	
	Υ	Υ	Yo	0~303237	
	М	М	M d	0~99999	
Mond	Т	Т	Td	0~99999	
Word	С	С	Cd	0~199	
	D	D	D d	0~7999	
	S	S	Sd	0~99999	
	SD	SD	SD d	8000~9999	







Register Type	Register Address	Register Contents	Bytes
Input Pagister	0x0001	Temperature	2
Input Register	0x0002	Humidity	2
	0x0101	Device Address	2
Keep Register	0x0102	Baud Rate: 0:9600 1:14400 2:19200	2
3	0x0103	Temperature Correction -10°C~10°C	2
	0x0104	Humidity Correction -10%RH~10%RH	2



# **PLC**

X0,M0 = ปุ่ม Start Y0 = เครื่องจักรที่ 1

X1,M2 = ปุ่ม Stop Y2 = เครื่องจักรที่ 2

X3 = ปุ่ม Emergency Stop Y3 = เครื่องจักรที่ 3

D10, D11 = Data Register Y4 = เครื่องจักรที่ 3

\*เมื่อกด Start ให้ทำการจำลองการทำงานเครื่องจักร ดังนี้

# เมื่อความชื้น น้อยกว่า 70%RH

Step ที่ 1 เครื่องจักรที่ 1 เปิด D10 วินาที ปิด D10 วินาที

Step ที่ 2 เครื่องจักรที่ 2 เปิด D11 วินาที ปิด D11 วินาที

Step ที่ 3 เครื่องจักรที่ 3 เปิด D10 วินาที ปิด D11 วินาที

เครื่องจักรที่ 4 ทำงานตรงกันข้ามกับเครื่องจักรที่ 3

# <u>เมื่อความชื้นมากกว่าหรือเท่ากับ 70%RH</u>

เครื่องจักรที่ 1,2 ปิด เครื่องจักรที่ 3,4 เปิด

เมื่อกด Stop เครื่องจักรที่ 1-4 หยุด ทำงานต่อเมื่อกด Start

เมื่อกด Emergency Stop เครื่องจักรหยุด และ เริ่มใหม่\*

## HMI

ตั้งค่าและแสดงค่า D10, D11
แสดงค่าสถานะเครื่องจักรที่ 1-4
สามารถกด Start, Stop ได้
แสดงกราฟ ความชื้น และ อุณหภูมิ
แสดงสถานะความชื้นน้อยกว่า 70%RH

# **V-Box IIoT Gateway**

อ่านค่า ความชื้น อุณหภูมิ จาก Com2 (V.Box)

สร้าง Cloud Scada (asean.v-box.net)

ตั้งค่าและแสดงค่า D10, D11

แสดงค่าสถานะเครื่องจักรที่ 1-4

สามารถกด Start, Stop ได้

แสดงกราฟ ความชื้น และ อุณหภูมิ

แสดงสถานะความชื้นน้อยกว่า 70%RH

Signature