
012-09200A

Instruction Manual and Experiment Guide for the PASCO scientific Model OS-8533A

POLARIZATION ANALYZER



© 2005 PASCO scientific





Table of Contents

Section	Page
Copyright, Warranty, and Equipment Return	ii
Description	1
Mounting a Rotary Motion Sensor	1
Using the Rotary Motion Sensor	3
Mounting a Light Sensor	3
Setup for Measuring Light Intensity	4
Verify Malus' Law of Polarization	5



Copyright, Warranty, and Equipment Return

Please—Feel free to duplicate this manual subject to the copyright restrictions below.

Copyright Notice

The PASCO scientific 012-09200 Model OS-8533A Polarization Analyzer is copyrighted and all rights reserved. However, permission is granted to non-profit educational institutions for reproduction of any part of the manual providing the reproductions are used only for their laboratories and are not sold for profit. Reproduction under any other circumstances, without the written consent of PASCO scientific, is prohibited.

Limited Warranty

PASCO scientific warrants the product to be free from defects in materials and workmanship for a period of one year from the date of shipment to the customer. PASCO will repair or replace at its option any part of the product which is deemed to be defective in material or workmanship. The warranty does not cover damage to the product caused by abuse or improper use. Determination of whether a product failure is the result of a manufacturing defect or improper use by the customer shall be made solely by PASCO scientific. Responsibility for the return of equipment for warranty repair belongs to the customer. Equipment must be properly packed to prevent damage and shipped postage or freight prepaid. (Damage caused by improper packing of the equipment for return shipment will not be covered by the warranty.) Shipping costs for returning the equipment after repair will be paid by PASCO scientific.

Equipment Return

Should the product have to be returned to PASCO scientific for any reason, notify PASCO scientific by letter, phone, or fax BEFORE returning the product. Upon notification, the return authorization and shipping instructions will be promptly issued.

Credits

This manual authored by: Dave Griffith

Equipment Return

Should the product have to be returned to PASCO scientific for any reason, notify PASCO scientific by letter, phone, or fax BEFORE returning the product. Upon notification, the return authorization and shipping instructions will be promptly issued.

➤ NOTE: NO EQUIPMENT WILL BE ACCEPTED FOR RETURN WITHOUT AN AUTHORIZATION FROM PASCO.

When returning equipment for repair, the units must be packed properly. Carriers will not accept responsibility for damage caused by improper packing. To be certain the unit will not be damaged in shipment, observe the following rules:

- ① The packing carton must be strong enough for the item shipped.
- ② Make certain there are at least two inches of packing material between any point on the apparatus and the inside walls of the carton.
- ③ Make certain that the packing material cannot shift in the box or become compressed, allowing the instrument come in contact with the packing carton.

Address: PASCO scientific

10101 Foothills Blvd. Roseville, CA 95747-7100

Phone: (916) 786-3800 FAX: (916) 786-3292

email: techsupp@pasco.com web: www.pasco.com



Introduction

The PASCO OS-8533A Polarization Analyzer is designed to be mounted on the Optics Bench of the OS-8515 Basic Optics System and to be used with the Basic Optics Light Source (part of the OS-8515 Basic Optics System) and a Light Sensor such as the PASCO CI-6504A, or PS-2106 to explore polarization. When used with the PASCO CI-6538 or PS-2120 Rotary Motion Sensor, you can measure the relationship between the light intensity transmitted through a set of polarizers and the angle of the polarizers.

Recommended Equipment

Basic Optics System (OS-8515) Rotary Motion Sensor (CI-6538, or PS-2120) Light Sensor (CI-6504A or PS-2106)

Description

The Polarization Analyzer consists of a Polarizer Holder, an Accessory Holder with Mounting Bracket, two Polarizers, a Retarder and an Aperature Bracket. The mounting bracket is permanently attached to the Accessory Holder. The mounting bracket holds a Rotary Motion Sensor in position to measure the angle of one Polarizer as it turns relative to the other Polarizer. The mounting bracket includes two thumbscrews and a plastic belt. The thumbscrews attach the Rotary Motion Sensor to the bracket. The plastic belt is used with a Rotary Motion Sensor.

The Polarizers and Retarder snap into the opening at the top of the Accessory Holder or the Polarizer Holder. The Retarder is a one-quarter wavelength (140 nanometer) retarder. Each Polarizer has an angular scale near its outside edge marked in ten degree increments with additional marks at 45, 135, 225, and 315 degrees.


One of the Polarizers has a groove on its front edge. Use this Polarizer with the *Accessory* Holder. When the Rotary Motion Sensor is mounted on the Accessory Holder bracket, you can put the plastic belt over the groove on the front of the Polarizer and a groove on the three-step pulley on the Rotary Motion Sensor. This allows you to measure the angular position of the Polarizer as it turns.


Mounting a Rotary Motion Sensor

Prepare the Rotary Motion Sensor

You will need a Phillips head screwdriver with a small tip (e.g., #1).

The Rotary Motion Sensor comes with a rod clamp








attached to one end. Use a Phillips head screwdriver to loosen the two screws that hold the rod clamp. Remove the rod clamp and screws. (Please put the rod clamp and screws in a safe place for future use.)

The Rotary Motion Sensor also comes with a rubber "O" ring in the largest groove of the three-step pulley that is attached to the sensor's shaft. Remove the "O" ring from the three-step pulley and put the ring in a safe place for future use. The sensor is now ready to mount on the Accessory Holder bracket.

Prepare the Mounting Bracket



The bracket comes with two thumbscrews stored in threaded holes on the side of the bracket. Remove the

two thumbscrews and set them aside for now.

The bracket also holds the plastic belt. The belt is wrapped twice around two semi-circular notches on the top and bottom edges of the bracket. Unwrap the belt from the notches and set it aside for now.


Attach the Rotary Motion Sensor

Turn the Rotary Motion Sensor so the three-step pulley faces the Accessory Holder and the threaded holes in the end of the

sensor line up with the holes of the Mounting Bracket. Use the two thumbscrews to attach the Rotary Motion Sensor to the Mounting Bracket.

Put on the Plastic Belt


Loop the bottom of the plastic belt around the three-step





pulley of the
Rotary Motion
Sensor so the bottom
of the belt is in the
large-diameter
groove of the steppulley.

Attach the Polarizer

Get the Polarizer that has the groove on its front edge. Slip the top of the plastic belt into the groove on the front edge of the Polarizer. Snap the Polarizer into place on the Accessory Holder.










Using the Rotary Motion Sensor

Mount the Accessory Holder on the Optics Bench


The Accessory Holder snaps into the Optics Bench. To move the Accessory Holder along the bench, grasp the base of the holder and squeeze the locking clip inward. Continue to squeeze inward on the locking clip as you move the holder to a new position. When you release the locking clip, the Accessory Holder is held

firmly in place.



Rotate the Polarizer

Rotate the Polarizer by grasping the edge of the Polarizer. As you turn the Polarizer, the plastic belt will turn the threestep pulley on the Rotary Motion



Sensor by the same amount. When the Rotary Motion Sensor is connected to *ScienceWorkshop* or PASPORT interface, you can measure the angular position of the Polarizer to within one-quarter degree.

Aperature Bracket

The Aperture Bracket has two main components: the Light Sensor Mount and the Aperture Bracket Holder.

Light Sensor Mount

The Light Sensor Mount has an Aperture Bracket Screen, an Aperture Disk, a large thumbscrew, and a threaded post. You can use either the large thumbscrew or the threaded post to attach a Light Sensor to the Light Sensor Mount in one of two positions. Use the threaded post if you want to hold the Light Sensor Mount in a rod clamp. The large thumbscrew or the post is stored in the threaded storage hole on the Light Sensor Mount when not in use.




Figure 10: Holder on Bench

Aperture Bracket Holder

Two metal thumbscrews attach the Aperture Bracket Holder to the back of the Light Sensor Mount. The Aperture Bracket Holder snaps into place anywhere along the center section of the Optics Bench that is part of the OS-8515 Basic Optics System. To move the holder along the bench, grasp the base of the holder and squeeze the locking clip inward. Continue to squeeze inward on the locking clip as you move the holder to the new position. When you release the locking clip, the holder is held firmly in place.



Aperture Bracket Screen

The Aperture Bracket Screen is designed to help you align the Aperture Disk with a light source. Two small thumbscrews attach the Aperture Bracket Screen to the front of the Light Sensor Mount.

Aperture Disk

The Aperture Disk has three circular apertures and six slit apertures (numbered one through six). The slit widths are as follows:

1 = 0.1 mm	2 = 0.2 mm
3 = 0.3 mm	4 = 0.5 mm
5 = 1.0 mm	6 = 1.5 mm




Figure 11: Aperture Disk

Using the Aperature Bracket

Mounting a Light Sensor


You can use the Aperture Bracket to mount a Light Sensor on the Optics Bench. You can use the Light Sensor to measure the intensity of light through the Polarizers as you rotate one Polarizer relative to the other.

Use either the large thumbscrew or the post to mount a Light Sensor to the Light Sensor Mount. Position the Light Sensor on top of the Light Sensor Mount so the hole in the bottom of the sensor is in line with the *front* hole in the mount and the opening of the Light Sensor touches the vertical part of the Light Sensor Mount.

One circular aperture is 8 mm in diameter, the same dimension as the opening of the PASCO Model CI-6504A, CI-6604, or PS-2106 Light Sensor. A second circular aperture has the same diameter but has a grid pattern of small holes (0.25 mm diameter) that allows 10% transmission of light through the aperture. The third circular aperture is 2 mm in diameter, or one-fourth the diameter of the larger circular apertures, and translucent.

The Aperture Disk can be rotated to any of the nine

The Aperture Disk can be rotated to any of the nine positions to put one of the slits or circular apertures in line with a Light Sensor mounted behind the Aperture Disk.








Figure 13: Light Sensor onto Mount

Put the threaded end of the thumbscrew or post through the hole and turn the thumbscrew or post clockwise to tighten. See Figure 12 & 13.

Snap the Aperture Bracket Holder into the Optics Bench.Rotate the Aperture Disk so the open circular aperture is in line with the opening to the Light Sensor.



Setup for Measuring Light Intensity

You can use the Basic Optics Bench, Basic Optics Light Source, Polarization Analyzer, Rotary Motion Sensor, Aperture Bracket, and a Light Sensor to measure the light intensity through the Polarizers as one Polarizer is rotated relative to the other.

Prepare the Polarizer

Put the second Polarizer in the empty Polarizer Mount that comes with the Polarization Analyzer.

Mount the Light Source

Put the Basic Optics Light Source at one end of the Basic Optics Bench. Refer to the OS-8515 instructions. Turn the Light Source so it produces a "point source" of light that is aimed toward the other end of the bench.

Mount the Polarization Analyzer

Snap the Polarizer Mount onto the Optics Bench. Snap the Polarization Analyzer with Rotary Motion
Sensor onto the Optics Bench.

Mount the Light Sensor

Snap the Aperture Bracket Holder with the Light Sensor onto the Optics Bench with the Light Sensor opening toward the Light Source




Figure 14: Prepare Polarizer




Figure 15: Setup for Measuring Light Intensity



Notes:



Verify Malus' Law of Polarization

EQUIPMENT NEEDED

- Basic Optics Bench (part of OS-8515) Light Sensor (CI-6504A or PS-2106)
- Basic Optics Light Source (part of OS-8515) Rotary Motion Sensor (CI-6538 or PS-2120)
- Polarization Analyzer with Aperture Bracket (OS-8533A)

Introduction

The purpose of this laboratory activity is to determine the relationship between the intensity of the transmitted light through two polarizers and the angle, \emptyset , of the axes of the two polarizers.


Theory

 $I = I_0 \cos^2 \phi$

A polarizer only allows light which is vibrating in a particular plane to pass through it. This plane forms the "axis" of polarization. Unpolarized light vibrates in all planes perpendicular to the direction of propagation. If unpolarized light is incident upon an "ideal" polarizer, only half will be transmitted through the polarizer. Since in reality no polarizer is "ideal", less than half the light will be transmitted.

The transmitted light is polarized in one plane. If this polarized light is incident upon a second polarizer, the axis of which is oriented such that it is perpendicular to the plane of polarization of the incident light, no light will be transmitted through the second polarizer.

However, if the second polarizer is oriented at an angle so that it is not perpendicular to the first polarizer, there will be some component of the electric field of the polarized light that lies in the same direction as the axis of the second polarizer,



thus some light will be transmitted through the second polarizer (see the bottom figure).

The component, E, of the polarized electric field, E_o , is found by:

$$E = E_0 \cos \phi$$

Since the intensity of the light varies as the square of the electric field, the light intensity transmitted through the second filter is given by:

where I_o is the intensity of the light passing through the first filter and \emptyset is the angle between the polarization axes of the two filters.



Consider the two extreme cases illustrated by this equation:

• If \emptyset is zero, the second polarizer is aligned with the first polarizer, and the value of $\cos^2 \emptyset$ is one. Thus the intensity transmitted by the second filter is equal to the light intensity that passes through the first filter. This case will allow maximum intensity to pass through.

- If Ø is 90°, the second polarizer is oriented perpendicular to the plane of polarization of the first filter, and the cos²(90°) gives zero. Thus no light is transmitted through the second filter. This case will allow minimum intensity to pass through.
- These results assume that the only absorption of light is due to polarizer effects. In fact most polarizing films are not clear and thus there is also some absorption of light due to the coloring of the Polaroid filters.


Procedure

In this activity, the Light Sensor measures the relative intensity of light that passes through two polarizers. You will change the angle of the second polarizer relative to the first. The Rotary Motion Sensor measures the angle.

The DataStudio records and displays the light intensity and the angle between the axes of the polarizers. You can use the program's built-in calculator to compare the relative intensity to the *angle*, the *cosine of the angle*, and the *cosine*² of the angle.

Equipment Setup

- 1. Mount the Basic Optics
 Light Source, Polarizer
 Holder, Polarizer Analyzer
 with Rotary Motion Sensor,
 and Aperture Bracket
 Holder with Light Sensor as
 shown. (Refer to the Introduction for more information.)
- Connect the Light Sensor and Rotary Motion Sensor to the computer through a ScienceWorkshop or PASport interface (or interfaces), and start DataStudio.





Experiment Setup

Select the Sensors and Set the Sample Rate

• Refer to DataStudio on-line help for detailed information on selecting sensors and changing the sample rate.

- 1. Set up the Rotary Motion Sensor for high resolution (for example, 1440 Divisions per Rotation). Select *Large Pulley (Groove)* for the linear calibration (if you are using a PASport Sensor, this step is unecessary).
- 2. Set the sample rate of both sensors to 20 Hz, or 20 measurements per second.

Select the Display

- Refer to DataStudio on-line help for detailed information selecting and changing displays.
- 1. Select a Graph display.
- 2. Set the axes of the Graph display so *light intensity* is on the *vertical* axis and *angular position* is on the *horizontal* axis.

Prepare to Record Data

- Refer to DataStudio on-line help for detailed information on *monitoring* and *recording* data.
- 1. Turn both Polarizers so they are at the same beginning angle (e.g., zero degrees).
- 2. Start monitoring data.
- 3. Rotate one Polarizer back and forth until the transmitted light intensity is *maximum*.
- 4. Stop monitoring data.

Record Data

- 1. Start recording data.
- 2. Slowly rotate the Polarizer on the Polarization Analyzer in the clockwise direction. Continue to rotate the Polarizer until you have made one complete rotation (360 degrees).
- 3. After one complete rotation, stop recording data.

Analyze the Data

- Refer to the on-line help for DataStudio detailed information on creating and displaying calculations and using DataStudio for data analysis.
- 1. Use the Experiment Calculator in DataStudio software to create a calculation of the *cosine* of the angle between the Polarizers.
- 2. Repeat the procedure to create a calculation of the *cosine*² of the angle of the Polarizers.
- 3. Use the Graph display to examine the plot of light intensity versus angle.
- 4. Change the Graph display to show the plot of light intensity versus the cosine of the angle, and then change the Graph display to show the plot of light intensity versus the cosine² of the angle.
- 5. Use Data Studio software to determine the relationship between the light intensity and the cosine² of the angle.



Questions

- 1. What is the shape of the plot of light intensity versus angle?
- 2. What is the shape of the plot of light intensity versus cosine of the angle?
- 3. What is the shape of the plot of light intensity versus cosine² of the angle?
- 4. Theoretically, what percentage of incident plane polarized light would be transmitted through three Polarizers which have their axes rotated 17 degrees (0.29 radians) from each other? Assume ideal polarizers and assume that the second polarizer's axis is rotated 17 degrees (0.29 radians) from the first and that the third polarizer's axis is rotated 17 degrees (0.29 radians) from the second.
- 5. From your data, determine the answer to Question #4 for the real polarizers.

