


RWY 01



WARNING


1. After climbing to (600) immediately contact Vnukovo-Radar on frequency 126.000 MHz.
2. All ACFT shall follow the noise abatement procedures at all times as in accordance with ICAO DOC 8168.
3. Initially cleared height of climb after take-off for all SID routes is (900).
4. Minimum climb gradient is 5.8 % up to (150).
5. IAS MAX 460km/h up to FL100.

CHANGE: LO 01D

STANDARD DEPARTURE CHART
INSTRUMENT (SID) - ICAO

TRANSITION
HEIGHT : (1200)

MOSCOW, RUSSIA
VNUKOVO
RWY 01



VNUKOVO TOWER
RADAR
MOSCOW APPROACH

118.300
126.000
See AD 2.1 UUWW-55


BEARINGS AND TRACKS ARE MAGNETIC
ALTITUDES, HEIGHTS AND ELEVATIONS ARE IN METRES
DISTANCES ARE IN KILOMETRES

WARNING:
1. After climbing to (600) immediately contact Vnukovo-Radar on frequency 126.000 MHz.
2. All ACFT shall follow the noise abatement procedures at all times as in accordance with ICAO DOC 8168.
3. Initially cleared height of climb after take-off for all SID routes is (900).
4. Minimum climb gradient is 5.8% up to (150).
5. IAS MAX 460km/h up to FL100.

STANDARD DEPARTURE CHART
INSTRUMENT (SID) - ICAO

TRANSITION
HEIGHT : (1200)

MOSCOW, RUSSIA
VNUKOVO
RWY 19



VNUKOVO TOWER
RADAR
MOSCOW APPROACH

118.300
126.000
See AD 2.1 UUWW-55

BEARINGS AND TRACKS ARE MAGNETIC
ALTITUDES, HEIGHTS AND ELEVATIONS ARE IN METRES
DISTANCES ARE IN KILOMETRES

WARNING:

1. After climbing to (600) immediately contact Vnukovo-Radar on frequency 126.000 MHz.

2. All ACFT shall follow the noise abatement procedures at all times as in accordance with ICAO DOC 8168.


3. Initially cleared height of climb after take-off for all SID routes is (900).

4. IAS MAX 460km/h up to FL100.

Federal Air Transport Agency

AIRAC AMDT 12/18

RWY 06




AIRAC AMDT 12/17


STANDARD DEPARTURE CHART
INSTRUMENT (SID) - ICAO

TRANSITION
HEIGHT : (1200)

MOSCOW, RUSSIA
VNUKOVO
RWY 06



RWY 06




AIRAC AMDT 04/18

CHANGE: BRG

STANDARD DEPARTURE CHART
INSTRUMENT (SID) - ICAO

TRANSITION
HEIGHT : (1200)

MOSCOW, RUSSIA
VNUKOVO
RWY 24



VNUKOVO TOWER 118.300
RADAR 126.000
MOSCOW APPROACH See AD 2.1 UUUW-55

BEARINGS AND TRACKS ARE MAGNETIC
ALTITUDES, HEIGHTS AND ELEVATIONS ARE IN METRES
DISTANCES ARE IN KILOMETRES

- WARNING:**
1. After climbing to (600) immediately contact Vnukovo-Radar on frequency 126.000 MHz.
 2. All ACFT shall follow the noise abatement procedures at all times as in accordance with ICAO DOC 8168.
 3. Initially cleared height of climb after take-off for all SID routes is (900).
 4. IAS MAX 460km/h up to FL100.