


STANDARD ARRIVAL CHART INSTRUMENT (STAR) - ICAO



MOSCOW, RUSSIA **VNUKOVO**



VNUKOVO ARRIVAL MOSCOW APPROACH

CHANGE: New chart

123.400

127.200 128.000 134.000 131.200 134.675

TRANSITION LEVEL:

- FL110 when QNH is 1013 hPa (760mm mercury column) or above;
- FL120 when QNH is 977 hPa (733mm mercury column) or above, but less than 1013 hPa (760mm mercury column);
- FL130 when QNH is less than 977 hPa (733mm mercury column).

BEARINGS AND TRACKS ARE MAGNETIC ALTITUDES AND ELEVATIONS IN FEET DISTANCES IN KILOMETRES

Alt set: -QNH(QFE on reg); -hPa(mm on reg).