

doesn't press the button.

OFF

Battery Life

Check the current battery life of VC 110's GizmoPal 2



Contacts

Edit VC 110's contact list.



Turn Off VC 110's Gizmo

Note: You can't turn it back on using the app. The only way to turn the GizmoPal 2 on is to press the Play button on the gizmo for 4 seconds.



About Gizmo

View information about VC 110's GizmoPal 2













Cousin (this is you)



Dad

To 'edit' a contact or Caregiver tap the contact name.


To 'Add' a NEW contact or Caregiver select the '+' sign














Tap on Box to Allow Caregiver
Permission













Contacts

Edit Contact

Enter Contact's Phone Number

(XXX) XXX-XXXX



Enter Contact's Name (Optional)

Contact OR Caregiver's Name

Select what VC 110 calls this contact

Dad



Caregiver - Allow this contact to use the GizmoHub app for locating VC 110's gizmo.

CANCEL



Caregiver Permission Allowed







