

POST LAB

```
ws = 2000;  
w1 = 100;  
w2 = 300;  
order = 32;  
wn = [w1 w2] / (ws / 2);  
[b, a] = butter(order/2, wn, 'bandpass');  
[H, w] = freqz(b, a);  
subplot(2,1,1);  
plot(w/pi, 20*log10(abs(H)));  
title('Band-pass Butterworth Filter');  
xlabel('Magnitude');  
subplot(2,1,2);  
plot(w/pi, angle(H));  
xlabel('Phase');
```

