```
CanAdaptor
      - funcsmap
      handler_vcrhandler_rcshandler_rci
      handler_ds
      handler_vdrhandler_mtf
      - isBigEndian
      ptr_can_dump_ptr_can_send_
      - psotmsg tm
      + CanAdaptor()
      + ~CanAdaptor()
      + Initialize()
      + Release()
      + Open()
      + RunControlFlag()
                                        -instance
      + IsConnected()
      + CheckSocketStatus()
      + StopPostMessage()
      + SetHandler()
      and 7 more..
      + getInstance()
      - Send()
      - Receive()
      CanOpen()
      - PrintMapState()
      - MakeFramebody()
      PostMessageByType()
      PostMessageByType()PostMessageByType()
      PostMessageByType()
      PostMessageByType()
      PostMessageByType()

    PostMessageByType()

      SOpen()
      - ROpen()
                    -canlib_
            DataRelayer
 faultCallback
- rpmCallback
 system_endian
- magMap
- channelMap
+ DataRelayer()
+ ~DataRelayer()
+ ControlSteering()
+ ControlVel()
+ ControlHardware()
+ StopPostMessage()
+ HeartBeat()
+ RegistRpmCallback()
+ RegistFaultCallback()
+ RegistRpmCallback()
+ RegistFaultCallback()
+ Run()
+ SendTest()
SetmsgMap()
 SendMessageControlSteering()
SendMessageControlAccelerate()
- SendMessageControlHardware()
- Handler_\
_Request()
           VCU_EPS_Control
 Handler_Remote_Control
 Shake()
- Handler_Remote_Control_IO()
- Handler_DBS_Status()
- Handler_VCU_DBS_Request()
- Handler_MCU_Torque
_Feedback()
 ConvertSpeedUnits()
is_big_endian()
```