






Step I

Choose your version Step 2

Choose your cam plates



<i>;</i>	
CAM PLATES	04 PR0
Side plate freestyle M3 2.5mm (x1)	Side plate 25°_04 PR0 2.5mm (x1)
pocket depth 12mm	pocket depth 12mm
pocket depth 12mm	pocket depth 12mm
depth 1.2mm Side plate cinématique M3 2.5mm (x1)	depth 1.2 mm Side plate 25°_04 PR0_soft 2.5mm (x1)
pocket depth 12mm hole hole hole hole hole hole	pocket depth 12mm pocket depth 10mm pocket depth 10mm pocket depth 11mm
pocket : depth 1.2mm	2 pockets: depth 1 & 1.2 mm
Side plate freestyle M2 2.5mm (x1))
pocket depth 12mm pocket depth 12mm pocket: depth 1.2mm	
Side plate cinématique M2 2.5mm (x1)	
hole hole hole hole hole hole hole hole	
pocket : depth 1.2mm	

*chamfers are recommanded everywhere except on camera plates

Line type	
cut ————————————————————————————————————	