telnet 157.237.14.60 -f logfile.txt

-> bist

===== EMX BIST menu ======

0: BSP test

7: TX channels

1: TX36 test

8: RX noise level

2: RX32 test

9: RX noise spectrum

3: Power Supply

10: CPU Test

4: TX Power test

15: Software date/version

5: Nibble bus test

20: SingleChannels

6: RX channels

-1: Quit

Detailed reports:

30: TX channels slot 1 - 5

35: RX noise level graphical view

31: TX channels slot 6 - 10

36: RX noise spectrum graphical view

32: TX channels slot 11 - 15

33: TX channels slot 16 - 20

34: TX channels slot 21 - 24

40: Junction box lab test slot 0 - 5 (fast)

41: Junction box lab test slot 0 - 5 (slow)

50: Preamp amplitude test R1

51: Preamp phase test R1

52: Preamp amplitude test R2-R8

53: Preamp phase test R2-R8

Select test:

Em122-118

Sys #

515 4.3.2

Release

PV 1.2

BSP

イン

Created for EMIZZ rel 2.1.1\_Mar 2016

Version 4.3.2

Build 31 DBVersion 30.0

CD generated 2016-Feb 24