If the file, [L1IFStream.xml] doesn't work: Make a new template from scratch. These are the steps to follow: 1) Run FT PROG.exe 2) File->"New Template" 3) Click on "Chip Details" 4) Type: Pulldown to "FT2232H" 5) Click + in front of "Hardware Specific" 6) Click + in front of "Port A" 7) Click on "Hardware" 8) Select radio button after "245 FIFO" 9) Click on "Driver" 10) Leave radio button in default position, "Virtual COM Port" 11) Click on + in front of "Port B" 12) Click on "Hardware" 13) Select radio button after "OPTO Isolate" 14) Click on "Driver" 15) Select radio button value for "D2XX Direct" 16) File->"Save As Template" 17) Give the template a name and save it. 18) Devices->"Scan and Parse"

25) Right click on "Device: 0[LocID:0x111]"->"Close Device"
26) Use Ports in Device Manager to determine COM port number

27) Open TerraTerm in Serial mode, select the COM port number 28) The window should look like the image below