## Creating a low power consumption Print Server

Sub-titled:
An update on Raspberry Pi's
and
What is AArch64, A64, arm64, ARMv8-A, Cortex-A53 & A72?

Waikato Linux Users Group Ian Stewart 2019-xx-xx

### Print Server - Considerations

- Raspberry Pi / ARM chip has low power consumption
- R-Pi with 64 bit instruction set. AArch64 or A64.
- Linux OS compiled for A64. Ubuntu Server 18.04.3
- Print Server utilities.
- Common Unix Printing System (CUPS)
- Special Drivers
- Remote Management
- Multi-core CPUs
- 4 x USB Ports for printers
- Headless
- Private LAN

# Raspberry Pi's - Multi-core 64/32 bit ARMv8-A

Rpi Version	Model	Broadcom	Cores	Clock
2	B V1.2	BCM2837	4 x Cortex A53	900MHz
3	В	BCM2837	4 x Cortex A53	1.2GHz
3	B+	BCM2837-B0	4 x Cortex A53	1.4GHz
4	В	BCM2711	4 x Cortex-A72	1.5GHz

# Raspberry Pi's AArch64 - AMDv8-A

R-Pi 3B+








Pi Compute Module - 3+




## R-Pi 4B Overview – New Features



# Raspberry Pi – Operating Systems

https://www.raspberrypi.org/downloads/



## Ubuntu Mate – Download options

#### Raspberry Pi (recommended)



Download Size

For aarch32 (ARMv7) computers, like:

- Raspberry Pi Model B 2
- Raspberry Pi Model B 3
- Raspberry Pi Model B 3+



#### Raspberry Pi (experimental)

For aarch64 (ARMv8) computers, like:

- Raspberry Pi Model B 3
- Raspberry Pi Model B 3+

#### Which release would you like?

for a Raspberry Pi ARMv7 32-bit system

#### Which release would you like?

for a Raspberry Pi ARMv8 64-bit system



Supported until April 2021

beta1


▲ ubuntu-mate-18.04.2-beta1-desktop-armhf+raspi-ext4.img.xz

▲ ubuntu-mate-18.04.2-beta1-desktop-arm64+raspi3-ext4.img.xz


1.2 GB Download Size 1.2 GB

## Download Ubuntu Server 18.04.3 arm64

### Installation instructions



# Archive Manager - extracts the .img file



Install to SD-Card using dd...


```
$ sudo dd bs=32M if=ubuntu-18.04.3-preinstalled-server-arm64+raspi3.img
of=/dev/sdb status=progress conv=fsync
75+1 records in
75+1 records out
2521340928 bytes (2.5 GB, 2.3 GiB) copied, 298.925 s, 8.4 MB/s
```

## Boot R-Pi – Start Tailoring

- Insert SD-Card into R-Pi
- Boot R-Pi
- Login to ubuntu account, password: ubuntu
- Forced to change password.
- Plug into ethernet and get dhcp server address.
- \$ sudo apt update
- \$ sudo apt dist-upgrade # <-- 58 Packages
- •\$ reboot
  - Optional: Implement networking policy.
- Change Hostname.
- Modem providing fixed IP.

## Create print-server

- •\$ sudo apt install tasksel
- •\$ sudo tasksel
- From Tasksel Menu, note "Cloud Image" installed.
- Select installation of "Print Server" applications (122 files).



```
[ ] Xubuntu live CD
[*] Ubuntu Cloud Image (instance)
[ ] DNS server
[ ] Kubuntu desktop
[ ] Kubuntu full
[ ] LAMP server
[ ] Mail server
[ ] PostgreSQL database
[*] Print server
[ ] Samba file server
```

## Create print-server

Does the printer need special drivers?

• \$ apt-cache search printer-driver

### Returns:

all, brlaser, c2050, c2esp, cjet, cups, dymo, escpr, foo2zjs, foo2zjs, fujixerox, gutenprint, hpcups, hpijs, indexbraille, locale, m2300w, min12xxw, oki, OpenPrinting, pnm2ppa, postscript, ptouch, pxljr, sag, splix

### **Example:**

•\$ sudo apt install printer-driver-brlaser

## SSH into "ubuntu" account on print server

• In this case the print-server was dhcp served 10.1.1.9

```
2018 Q1
$ ssh ubuntu@10.1.1.9
ubuntu@10.1.1.9's password:
Welcome to Ubuntu 18.04.3 LTS (GNU/Linux 4.15.0-1041-raspi2 aarch64)
                                                            ARM
                   https://help.ubuntu.com
 * Documentation:
                                                         Architecture
                   https://landscape.canonical.com
 * Management:
                                                             64
                   https://ubuntu.com/advantage
 * Support:
                                                           amd64
                                                          ARMv8-A
  System information as of Tue Sep 17 00:47:59 UTC 2019
  System load:
                2.5
                                   Processes:
                                                        133
  Usage of /:
                5.5% of 28.21GB
                                  Users logged in:
                                   IP address for eth0: 10.1.1.9
  Memory usage:
                27%
  Swap usage:
                0%
```

DHCP served IP address

## Set CUPS for remote administration

 ubuntu@ubuntu:~\$ sudo cupsctl --remote-admin --remoteany -share-printers

Add "ubuntu" account to the lpadmin group

• ubuntu@ubuntu:~\$ sudo usermod -a -G lpadmin ubuntu

## Check CUPS status

```
ubuntu@ubuntu:~$ sudo service cups restart ubuntu@ubuntu:~$ sudo service cups status
```


```
• cups.service - CUPS Scheduler
   Loaded: loaded (/lib/systemd/system/cups.service; enabled; vendor
preset: enabled)
   Active: active (running) since Tue 2019-09-17 01:20:34 UTC; 2s ago
     Docs: man:cupsd(8)
 Main PID: 6530 (cupsd)
    Tasks: 3 (limit: 1056)
   CGroup: /system.slice/cups.service

-6530 /usr/sbin/cupsd -l


-6533 /usr/lib/cups/notifier/dbus dbus://
```

Sep 17 01:19:21 ubuntu systemd[1]: Started CUPS Scheduler.


### **CUPS** Remote Administration




## **CUPS** - Authorisation




## CUPS – Add Printer



## CUPS – Select USB connection to Printer



### CUPS – Add Shared Printer



# CUPS – Using brlaser driver

CUPS.org Home

Administration

Classes

Help

Jobs

Printers

#### Add Printer

Name: Brother\_DCP-7065DN

**Description: Brother DCP-7065DN** 

Location:

Connection: usb://Brother/DCP-7065DN?serial=E69895C1N312327

**Sharing:** Share This Printer

Make: Brother Select Another Make/Manufacturer

Model: Brother DCP-7065DN, using brlaser v4 (en)

Brother DCP-1200 - CUPS+Gutenprint v5.2.13 (en)

Brother DCP-1200 Foomatic/hl1250 (recommended) (en)

Brother DCP-1200 Foomatic/ljet2p (en)

Brother DCP-1510 series, using brlaser v4 (en)

Brother DCP-7010 Foomatic/hl1250 (recommended) (en)

Brother DCP-7010 Foomatic/lj4dith (en) Brother DCP-7010 Foomatic/ljet4 (en) Brother DCP-7010 Foomatic/ljet4d (en)

Brother DCP-7020 Foomatic/hl1250 (recommended) (en)

Or Provide a PPD File:

Browse...

No file selected.

Add Printer

# CUPS – Changing Printer Setup


CUPS.org Home Administration Classes Help Jobs Printers


### **Set Printer Options**

#### Set Default Options for Brother\_DCP-7065DN

General Banners Policies

#### General






## CUPS – Print Test Page

CUPS.org Home Administration Classes Help Jobs Printers

#### Brother\_DCP-7065DN

#### Brother\_DCP-7065DN (Idle, Accepting Jobs, Shared)





### CUPS – Status

CUPS.org Administration Classes Home Help Jobs Printers Brother\_DCP-7065DN (Idle, Accepting Jobs, Shared) Maintenance Administration **Description:** Brother DCP-7065DN Location: **Driver:** Brother DCP-7065DN, using brlaser v4 (grayscale, 2-sided printing) Connection: usb://Brother/DCP-7065DN?serial=E69895C1N312327 **Defaults:** job-sheets=none, none media=iso a4 210x297mm sides=two-sided-long-edge Jobs Search in Brother DCP-7065DN: Search Clear Show Active Jobs Show All Jobs Jobs listed in descending order. ID Name User Size Pages State Control Brother DCP-7065DN-1 2 Unknown Withheld 1k completed at Reprint Job Tue Sep 17 01:44:29 2019


## Computers on the Network

- Click on System -> Administration -> Printers
- The print servers printer will now appear with the printservers Hostname in its name.
- Proceed to print to this print server printer.





## Computers on the Network



# Questions / Discussion