硬體安全設計與操作...

POF SECURITY
AN EMEMORY COMPANY


硬體安全設計 與操作。

- 1. Root-of-Trust (Recap)
- 2. HRoT Definition
- 3. Secure Primitives
- 4. Cryptos, Protocol and Certificate
- 5. Secure Boot

硬體安全設計 與操作。


Hardware Root-of-Trust: Recap

RoT for Internal and External Trusted Basis.




Root-of-Trust is the root of information. It should be trusted and free from doubt.

External Security: Secure Communication.



Security fundamentals: 1. trusted keys 2. certificate for authentication 3. digest for integrity check 4. cryptography for protecting the transmission

(SoC) Internal Security: Secure Boot.



HRoT provides **Secure Storage**, **HUK** and **Cryptos** for: 1. As anchor of chain of trust, 2. RSA/ECC and SHA for digest and verification 3. FW protection using AES with local PUF key

(SoC) Information that A RoT Should Protect.

	For External Security	For Internal Security
Keys	 UID Root Key (HUK) Private/Public Key Shared Key CA Public key (Digest) Global FW Key 	 Root Key (HUK) Private/Public Key FW Public Key Local KEK/Local FW Key
Certificate	Service Certificate (X.509) FW Signature (Secure Boot) Key Certificate (X.509)	
Secure Info.	Chip Lock/Unlock PWD	Versioning/Debugging

Can't be stolen (Must Important): HUK(Private Key), KEK (Local Key) and FW Key Can't be revised (For Secure Boot, Authentication): CA Public key and Certificate.

→ HRoT is needed to robustly protect these secret keys and information than RoT

硬體安全設計 與操作。

HRoT Definition

(Basic) Hardware Root of Trust.



Design Consists of

OTP

Entropy: PUF

Entropy: TRNG

Ant-tampering

Aim for

Key Generation

Key Storage

Secure Operation

(Standard) Hardware Root of Trust.



Design Consists of

OTP

Entropy: PUF

Entropy: TRNG

Cryptos

Ant-tampering

Aim for


Key Generation

Secure Storage

Secure Operation


Secure Environment

Vulnerability for a Convention SoC -



page 11 PUFsecurity


S1: Convention Secure SoC



- 最常見的系統安全設計架構
- 離散的密碼學硬體加速器提供加密運算
- 需要安全處理器以及各單元的抗攻擊設計

page 12 PUFsecurity

S2: Secure Subsystem using Secure CPU




降低被攻擊的缺口,隔離金鑰跟一般非安全資訊

- 設計獨立區塊,保護金鑰及重要系統資訊,並永久隔離在安全邊界內
- 主CPU/記憶體不能碰觸金鑰,金鑰外存都需要做KWP加密保護。
- 主動的安全隔離區, 擁有OTP存儲、專用的工作記憶體和硬體加速單元。

page 13 PUFsecurity

S3: Secure Subsystem using FSM ...




降低被攻擊的缺口,隔離金鑰跟一般非安全資訊

- 保護金鑰以及重要系統資訊於一層純硬體的安全邊界內。
- 使用FSM (Finite State Machine) · 不使用CPU · 更難被攻擊。
- · 被動的安全隔離區,如果有高階的安全應用(如付費),需要額外CPU運算。

page 14 PUFsecurity

S4: Secure Subsystem using Secure CPU+ •



在S2 的基礎之下,增加高階安全應用的使用場景。

- 完整執行安全應用、保護金鑰、憑證以及重要系統資訊,並被隔離在安全邊界內
- 主動的安全隔離區, 擁有安全的NVM存儲、專用的工作記憶體和硬體加速單元
- 因為需要執行安全應用程式,需要增加ROM、大容量Flash、所以需要更強力的 CPU/OS/FW,以及相對應的 SoC I/F,複雜度大幅度提高。

page 15 PUFsecurity

Comparison among HRoT .

Solution	S1	S2	S3	S4
Secure IP	Discrete Cryptos	RT-120 (Rambus) eSecure (Secure IC) tRoot Vx (Synopsys)	CC312/CC712(ARM) PUFcc3	RT-650 (Rambus) tRoot Fx (Synopsys) RISC-V+/PUFcc3
2 nd CPU/HW		Secure CPU ROM/RAM/(Flash)		Secure CPU+ ROM/RAM/Flash
Pros	• Flexible cryptos	Flexible cryptosActive HRoT	Cost EffectiveFixed cryptosHighest Security	Trusted Secure ApplicationsAsset Protection
Cons • Secure CPU • Key Protection • Secure CPU is MUST • ROM and Flash are MUST for Booting		Function limitation using FSM	Complexity as a SoC Secure CPU+, ROM and Flash are MUST	

Ch-2.

Secure Primitives in a HRoT

Components of the Hardware Root of Trust.

	What	How
硬體信任根	金鑰(儲存)熵源	用於金鑰存儲的 NVM (OTP)靜態熵 (HUK)動態熵 (TRNG)
硬體信任根(廣義)	• 可信任操作 • 可信任環境	 防篡改 Anti-Tampering 安全飛地 Secure Enclave 金鑰管理 Key Management 密碼學 Cryptography 可信固件 Trusted FW/API 可信作業系統 Trusted OS


Entropy: Static Entropy a.k.a. PUF.


Paired Device with one-time uncertain mechanism Ex: SRAM-PUF, RO-PUF NeoPUF

Static Entropy

Post-Processing /Conditioning

Static
Random Numbers
(min.Entropy=1)





Entropy Accumulation

HW Adjustment

Health Check

Root Key/HUK

UID

Entropy: Dynamic Source to TRNG.

Device with time-dependence uncertain mechanism


Dynamic Entropy

Post-Processing /Conditioning

Non-deterministic Random Numbers (min.Entropy=1)

Ex: ROSC, PLL, noises...





0, 0, 1, 1....

0, 1, 1, 1....

HW Adjustment


Entropy

Accumulation

Health Check


Nonce

Session Keys



Entropy: TRNG Design.


NIST SP800-90B Diagram



90B Requirement	How?	
① Analog Noise Source	Noise source from PLL/ROSC(Jitter) or ADC	
② Digitization	Noise to Raw Entropy	
1 2 Noise Source Analysis	Entropy Model	
③ Conditioning	Non-linear Compression (ex: SHA)	
④ Health Test	Noise source health check	
⑤ Output Data Q.C.	Passed NIST800-22; 90B Restart Tests Passed AIS31 Tests	


The design of either static or dynamic entropy is based on a combination of analog design (noise source) and digital design (function/algorithm).

Key Management: Generation and Access.



- UID, TRNG, and Provisioned Key Storage
- Secure Certified OTP with Tamper-Proof
- Static Entropy Protects OTP
- PUF and HW cryptos Protect Keys
- Access Authority Control for Keys
- Complete Key/Data Lock or Revocation
- Entropy Revocation


Key Management: Key Wrapping.



- Only encrypted key stored in normal world
- KWP uses KEK from PUF or HUK seed

KWP: Key Wrapping Function; KEK: Key Encryption Key; KDF: Key Derivation Function


Key Management: Key Derivation Function.



- KDF in PUFiot follows standard NIST SP800-56C
- Derived keys are stored in MMU (memory management unit) for further use or as KEK to wrap the key for storing outside the PUF-realm

KDK: Key Derived Key; KEK: Key Encryption Key

Secure Storage: Conventional Storage.



Invasive/Semi-invasive attacks

- SEM, FIB, TEM on bit-cells
- Passive voltage contrast by SEM on bit-cells
- Locate address, delayer and nano probing

Non-invasive attacks

- Side channel attacks by CPA/DPA
- Unauthorized access
- Fault injection on visible pins
- Fault injection on secure registers
- Photon emission inspection (InGaAs/EMMI)

Secure Storage: Threats and Countermeasures.


Threat Model	Against Design (Green/Blue for hard macro/digital)	
SEM, FIB, TEM, optical inspection (OBIC/OBIRCH)	Need to apply secure device design	
Passive voltage contrast	Need to apply special layout	
Locate address, delayer and nano probing	Top metal shielding, security-oriented IP layout, inter-metal routing	
optical inspection (OBIC/OBIRCH)	Encryption, post-masking, random dummy read	
Power analysis on SA during read	Active SA protection during reading	
Fault injection on IO or mode select	Output Data Fault Detection, Pin Protection	
Rollback, replay attack and software access	Assess Permission Design and Post-Masking	
Secure setting or reserved bit leakage/revise	Secure repair and test-mode protection by lock	
Key location, photon emission, fault injection, glitch	Random dummy insertion READ	
Power analysis on CP or maliciously cut power	Unified operating power and power floating detection	
Dhoton emission inspection	Active SA protection during reading	
Photon emission inspection	Address/IO scrambler, post-masking, random dummy read	

硬體安全設計 與操作。


Symmetric and Hashing Cryptos for Secure Operations

→ Block Cipher, Digest and Authentication

Cryptographic Algorithms.




Symmetric Cryptography.




Algorithms: AES · ChaCha20 · 3DES · DES · RC5 · RC6 · SM4

Use Cases: Secure data storage. Real-time data encryption/decryption

Example for using Symmetric Cryptography.




Hash Function.



Algorithms: MD5 \ SHA-1 \ SHA-2 \ SHA-3 \ SM3


Use Cases: Check data integrity (ex. downloading)

Symmetric Authentication (HMAC).



- Nonce is required to prevent replay attack.
- The same procedure is needed if the client needs to verify the shared key of Host

Symmetric Authentication (CMAC).



- Nonce is required to prevent replay attack.
- The same procedure is needed if the client needs to verify the shared key of Host

Wrap-up: Symmetric Authentication.


Pros: Easy and Fast Authentication

Consideration:

- How to inject secret key in Host and Client?
- 2. How to protect secret key in Host and Client?
- Only suitable for one-to-one bundles, not for one-to-many use scenarios.

(Host needs to record too much information)

Symmetric Secure Communication .




- ① The host provides nonce for host/client to generate session share key
- ② Client uses AES with temporary share key to encrypt the plaintext into cipher

硬體安全設計 與操作。

Asymmetric Cryptos for Secure Operations

→ PKC, Authentication and Certificate


Asymmetric Cryptography.



Algorithms: RSA / ECC / SM2


Use Cases: Data authentication. Secure email exchange (PGP email encryption)

Public Key Concerns.




Alice wants to use Bob's public key to send data to Bob, but what if Bob's public key is fake? → Bob's public key need to be **authenticated** by 3rd party (CA)


Certificate with Signed Public Key.



Certificate with X.509 Format.




Asymmetric Authentication – Phase I.



- ① The host requests a certificate (ID/public key/signature) from the client.
- ② Host uses ECDSA on the signature with the CA public key and then gets the digest
- 3 Host uses HMAC to get another digest of the ID/public key/message
- 4 Compare the two digests to verify the validity of the public key

Asymmetric Authentication – Phase II.



- ① The client uses its private key to sign the nonce from the host's TRNG
- ② The host uses the client's public key to decrypt the signed nonce from the client
- 3 Compare the initial nonce with the decrypted nonce, if OK, the private key is verified.

Asymmetric Authentication: MFP and Cartridge.





https://news.tvbs.com.tw/life/328610

Wrap-up: Asymmetric Authentication.


Pros:

- 1. Complete Authentication with proved certificate
- 2. Fulfill one-to-one bundle and one-to-many bundle scenarios.

Consideration:

- 1. How to protect private pair in Client? Secure room and HRoT is needed for private key protection
- 2. RSA or ECC takes time for authentication

Asymmetric Secure Communication .




- ① Public key exchange for share key generation using ECDH algorithm
- ② Client uses AES with session ECDH key to encrypt the plaintext into cipher

硬體安全設計 與操作。


Secure Boot

Internal Security: Secure Boot.




- RSA/ECC and SHA for FW digest and verification → Anti-FW hacking
- FW protection using AES with local PUF key → Anti-counterfeiting


Chain of Trust in a SoC (Key Generation).



Common Plain FW Deployment Flow.




Device Pairing Secure FW Deployment.



- Secure FW deployment using global key management
- Paired FW and SoC using local key during assembly and booting-up

Reference.



https://www.twblogs.net/a/5b7d9a052b71773f4f1812fd