

USER'S MANUAL

Safety labels

Document number:
90840_02_ENG

Marel Stork Poultry Processing B.V.
Boxmeer, The Netherlands

Marel Stork Poultry Processing Inc.
Gainesville, USA

Marel Townsend Further Processing B.V.
Boxmeer, The Netherlands

Marel Townsend Further Processing Inc.
Des Moines, USA

Marel Meat Processing B.V.
Oss, The Netherlands

Marel Meat Processing Inc.
Des Moines, USA

TABLE OF CONTENTS

1	PREFACE	3
1.1	Reading indicator	3
1.2	Know the safety Labels	4
2	APPLICATION OF SAFETY LABELS	5
3	ORDERING SAFETY LABELS	7

This user's manual is a translation of the original user's manual.

Copyright © Marel Stork Poultry Processing B.V.

All rights reserved.

All technical and technological information contained in this User's Manual as well as any drawings and technical specifications made available by us shall remain our property and shall not be utilised (other than for the operation of the equipment), reproduced, transmitted, or disseminated to any unauthorised person, in any form or by any means, without our prior written permission.

1 PREFACE

1.1 Reading indicator

The User's Manual uses the term "machine". By "machine" is meant: the specific module, installation, unit or system with the corresponding equipment.

This User's Manual contains several boxes. They draw your attention to dangerous situations for the user, machine and/or product and give you tips. They are subdivided and displayed as follows:



DANGER OF LIFE

The user's life is instantly threatened.



WARNING

The user can be (seriously) injured or seriously damage the machine.

The safety label in this box depends on the risk-bearing action that is discussed.



CAREFUL

The user can damage the machine or products when the instructions are not carried out with care.



NOTE

Observation containing additional information for the user.



TIP

Provides suggestions and advice to the user to carry out certain instructions more skilfully and easier.

Page and document numbers

Each page has a unique identification and consists of:

- the page number with the total number of pages.
Example:
4 / 24
- the document number and the date of issue.
Example:
93738_00_NLD / 17-08-2013



Danger of personal injury caused by sharp objects



Danger of personal injury caused by rotating parts



Danger of personal injury caused by seizure



Danger of personal injury caused by electrical power



Danger of personal injury caused by high temperatures



Danger of hearing impairments through noise pollution



Approaching danger zone



Danger of personal injury caused by inhaling dangerous gases



Danger of personal injury caused by radiation



Danger of personal health caused by radiation



Attention for unexpected hazards



Special safety label for laser product



Forbidden to step on

1.2 Know the safety Labels

The machines of Stork/Townsend are complete with means for safety and protection. It is imperative that caution be exercised when performing machine operations.

The adjacent safety labels alert the user to possible dangers. You will find them on the machine and in the User's Manual explaining the risk-bearing operations.



WARNING

Check at regular intervals that all safety labels are present and legible in the relevant positions on the machine. If any safety labels have been lost or damaged, apply new safety labels; see chapter 2 APPLICATION OF SAFETY LABELS.

2 APPLICATION OF SAFETY LABELS

If safety labels have become unrecognizable through damage or if safety labels have been lost, apply new safety labels onto the machine in the correct places. See the User's Manual of the machine for the correct places of the safety labels.

Apply the new safety labels as follows:

1. Clean the spot to which the safety label is to be applied; see fig. 1. Use a clean cloth which does not give off any fluff and a non-aggressive detergent or degreasant, such as methanol.



fig. 1 Cleaning the surface



NOTE

Aggressive detergents affect the layer of glue of the safety label.

2. Heat the cleaned surface to a temperature of 40°C; see fig. 2.




fig. 2 Heating the surface

3. Pull the endpaper off the safety label; see fig. 3.




fig. 3 Endpaper removal




fig. 4 Adhesion of safety label




fig. 5 Applying pressure to safety label

4. Stick the safety label onto the cleaned area; see fig. 4.

5. Apply pressure to the safety label with a spatula or roller, so that it is level with the machine surface, without any bubbles; see fig. 5.
6. Leave the safety label to dry for 48 hours.



NOTE

Do not use any water or detergent on the safety label during the first 48 hours after it has been applied to the machine.

3 ORDERING SAFETY LABELS

Safety labels can be ordered from Stork/Townsend by indicating the quantity required and the order number.




fig. 6 Dimensions of the safety labels



type A



type B



type C



type D



type E



type F



type G



type H



type I



type J



type K



type L



type M

tab. 1 Order numbers of safety labels

Type	Dimension h [mm], see fig. 6	Order no.
A	35	40.0002.384
	50	00.1070.001
	100	00.1070.002
B	35	40.0002.382
	50	00.1070.004
	100	00.1070.005
C	35	40.0002.383
	50	00.1070.007
	100	00.1070.008
D	35	40.0002.385
	50	00.1070.013
	100	00.1070.014
E	50	40.0002.146
	100	00.1070.017
F	100	00.1070.020
G	50	40.0001.161
	100	00.1070.011
	150	00.1070.012
H	150	00.1070.025
I	50	40.0002.386
	100	40.0002.387
J	50	40.0002.388
	100	40.0002.389
K	50	40.0002.390
	100	40.0002.391
L	100	40.0002.392
M	50	40.0002.394
	100	40.0002.393

