


ARMABOT

RS7 Encoder, P/N A0031, RevA Installation Instructions



RS7 Encoder kit includes:





Use vice or arbor press to install encoder magnet into magnet housing into location shown.

-Use hex socket with an outside diameter of 0.47 to 0.53 inches or equivalent tool to press push nut into location shown. Depth of push nut from plastic surface approx. 0.04 inches.

2

Magnet assembly

Use thumb or tool to carefully press on magnet assembly. It will make a small click sound. The wheel should spin true, adjust if necessary.

