DSPIRA Horn Telescope Cradle Assembly

MATERIALS NEEDED:

two 20" long
$$2 \times 2$$
's

two $9\frac{5}{8}$ " long 2×2 's

one $6\frac{11}{16}$ " long 2×2 's

three 9 " long 2×2 's

one $\frac{1}{8}$ " long 2×2 's


one $\frac{1}{8}$ " long 2×2 's

one $\frac{1}{8}$ " plywood piece, $\frac{1}{8}$ "

1" or 1 $\frac{1}{4}$ " construction screws – for attaching the thin plywood base to the cradle

ASSEMBLING THE CRADLE:

1. Using the 2 ½ " screws, assemble the 20", $6\frac{11}{16}$ " and $9\frac{5}{8}$ " pieces into a rectangle with a cross bar, as illustrated in the *top view* diagram to the right.



- 2. Attach the two 9" pieces extending downward from the corners at the left end of the rectangular frame and one 9" piece from the midpoint of the $6\frac{11}{16}$ " crossbar.
- 3. Use the construction screws to attach the $\frac{1}{4}$ " plywood piece to the bottom of these three extensions. This should form a structure that the can can fit into.



assembled cradle