

"How can I update the firmware for Cosori Smart Air Fryer?" : "To update the firmware, open the VeSync app, navigate to 'Settings,' and check for available firmware updates. Follow the on-screen instructions to complete the update.",

"How do I manage the Wi-Fi connection for Cosori Smart Air Fryer?" : "To manage the Wi-Fi connection, open the VeSync app, select your device, and go to 'Wi-Fi Settings' to update or reconnect to a network.",

"How do I check alerts and notifications for Cosori Smart Air Fryer?" : "Open the VeSync app, select your air fryer, and go to 'Notifications' to view or manage alerts related to cooking completion or maintenance.",

"How can I access cooking history for Cosori Smart Air Fryer?" : "To access cooking history, open the VeSync app, select your air fryer, and navigate to 'History' to view past cooking sessions.",

"How do I manage cooking settings for Cosori Smart Air Fryer?" : "Use the VeSync app to set and save your favorite cooking settings by selecting the air fryer and adjusting the temperature and time presets.",

"How do I troubleshoot Wi-Fi connection issues with Cosori Smart Air Fryer?" : "If experiencing Wi-Fi issues, check if your router settings have changed or reconnect the air fryer using the VeSync app by navigating to 'Wi-Fi Settings.'",

"How do I reset Cosori Smart Air Fryer?" : "To reset the air fryer, unplug it from the power source, wait 30 seconds, and plug it back in.",

"How can I control power settings for Cosori Smart Air Fryer?" : "Use the VeSync app to turn the air fryer on or off remotely by selecting the device and tapping the power icon.",

"How do I schedule maintenance reminders for Cosori Smart Air Fryer?" : "Set maintenance reminders in the VeSync app by selecting your air fryer and navigating to 'Reminders' to schedule regular cleaning.",

"How can I monitor energy usage of Cosori Smart Air Fryer?" : "Open the VeSync app, select the air fryer, and go to 'Energy Usage' to track power consumption.",

"How do I configure smart schedules for Cosori Smart Air Fryer?" : "Use the VeSync app to schedule cooking times by selecting your air fryer and navigating to 'Smart Schedules.'",

"How do I change network settings for Cosori Smart Air Fryer?" : "To change network settings, open the VeSync app, select the air fryer, and go to 'Wi-Fi Settings' to connect to a new network.",

"How do I restart Cosori Smart Air Fryer from the app?" : "To restart the air fryer, open the VeSync app, select your device, and navigate to 'Device Settings' to initiate a restart.",

"How do I ensure safety for Cosori Smart Air Fryer after use?" : "Turn off the air fryer immediately after use through the VeSync app to ensure safety.",

"How do I manage cooking notifications for Cosori Smart Air Fryer?" : "To adjust cooking notifications, open the VeSync app, select your air fryer, and go to 'Notifications' to manage alerts.",

"How do I review cooking programs for Cosori Smart Air Fryer?" : "Open the VeSync app, select the air fryer, and navigate to 'Cooking Programs' to review and adjust the preset programs.",

"How do I perform a factory reset for Cosori Smart Air Fryer?" : "To perform a factory reset, open the VeSync app, select the air fryer, and go to 'Device Settings' to initiate the reset.",

"How can I update the firmware for Instant Vortex Plus?" : "To update the firmware, open the Instant app, navigate to 'Settings,' and check for available firmware updates. Follow the on-screen instructions to complete the update.",

"How do I check alerts and notifications for Instant Vortex Plus?" : "Open the Instant app, select your air fryer, and go to 'Notifications' to view or manage alerts related to cooking completion or maintenance.",

"How can I access cooking history for Instant Vortex Plus?" : "To access cooking history, open the Instant app, select your air fryer, and navigate to 'History' to view past cooking sessions.",

"How do I manage cooking settings for Instant Vortex Plus?" : "Use the Instant app to set and save your favorite cooking settings by selecting the air fryer and adjusting the temperature and time presets.",

"How can I manage sharing access for Instant Vortex Plus?" : "To share device control, open the Instant app, select your air fryer, and go to 'Share Device' to add family members.",

"How do I reset Instant Vortex Plus?" : "To reset the air fryer, unplug it from the power source, wait 30 seconds, and plug it back in.",

"How can I control power settings for Instant Vortex Plus?" : "Use the Instant app to turn the air fryer on or off remotely by selecting the device and tapping the power icon.",

"How do I change network settings for Instant Vortex Plus?" : "To change network settings, open the Instant app, select the air fryer, and go to 'Wi-Fi Settings' to connect to a new network.",

"How can I deactivate sharing access for Instant Vortex Plus?" : "To remove shared access, open the Instant app, select the air fryer, and navigate to 'Share Device' to remove users.",

"How do I restart Instant Vortex Plus from the app?" : "To restart the air fryer, open the Instant app, select your device, and navigate to 'Device Settings' to initiate a restart.",

"How do I ensure safety for Instant Vortex Plus after use?" : "Turn off the air fryer immediately after use through the Instant app to ensure safety.",

"How do I review cooking programs for Instant Vortex Plus?" : "Open the Instant app, select the air fryer, and navigate to 'Cooking Programs' to review and adjust the preset programs.",

"How do I perform a factory reset for Instant Vortex Plus?" : "To perform a factory reset, open the Instant app, select the air fryer, and go to 'Device Settings' to initiate the reset.",

"How do I manage the Wi-Fi connection for Cosori Smart Air Fryer?" : "To manage the Wi-Fi connection, open the VeSync app, select your device, and go to 'Wi-Fi Settings' to update or reconnect to a network.",

"How do I check alerts and notifications for Cosori Smart Air Fryer?" : "Open the VeSync app, select your air fryer, and go to 'Notifications' to view or manage alerts related to cooking completion or maintenance.",

"How can I access cooking history for Cosori Smart Air Fryer?" : "To access cooking history, open the VeSync app, select your air fryer, and navigate to 'History' to view past cooking sessions.",

"How can I manage sharing access for Cosori Smart Air Fryer?" : "To share device control, open the VeSync app, select your air fryer, and go to 'Share Device' to add family members.",

"How do I reset Cosori Smart Air Fryer?" : "To reset the air fryer, unplug it from the power source, wait 30 seconds, and plug it back in.",

"How can I control power settings for Cosori Smart Air Fryer?" : "Use the VeSync app to turn the air fryer on or off remotely by selecting the device and tapping the power icon.",

"How do I manage cooking programs for Cosori Smart Air Fryer?" : "Open the VeSync app, select the air fryer, and navigate to 'Cooking Programs' to update or modify settings as desired.",

"How do I schedule maintenance reminders for Cosori Smart Air Fryer?" : "Set maintenance reminders in the VeSync app by selecting your air fryer and navigating to 'Reminders' to schedule regular cleaning.",

"How can I monitor energy usage of Cosori Smart Air Fryer?" : "Open the VeSync app, select the air fryer, and go to 'Energy Usage' to track power consumption.",

"How do I change network settings for Cosori Smart Air Fryer?" : "To change network settings, open the VeSync app, select the air fryer, and go to 'Wi-Fi Settings' to connect to a new network.",

"How can I deactivate sharing access for Cosori Smart Air Fryer?" : "To remove shared access, open the VeSync app, select the air fryer, and navigate to 'Share Device' to remove users.",

"How do I restart Cosori Smart Air Fryer from the app?" : "To restart the air fryer, open the VeSync app, select your device, and navigate to 'Device Settings' to initiate a restart.",

"How do I ensure safety for Cosori Smart Air Fryer after use?" : "Turn off the air fryer immediately after use through the VeSync app to ensure safety.",

"How do I manage cooking notifications for Cosori Smart Air Fryer?" : "To adjust cooking notifications, open the VeSync app, select your air fryer, and go to 'Notifications' to manage alerts.",

"How do I review cooking programs for Cosori Smart Air Fryer?" : "Open the VeSync app, select the air fryer, and navigate to 'Cooking Programs' to review and adjust the preset programs.",

"How do I perform a factory reset for Cosori Smart Air Fryer?" : "To perform a factory reset, open the VeSync app, select the air fryer, and go to 'Device Settings' to initiate the reset.",

"How can I update the firmware for Texas Instruments SensorTag?" : "To update the firmware, connect the SensorTag to your computer via USB and use the Texas Instruments software tool to check for available updates. Follow the instructions to update the firmware.",

"How do I manage sensor data from Texas Instruments SensorTag?" : "Use the SensorTag app to view and manage data collected by the sensors, including temperature, humidity, and more.",

"How do I replace the battery in Texas Instruments SensorTag?" : "To replace the battery, open the battery compartment on the back of the device and insert a new CR2032 coin cell battery.",

"How can I monitor the battery level of Texas Instruments SensorTag?" : "Use the SensorTag app to monitor the battery level of your device under 'Device Information.'",

"How do I set up alerts for Texas Instruments SensorTag?" : "Open the SensorTag app, select your device, and navigate to 'Alerts' to set up notifications for various sensor thresholds.",

"How do I update the software on Texas Instruments SensorTag?" : "To update the software, connect the SensorTag to a computer and use the Texas Instruments software tool to perform the update.",

"How do I check for software compatibility with Texas Instruments SensorTag?" : "Visit the Texas Instruments website to view the latest software compatibility information for your SensorTag model.",

"How do I troubleshoot connectivity issues with Texas Instruments SensorTag?" : "Ensure Bluetooth is enabled on your device, restart the SensorTag, and try reconnecting through the SensorTag app.",

"How do I enable cloud storage for data collected by Texas Instruments SensorTag?" : "Use the SensorTag app to link your device with a cloud service provider to store collected data remotely.",

"How do I configure sampling intervals for Texas Instruments SensorTag sensors?" : "Use the SensorTag app to adjust the sampling intervals for each sensor by navigating to 'Settings.'",

"How do I manage data sharing for Texas Instruments SensorTag?" : "Open the SensorTag app, navigate to 'Data Sharing,' and select the methods or contacts with whom you want to share the collected data.",

"How do I update security settings for Texas Instruments SensorTag?" : "To update security settings, open the SensorTag app and navigate to 'Security' to configure encryption and access options.",

"How do I adjust sensor sensitivity for Texas Instruments SensorTag?" : "Open the SensorTag app, select the device, and navigate to 'Sensor Settings' to adjust the sensitivity levels of the sensors.",

"How do I rename Texas Instruments SensorTag in the app?" : "To rename the SensorTag, open the SensorTag app, select the device, and navigate to 'Device Settings' to update the name.",

"How do I monitor temperature using Texas Instruments SensorTag?" : "Open the SensorTag app and select the temperature sensor to view real-time temperature data collected by the SensorTag.",

"How do I use Texas Instruments SensorTag with multiple devices?" : "To use SensorTag with multiple devices, unpair it from one device and pair it with another using the SensorTag app.",

"How do I set up data logging for Texas Instruments SensorTag?" : "Open the SensorTag app, navigate to 'Data Logging,' and enable logging to start recording sensor data.",

"How do I view the firmware version for Texas Instruments SensorTag?" : "Open the SensorTag app, navigate to 'Device Information,' and view the firmware version details.",

"How can I update the firmware for Amazon Echo?" : "To update the firmware, ensure your Amazon Echo is connected to Wi-Fi. The device will automatically download and install updates when available.",

"How do I connect Amazon Echo to Wi-Fi?" : "To connect Amazon Echo to Wi-Fi, open the Alexa app, go to 'Devices,' select your Echo, and follow the prompts to connect to a Wi-Fi network.",

"How do I manage the volume settings for Amazon Echo?" : "You can adjust the volume by turning the top ring on the Echo device or by using the Alexa app. You can also use voice commands like 'Alexa, increase volume.'",

"How do I change the wake word for Amazon Echo?" : "Open the Alexa app, select 'Devices,' choose your Echo, and navigate to 'Wake Word' to select a different wake word.",

"How do I set up multi-room music on Amazon Echo?" : "To set up multi-room music, open the Alexa app, go to 'Devices,' tap on 'Plus,' and select 'Set Up Multi-Room Music.' Follow the prompts to add your Echo devices.",

"How do I change the language on Amazon Echo?" : "Open the Alexa app, go to 'Devices,' select your Echo, and navigate to 'Language' to select a new language.",

"How do I disable the microphone on Amazon Echo?" : "Press the microphone button on the top of the Echo device to disable voice input. The light ring will turn red when the microphone is disabled.",

"How do I enable Do Not Disturb mode on Amazon Echo?" : "To enable Do Not Disturb mode, say 'Alexa, turn on Do Not Disturb,' or use the Alexa app to manually enable it under device settings.",

"How do I check the firmware version on Amazon Echo?" : "Open the Alexa app, go to 'Devices,' select your Echo, and navigate to 'About' to view the current firmware version.",

"How do I set reminders with Amazon Echo?" : "To set a reminder, say 'Alexa, remind me to [task] at [time],' or use the Alexa app to manually add reminders.",

"How do I update the Wi-Fi settings for Amazon Echo?" : "Open the Alexa app, go to 'Devices,' select your Echo, and choose 'Wi-Fi Network' to update the Wi-Fi settings.",

"How do I add skills to Amazon Echo?" : "Open the Alexa app, go to 'Skills & Games,' browse or search for a skill, and tap 'Enable' to add it to your Echo.",

"How do I disable a skill on Amazon Echo?" : "To disable a skill, open the Alexa app, go to 'Skills & Games,' select the skill you want to disable, and tap 'Disable Skill.'",

"How do I set an alarm on Amazon Echo?" : "To set an alarm, say 'Alexa, set an alarm for [time],' or use the Alexa app to manually set an alarm.",

"How do I customize the Flash Briefing on Amazon Echo?" : "Open the Alexa app, go to 'Settings,' select 'Flash Briefing,' and choose your preferred news sources.",

"How do I check for updates for Amazon Echo?" : "Amazon Echo checks for updates automatically when connected to Wi-Fi. To manually check, restart the device and it will search for updates.",

"How do I use Amazon Echo to make calls?" : "To make a call, say 'Alexa, call [contact name],' or use the Alexa app to initiate a call to your contacts.",

"How do I enable voice purchasing on Amazon Echo?" : "Open the Alexa app, go to 'Settings,' select 'Voice Purchasing,' and toggle the setting to enable voice purchases.",

"How do I use Amazon Echo as a speaker for my TV?" : "To use Echo as a speaker for your TV, connect it via Bluetooth or use an Echo device with an audio-in option, and set it as the output device.",

"How do I link my calendar to Amazon Echo?" : "Open the Alexa app, go to 'Settings,' select 'Calendar & Email,' and follow the prompts to link your calendar account.",

"How do I check Amazon Echo's network strength?" : "Open the Alexa app, go to 'Devices,' select your Echo, and navigate to 'Network' to view signal strength.",

"How do I set up a guest network for Amazon Echo?" : "To connect your Echo to a guest network, open the Alexa app, go to 'Devices,' select your Echo, and update the Wi-Fi settings to the guest network.",

"How do I reset Amazon Echo to factory settings?" : "To reset Amazon Echo, press and hold the action button for 20 seconds until the light ring turns orange, indicating that the reset process has started.",

"How can I update the firmware for Google Nest Hub?" : "To update the firmware, ensure your Google Nest Hub is connected to Wi-Fi. Updates are installed automatically when available.",

"How do I connect Google Nest Hub to Wi-Fi?" : "To connect Google Nest Hub to Wi-Fi, open the Google Home app, tap on your device, and follow the prompts to connect it to a Wi-Fi network.",

"How do I adjust the volume on Google Nest Hub?" : "To adjust the volume, use the volume buttons on the side of the device or say 'Hey Google, set the volume to [level].'",

"How do I set up Google Assistant Routines on Google Nest Hub?" : "Open the Google Home app, tap on 'Routines,' and customize your desired routine by adding triggers and actions.",

"How do I set up multiple user voice recognition on Google Nest Hub?" : "Open the Google Home app, go to 'Assistant settings,' tap on 'Voice Match,' and follow the instructions to add multiple users.",

"How do I customize the ambient clock on Google Nest Hub?" : "Open the Google Home app, select your device, tap on 'Ambient Mode,' and choose your preferred clock style.",

"How do I check the firmware version of Google Nest Hub?" : "To check the firmware version, open the Google Home app, select your device, and go to 'Device settings' to view firmware information.",

"How do I enable Continued Conversation on Google Nest Hub?" : "Open the Google Home app, go to 'Assistant settings,' select 'Continued Conversation,' and toggle it on to enable the feature.",

"How do I control Google Nest Hub using voice commands?" : "Simply say 'Hey Google' followed by your command to play music, check the weather, control smart home devices, and more.",

"How do I manage device groups for Google Nest Hub?" : "Open the Google Home app, go to 'Rooms and groups,' and create or manage groups to include your Google Nest Hub and other smart devices.",

"How do I change the language on Google Nest Hub?" : "Open the Google Home app, go to 'Assistant settings,' select 'Languages,' and choose your preferred language for Google Nest Hub.",

"How do I set reminders with Google Nest Hub?" : "To set a reminder, say 'Hey Google, remind me to [task] at [time],' or use the Google Home app to manually set reminders.",

"How do I delete voice recordings from Google Nest Hub?" : "Open the Google Home app, go to 'Assistant settings,' select 'Your data in the Assistant,' and delete voice recordings as needed.",

"How do I set an alarm on Google Nest Hub?" : "To set an alarm, say 'Hey Google, set an alarm for [time],' or use the Google Home app to manually set an alarm.",

"How do I link my calendar to Google Nest Hub?" : "Open the Google Home app, go to 'Assistant settings,' select 'Calendar,' and follow the prompts to link your calendar account.",

"How do I customize News settings on Google Nest Hub?" : "Open the Google Home app, go to 'Assistant settings,' select 'News,' and choose your preferred news sources.",

"How do I rename my Google Nest Hub device?" : "Open the Google Home app, select your device, and navigate to 'Device settings' to rename your Google Nest Hub.",

"How do I use Google Nest Hub to make video calls?" : "To make a video call, link your Google Nest Hub with Google Duo in the Google Home app, then say 'Hey Google, call [contact name].'",

"How do I create a shopping list with Google Nest Hub?" : "To create a shopping list, say 'Hey Google, add [item] to my shopping list,' or use the Google Home app to add items manually.",

"How do I disconnect Google Nest Hub from Bluetooth?" : "To disconnect from Bluetooth, open the Google Home app, select your device, and navigate to 'Bluetooth settings' to disconnect.",

"How do I enable Guest Mode on Google Nest Hub?" : "Say 'Hey Google, turn on Guest Mode' to enable it, or use the Google Home app to manually activate Guest Mode for privacy.",

"How do I set up Family Bell announcements on Google Nest Hub?" : "Open the Google Home app, go to 'Assistant settings,' select 'Family Bell,' and follow the prompts to set up announcements."

"How do I use Google Nest Hub to control smart home devices?" : "Simply say 'Hey Google, turn on/off [device],' or use the Google Home app to control your smart home devices through Google Nest Hub."

"How do I enable interpreter mode on Google Nest Hub?" : "Say 'Hey Google, be my interpreter,' and Google Nest Hub will enter interpreter mode to translate conversations in real-time."

"How do I use Google Nest Hub for fitness tracking?" : "Link your fitness account in the Google Home app to view activity metrics and workout videos directly on Google Nest Hub."

"How do I manage schedules with Google Nest Hub?" : "Open the Google Home app, go to 'Assistant settings,' select 'Routines,' and set schedules for tasks like turning off lights or adjusting the thermostat."

"How can I update the firmware for Amazon Echo?" : "To update the firmware, ensure your Amazon Echo is connected to Wi-Fi. The device will automatically download and install updates when available."

"How do I connect Amazon Echo to Wi-Fi?" : "To connect Amazon Echo to Wi-Fi, open the Alexa app, go to 'Devices,' select your Echo, and follow the prompts to connect to a Wi-Fi network."

"How can I update the firmware for Google Nest Hub?" : "To update the firmware, ensure your Google Nest Hub is connected to Wi-Fi. Updates are installed automatically when available."

"How do I connect Google Nest Hub to Wi-Fi?" : "To connect Google Nest Hub to Wi-Fi, open the Google Home app, tap on your device, and follow the prompts to connect it to a Wi-Fi network."

"How do I adjust the volume on Google Nest Hub?" : "To adjust the volume, use the volume buttons on the side of the device or say 'Hey Google, set the volume to [level].'"

"How do I set up Google Assistant Routines on Google Nest Hub?" : "Open the Google Home app, tap on 'Routines,' and customize your desired routine by adding triggers and actions."

"How do I enable Downtime on Google Nest Hub?" : "To enable Downtime, open the Google Home app, go to 'Digital Wellbeing,' and set up Downtime for your Google Nest Hub."

"How do I set up multiple user voice recognition on Google Nest Hub?" : "Open the Google Home app, go to 'Assistant settings,' tap on 'Voice Match,' and follow the instructions to add multiple users."

"How do I enable Continued Conversation on Google Nest Hub?" : "Open the Google Home app, go to 'Assistant settings,' select 'Continued Conversation,' and toggle it on to enable the feature.",

"How do I control Google Nest Hub using voice commands?" : "Simply say 'Hey Google' followed by your command to play music, check the weather, control smart home devices, and more.",

"How do I manage device groups for Google Nest Hub?" : "Open the Google Home app, go to 'Rooms and groups,' and create or manage groups to include your Google Nest Hub and other smart devices.",

"How do I change the language on Google Nest Hub?" : "Open the Google Home app, go to 'Assistant settings,' select 'Languages,' and choose your preferred language for Google Nest Hub.",

"How do I set reminders with Google Nest Hub?" : "To set a reminder, say 'Hey Google, remind me to [task] at [time],' or use the Google Home app to manually set reminders.",

"How do I disable the microphone on Google Nest Hub?" : "Toggle the physical microphone switch on the back of Google Nest Hub to disable voice input. The screen will display that the microphone is off.",

"How do I check the connectivity status of Google Nest Hub?" : "Open the Google Home app, select your device, and navigate to 'Device settings' to check the connectivity status.",

"How do I link my calendar to Google Nest Hub?" : "Open the Google Home app, go to 'Assistant settings,' select 'Calendar,' and follow the prompts to link your calendar account.",

"How do I enable Night Mode on Google Nest Hub?" : "Open the Google Home app, select your device, and go to 'Display settings' to enable Night Mode, which adjusts screen brightness at night.",

"How do I customize News settings on Google Nest Hub?" : "Open the Google Home app, go to 'Assistant settings,' select 'News,' and choose your preferred news sources.",

"How do I use Google Nest Hub as an intercom?" : "To use your Nest Hub as an intercom, say 'Hey Google, broadcast [message],' or use the Google Home app to broadcast a message to all devices.",

"How do I rename my Google Nest Hub device?" : "Open the Google Home app, select your device, and navigate to 'Device settings' to rename your Google Nest Hub.",

"How do I use Google Nest Hub to make video calls?" : "To make a video call, link your Google Nest Hub with Google Duo in the Google Home app, then say 'Hey Google, call [contact name].'",

"How do I manage paired Bluetooth devices for Google Nest Hub?" : "Open the Google Home app, select your Google Nest Hub, and navigate to 'Bluetooth settings' to manage paired devices.",

"How do I create a shopping list with Google Nest Hub?" : "To create a shopping list, say 'Hey Google, add [item] to my shopping list,' or use the Google Home app to add items manually.",

"How do I disconnect Google Nest Hub from Bluetooth?" : "To disconnect from Bluetooth, open the Google Home app, select your device, and navigate to 'Bluetooth settings' to disconnect.",

"How do I use Google Nest Hub to control smart home devices?" : "Simply say 'Hey Google, turn on/off [device],' or use the Google Home app to control your smart home devices through Google Nest Hub.",

"How do I use Google Nest Hub for fitness tracking?" : "Link your fitness account in the Google Home app to view activity metrics and workout videos directly on Google Nest Hub.",

"How do I manage schedules with Google Nest Hub?" : "Open the Google Home app, go to 'Assistant settings,' select 'Routines,' and set schedules for tasks like turning off lights or adjusting the thermostat.",

"How do I manage alarms on Google Nest Hub?" : "To manage alarms, open the Google Home app, select your device, and navigate to 'Alarms & Timers' to view, modify, or delete alarms.",

"How do I connect Google Nest Hub to a new Wi-Fi network?" : "Open the Google Home app, select your device, and tap on 'Wi-Fi Settings' to connect to a new Wi-Fi network.",

"How can I update the firmware for Amazon Echo?" : "To update the firmware, ensure your Amazon Echo is connected to Wi-Fi. The device will automatically download and install updates when available.",

"How do I reset Amazon Echo to factory settings?" : "To reset Amazon Echo, press and hold the action button for 20 seconds until the light ring turns orange, indicating that the reset process has started.",

"How do I connect Amazon Echo to Wi-Fi?" : "To connect Amazon Echo to Wi-Fi, open the Alexa app, go to 'Devices,' select your Echo, and follow the prompts to connect to a Wi-Fi network.",

"How can I update the firmware for Google Nest Hub?" : "To update the firmware, ensure your Google Nest Hub is connected to Wi-Fi. Updates are installed automatically when available.",

"How do I reset Google Nest Hub to factory settings?" : "To reset Google Nest Hub, press and hold both volume buttons located at the back of the device for about 10 seconds until you see a message indicating the reset process has started.",

"How can I update the firmware for LIFX Smart Bulb?" : "To update the firmware, open the LIFX app, go to 'Settings,' select your LIFX bulb, and check for available firmware updates. Follow the on-screen instructions to complete the update.",

"How do I connect LIFX Smart Bulb to Wi-Fi?" : "To connect the LIFX Smart Bulb to Wi-Fi, open the LIFX app, tap 'Add Device,' and follow the prompts to connect it to your Wi-Fi network.",

"How do I change the color of LIFX Smart Bulb?" : "Open the LIFX app, select your bulb, and use the color wheel to choose your preferred color. You can also use voice commands if connected to a voice assistant.",

"How do I set a schedule for LIFX Smart Bulb?" : "To set a schedule, open the LIFX app, select your bulb, and navigate to 'Schedules' to set specific on and off times for the bulb.",

"How do I control LIFX Smart Bulb using voice commands?" : "To control the LIFX bulb using voice commands, link it to a voice assistant like Amazon Alexa or Google Assistant, then use commands like 'Turn on LIFX bulb.'",

"How do I create scenes with LIFX Smart Bulb?" : "To create scenes, open the LIFX app, go to 'Scenes,' and customize your desired lighting configurations by selecting colors and brightness levels for each bulb.",

"How do I update Wi-Fi settings for LIFX Smart Bulb?" : "To update Wi-Fi settings, open the LIFX app, select your bulb, and go to 'Wi-Fi Settings' to connect to a new network.",

"How do I delete a LIFX Smart Bulb from the app?" : "To delete a bulb, open the LIFX app, select the bulb, go to 'Settings,' and tap 'Delete Device.'",

"How do I troubleshoot connection issues with LIFX Smart Bulb?" : "If you're experiencing connection issues, try resetting the bulb, restarting your router, and ensuring the LIFX app is updated.",

"How do I rename my LIFX Smart Bulb?" : "Open the LIFX app, select your bulb, go to 'Settings,' and tap on the name to edit it.",

"How do I check for firmware updates for LIFX Smart Bulb?" : "Open the LIFX app, select your bulb, and navigate to 'Settings' to check for available firmware updates.",

"How do I integrate LIFX Smart Bulb with Amazon Alexa?" : "Open the Alexa app, go to 'Devices,' tap on 'Add Device,' and select 'LIFX' to link your account and control the bulb using Alexa.",

"How do I adjust the color temperature on LIFX Smart Bulb?" : "Open the LIFX app, select your bulb, and use the color temperature slider to adjust between warm and cool white tones.",

"How do I create a new group for LIFX Smart Bulbs?" : "Open the LIFX app, go to 'Groups,' and tap 'Create Group' to add bulbs that you want to control together.",

"How do I set up location-based control for LIFX Smart Bulb?" : "Open the LIFX app, go to 'Settings,' and enable 'Location Services' to control your lights based on your location.",

"How do I adjust power-on behavior for LIFX Smart Bulb?" : "To adjust power-on behavior, open the LIFX app, select your bulb, and go to 'Settings' to set what the bulb does when powered on.",

"How do I turn on/off LIFX Smart Bulb remotely?" : "Open the LIFX app, select your bulb, and tap the power button to turn it on or off remotely.",

"How do I check energy usage for LIFX Smart Bulb?" : "Open the LIFX app, select your bulb, and navigate to 'Energy Usage' to view the estimated power consumption of the bulb.",

"How do I rename a group of LIFX Smart Bulbs?" : "Open the LIFX app, go to 'Groups,' select the group you want to rename, and edit the group name under 'Settings.'",

"How do I control LIFX Smart Bulb from a smartwatch?" : "Install the LIFX app on your smartwatch, and use it to control your LIFX Smart Bulbs directly from your wrist.",

"How do I use voice commands to change LIFX Smart Bulb to a specific color?" : "If linked to a voice assistant, say 'Set LIFX bulb to [color]' to change the color using voice commands.",

"How do I reset Amazon Echo to factory settings?" : "To reset Amazon Echo, press and hold the action button for 20 seconds until the light ring turns orange, indicating that the reset process has started.",

"How do I connect Amazon Echo to Wi-Fi?" : "To connect Amazon Echo to Wi-Fi, open the Alexa app, go to 'Devices,' select your Echo, and follow the prompts to connect to a Wi-Fi network.",

"How do I reset Google Nest Hub to factory settings?" : "To reset Google Nest Hub, press and hold both volume buttons located at the back of the device for about 10 seconds until you see a message indicating the reset process has started.",

"How do I connect Google Nest Hub to Wi-Fi?" : "To connect Google Nest Hub to Wi-Fi, open the Google Home app, tap on your device, and follow the prompts to connect it to a Wi-Fi network.",

"How can I update the firmware for LIFX Smart Bulb?" : "To update the firmware, open the LIFX app, go to 'Settings,' select your LIFX bulb, and check for available firmware updates. Follow the on-screen instructions to complete the update.",

"How can I update the firmware for Kasa Smart Bulb?" : "To update the firmware, open the Kasa app, go to 'Devices,' select your Kasa Smart Bulb, and check for available firmware updates. Follow the instructions to complete the update.",

"How do I reset Kasa Smart Bulb to factory settings?" : "To reset the Kasa Smart Bulb, turn it on and off three times until it blinks rapidly, indicating a successful reset.",

"How do I connect Kasa Smart Bulb to Wi-Fi?" : "Open the Kasa app, tap 'Add Device,' and follow the prompts to connect the bulb to your Wi-Fi network.",

"How can I update the firmware for Nest Thermostat?" : "To update the firmware, ensure your Nest Thermostat is connected to Wi-Fi. Firmware updates will be installed automatically when available.",

"How do I connect Nest Thermostat to Wi-Fi?" : "To connect Nest Thermostat to Wi-Fi, press the thermostat ring to open the 'Settings' menu, then select 'Network' and follow the prompts to connect.",

"How do I set a schedule on Nest Thermostat?" : "Open the Google Home app or Nest app, select your thermostat, and go to 'Schedule' to set temperature adjustments for different times of the day.",

"How do I enable Eco Mode on Nest Thermostat?" : "Press the thermostat ring, select 'Eco,' and then choose 'Start Eco Mode' to save energy when you're away.",

"How do I control Nest Thermostat using voice commands?" : "Link your thermostat to Google Assistant or Amazon Alexa, then use commands like 'Hey Google, set the temperature to 72 degrees.'",

"How do I create Home/Away Assist settings on Nest Thermostat?" : "Open the Nest app, go to 'Settings,' select 'Home/Away Assist,' and configure the temperature settings for when you are home or away.",

"How do I check the battery level of Nest Thermostat?" : "To check the battery level, press the thermostat ring, go to 'Settings,' and select 'Technical Info' to view the battery status.",

"How do I lock Nest Thermostat?" : "Press the thermostat ring, go to 'Settings,' select 'Lock,' and follow the prompts to set a PIN code to lock the thermostat.",

"How do I update the location settings on Nest Thermostat?" : "Open the Google Home or Nest app, select your thermostat, go to 'Settings,' and update the address under 'Home Information.'",

"How do I adjust the display brightness on Nest Thermostat?" : "Press the thermostat ring, go to 'Settings,' select 'Display,' and adjust the brightness level as desired.",

"How do I set temperature safety alerts on Nest Thermostat?" : "Open the Nest app, go to 'Settings,' select 'Safety Temperatures,' and set minimum and maximum temperature thresholds for safety alerts.",

"How do I rename my Nest Thermostat?" : "Open the Google Home or Nest app, select your thermostat, go to 'Settings,' and tap on the name to edit it.",

"How do I enable Airwave feature on Nest Thermostat?" : "Open the Nest app, go to 'Settings,' select 'Airwave,' and enable it to reduce energy usage by running the fan after the compressor turns off.",

"How do I troubleshoot Wi-Fi issues on Nest Thermostat?" : "If experiencing Wi-Fi issues, restart your thermostat and router, and ensure the Wi-Fi network name and password are correct.",

"How do I calibrate Nest Thermostat?" : "Nest Thermostat automatically calibrates itself. If you notice discrepancies, try restarting the thermostat or contact support.",

"How do I set up Family Accounts for Nest Thermostat?" : "Open the Google Home or Nest app, go to 'Settings,' select 'Family & Guests,' and invite members to share control of the thermostat.",

"How do I check the software version of Nest Thermostat?" : "Press the thermostat ring, go to 'Settings,' select 'Technical Info,' and view the software version.",

"How do I integrate Nest Thermostat with SmartThings?" : "Open the SmartThings app, tap 'Add Device,' search for 'Nest Thermostat,' and follow the prompts to link your account.",

"How do I disable learning on Nest Thermostat?" : "Open the Nest app, go to 'Settings,' select 'Learning,' and turn off Auto-Schedule to disable the learning feature.",

"How do I change the home icon on Nest Thermostat?" : "Open the Nest app, go to 'Settings,' select 'Home Icon,' and choose from the available options to personalize your thermostat.",

"How do I use Quick View on Nest Thermostat?" : "Press the thermostat ring to activate Quick View, which allows you to quickly access settings, energy history, and schedule.",

"How do I set a heat pump balance on Nest Thermostat?" : "Open the Nest app, go to 'Settings,' select 'Heat Pump Balance,' and choose between 'Max Comfort,' 'Max Savings,' or a custom setting.",

"How can I update the firmware for Amazon Echo?" : "To update the firmware, ensure your Amazon Echo is connected to Wi-Fi. The device will automatically download and install updates when available.",

"How do I connect Amazon Echo to Wi-Fi?" : "To connect Amazon Echo to Wi-Fi, open the Alexa app, go to 'Devices,' select your Echo, and follow the prompts to connect to a Wi-Fi network.",

"How can I update the firmware for Google Nest Hub?" : "To update the firmware, ensure your Google Nest Hub is connected to Wi-Fi. Updates are installed automatically when available.",

"How do I reset Google Nest Hub to factory settings?" : "To reset Google Nest Hub, press and hold both volume buttons located at the back of the device for about 10 seconds until you see a message indicating the reset process has started.",

"How do I connect Google Nest Hub to Wi-Fi?" : "To connect Google Nest Hub to Wi-Fi, open the Google Home app, tap on your device, and follow the prompts to connect it to a Wi-Fi network.",

"How can I update the firmware for LIFX Smart Bulb?" : "To update the firmware, open the LIFX app, go to 'Settings,' select your LIFX bulb, and check for available firmware updates. Follow the on-screen instructions to complete the update.",

"How do I connect LIFX Smart Bulb to Wi-Fi?" : "To connect the LIFX Smart Bulb to Wi-Fi, open the LIFX app, tap 'Add Device,' and follow the prompts to connect it to your Wi-Fi network.",

"How do I reset Kasa Smart Bulb to factory settings?" : "To reset the Kasa Smart Bulb, turn it on and off three times until it blinks rapidly, indicating a successful reset.",

"How do I connect Kasa Smart Bulb to Wi-Fi?" : "Open the Kasa app, tap 'Add Device,' and follow the prompts to connect the bulb to your Wi-Fi network.",

"How can I update the firmware for Nest Thermostat?" : "To update the firmware, ensure your Nest Thermostat is connected to Wi-Fi. Firmware updates will be installed automatically when available.",

"How do I reset Nest Thermostat to factory settings?" : "To reset the Nest Thermostat, go to 'Settings,' select 'Reset,' and choose 'All Settings' to restore factory defaults.",

"How do I reset ecobee SmartThermostat to factory settings?" : "To reset the ecobee SmartThermostat, go to 'Main Menu,' select 'Settings,' then 'Reset,' and choose 'Reset All Settings.'",

"How do I connect ecobee SmartThermostat to Wi-Fi?" : "To connect the ecobee SmartThermostat to Wi-Fi, go to 'Main Menu,' select 'Wi-Fi,' and follow the prompts to connect to your network.",

"How do I adjust the temperature with ecobee SmartThermostat?" : "Use the touchscreen on the thermostat or open the ecobee app to adjust the temperature settings.",

"How do I control ecobee SmartThermostat using voice commands?" : "Link your thermostat to Amazon Alexa or Google Assistant, then use commands like 'Set the temperature to 72 degrees.'",

"How do I create Home/Away settings on ecobee SmartThermostat?" : "Open the ecobee app, go to 'Settings,' select 'Preferences,' and configure temperature settings for when you're home or away.",

"How do I check the system status of ecobee SmartThermostat?" : "Go to 'Main Menu' on the thermostat, select 'System,' and view the status of heating, cooling, and fan.",

"How do I lock ecobee SmartThermostat?" : "Open the ecobee app, go to 'Settings,' select 'Access Control,' and set a PIN to lock the thermostat.",

"How do I use ecobee SmartThermostat with multiple zones?" : "Install multiple ecobee SmartThermostats in each zone and link them through the ecobee app for individual or group control.",

"How do I integrate ecobee SmartThermostat with Apple HomeKit?" : "Open the Home app on your iOS device, tap 'Add Accessory,' and scan the HomeKit code found on your ecobee thermostat.",

"How do I adjust the display brightness on ecobee SmartThermostat?" : "Go to 'Main Menu,' select 'Settings,' then 'Display,' and adjust the brightness level as desired.",

"How do I view energy reports on ecobee SmartThermostat?" : "Open the ecobee app, go to 'Home IQ,' and view energy usage reports for insights into your heating and cooling patterns.",

"How do I rename my ecobee SmartThermostat?" : "Open the ecobee app, select your thermostat, go to 'Settings,' and tap on the name to edit it.",

"How do I troubleshoot Wi-Fi issues on ecobee SmartThermostat?" : "If experiencing Wi-Fi issues, restart your thermostat and router, and ensure that the Wi-Fi network name and password are correct.",

"How do I adjust the temperature differential on ecobee SmartThermostat?" : "Open the ecobee app, go to 'Settings,' and adjust the temperature differential under 'Thresholds.'",

"How do I check compatibility for ecobee SmartThermostat installation?" : "Visit the ecobee compatibility checker online and enter details about your current HVAC system to verify compatibility.",

"How do I calibrate ecobee SmartThermostat?" : "ecobee SmartThermostat automatically calibrates itself. If discrepancies are noted, restart the thermostat or contact support.",

"How do I enable Dehumidify Using AC on ecobee SmartThermostat?" : "Open the ecobee app, go to 'Settings,' select 'Equipment,' and enable 'Dehumidify Using AC' to help control humidity levels.",

"How do I change the temperature units on ecobee SmartThermostat?" : "Go to 'Main Menu,' select 'Settings,' then 'Preferences,' and switch between Fahrenheit and Celsius.",

"How do I set up Family Accounts for ecobee SmartThermostat?" : "Open the ecobee app, go to 'Settings,' select 'Family Accounts,' and invite members to share control of the thermostat.",

"How can I update the firmware for Honeywell Lyric?" : "To update the firmware, ensure your Honeywell Lyric is connected to Wi-Fi. Firmware updates are installed automatically when available.",

"How do I adjust the temperature with Honeywell Lyric?" : "Rotate the thermostat ring or use the Lyric app to adjust the temperature to your desired setting.",

"How do I control Honeywell Lyric using voice commands?" : "Link your Lyric thermostat to Amazon Alexa or Google Assistant and use voice commands like 'Set the temperature to 70 degrees.'",

"How do I create geofencing settings on Honeywell Lyric?" : "Open the Lyric app, go to 'Settings,' select 'Geofencing,' and configure the temperature settings based on your location.",

"How do I check the battery level of Honeywell Lyric?" : "To check the battery level, open the Lyric app, go to 'Settings,' and select 'Battery' to view the current status.",

"How do I update the location settings on Honeywell Lyric?" : "Open the Lyric app, go to 'Settings,' select 'Location,' and update your home address.",

"How do I enable Smart Response on Honeywell Lyric?" : "Open the Lyric app, go to 'Settings,' select 'Smart Response,' and enable it to pre-heat or pre-cool your home before scheduled times.",

"How do I use Honeywell Lyric with multiple zones?" : "Install multiple Honeywell Lyric thermostats in each zone and link them through the Lyric app for individual or group control.",

"How do I integrate Honeywell Lyric with Google Home?" : "Open the Google Home app, tap 'Add Device,' select 'Works with Google,' and link your Honeywell Lyric account.",

"How do I adjust the display brightness on Honeywell Lyric?" : "Go to 'Settings' on the thermostat or use the Lyric app to adjust the display brightness level.",

"How do I view energy usage on Honeywell Lyric?" : "Open the Lyric app, select your thermostat, and navigate to 'Energy Report' to view historical energy usage details.",

"How do I rename my Honeywell Lyric thermostat?" : "Open the Lyric app, select your thermostat, go to 'Settings,' and tap on the name to edit it.",

"How do I enable fan control on Honeywell Lyric?" : "Open the Lyric app, go to 'Fan Settings,' and adjust the fan mode to 'On' or 'Auto' as needed.",

"How do I adjust temperature swing settings on Honeywell Lyric?" : "Open the Lyric app, go to 'Settings,' and adjust the temperature swing settings under 'Thermostat Preferences.'",

"How do I calibrate Honeywell Lyric?" : "Honeywell Lyric automatically calibrates itself. If discrepancies are noted, try restarting the thermostat or contact support.",

"How do I enable Auto Changeover on Honeywell Lyric?" : "Open the Lyric app, go to 'Settings,' select 'Auto Changeover,' and enable it to switch between heating and cooling automatically.",

"How do I set up Family Accounts for Honeywell Lyric?" : "Open the Lyric app, go to 'Settings,' select 'Family Accounts,' and invite members to share control of the thermostat.",

"How do I check the software version of Honeywell Lyric?" : "Open the Lyric app, go to 'Settings,' and select 'Device Info' to view the software version.",

"How do I adjust fan settings on Honeywell Lyric?" : "Press the thermostat ring, go to 'Fan,' and set a schedule or adjust fan runtime manually.",

"How do I disable learning on Honeywell Lyric?" : "Open the Lyric app, go to 'Settings,' select 'Learning,' and turn off Auto-Schedule to disable the learning feature.",

"How do I change the home icon on Honeywell Lyric?" : "Open the Lyric app, go to 'Settings,' select 'Home Icon,' and choose from the available options to personalize your thermostat.",

"How do I use Quick View on Honeywell Lyric?" : "Press the thermostat ring to activate Quick View, which allows you to quickly access settings, energy history, and schedule.",

"How do I set a heat pump balance on Honeywell Lyric?" : "Open the Lyric app, go to 'Settings,' select 'Heat Pump Balance,' and choose between 'Max Comfort,' 'Max Savings,' or a custom setting.",

"How do I enable Seasonal Savings on Honeywell Lyric?" : "Open the Lyric app, go to 'Settings,' select 'Seasonal Savings,' and enable it to optimize your energy usage during peak seasons.",

"How do I set reminders for filter changes on Honeywell Lyric?" : "Open the Lyric app, go to 'Settings,' select 'Reminders,' and set a schedule for filter change reminders.",

"How do I change the display language on Honeywell Lyric?" : "Open the Lyric app, go to 'Settings,' select 'Language,' and choose your preferred display language.",

"How can I update the firmware for TP-Link Kasa Smart Plug?" : "To update the firmware, open the Kasa app, go to 'Devices,' select your Smart Plug, and check for available firmware updates. Follow the instructions to complete the update.",

"How do I set a schedule for TP-Link Kasa Smart Plug?" : "Open the Kasa app, select your Smart Plug, and go to 'Schedule' to set specific on and off times.",

"How do I enable Away Mode on TP-Link Kasa Smart Plug?" : "Open the Kasa app, select your Smart Plug, and enable 'Away Mode' to turn the plug on and off randomly, simulating someone being home.",

"How do I control TP-Link Kasa Smart Plug using voice commands?" : "Link your Kasa Smart Plug to Amazon Alexa or Google Assistant, then use voice commands like 'Turn on the Smart Plug.'",

"How do I rename TP-Link Kasa Smart Plug?" : "Open the Kasa app, select your Smart Plug, go to 'Settings,' and tap on the name to edit it.",

"How do I check energy usage for TP-Link Kasa Smart Plug?" : "Open the Kasa app, select your Smart Plug, and navigate to 'Energy Usage' to view power consumption details.",

"How do I integrate TP-Link Kasa Smart Plug with Google Home?" : "Open the Google Home app, tap 'Add Device,' select 'Works with Google,' and link your Kasa account to control the plug via Google Home.",

"How do I integrate TP-Link Kasa Smart Plug with Amazon Alexa?" : "Open the Alexa app, go to 'Devices,' tap on 'Add Device,' and select 'Kasa' to link your account and control the plug using Alexa.",

"How do I enable voice control for TP-Link Kasa Smart Plug?" : "Open the Kasa app, go to 'Integrations,' and link the plug to your preferred voice assistant like Amazon Alexa or Google Assistant.",

"How do I update the Wi-Fi settings for TP-Link Kasa Smart Plug?" : "To update Wi-Fi settings, reset the plug by pressing and holding the power button for 10 seconds, then reconnect it through the Kasa app.",

"How do I check the firmware version of TP-Link Kasa Smart Plug?" : "Open the Kasa app, select your Smart Plug, and navigate to 'Settings' to view the firmware version.",

"How do I set up Smart Actions for TP-Link Kasa Smart Plug?" : "Open the Kasa app, go to 'Smart Actions,' and create actions to automate how your Smart Plug operates with other devices.",

"How do I troubleshoot connection issues with TP-Link Kasa Smart Plug?" : "If experiencing connection issues, try resetting the plug, restarting your router, and ensuring that the Kasa app is up to date.",

"How do I enable remote control for TP-Link Kasa Smart Plug?" : "Ensure your Smart Plug is connected to Wi-Fi, and use the Kasa app to control it remotely from anywhere.",

"How do I set up a group for TP-Link Kasa Smart Plugs?" : "Open the Kasa app, go to 'Groups,' and add multiple Smart Plugs to a group for simultaneous control.",

"How do I adjust power-on behavior for TP-Link Kasa Smart Plug?" : "Open the Kasa app, select your Smart Plug, and go to 'Settings' to set the default behavior when the plug is powered on.",

"How do I use TP-Link Kasa Smart Plug with a smart hub?" : "Check if your smart hub is compatible with Kasa, then link your account using the hub's app to control the plug.",

"How do I enable cloud access for TP-Link Kasa Smart Plug?" : "Open the Kasa app, go to 'Settings,' and enable 'Remote Control' to allow cloud access for controlling the plug remotely.",

"How do I control TP-Link Kasa Smart Plug from a smartwatch?" : "Install the Kasa app on your smartwatch, and use it to control your Kasa Smart Plug directly from your wrist.",

"How do I unlink TP-Link Kasa Smart Plug from Google Home?" : "Open the Google Home app, go to 'Linked Services,' select 'Kasa,' and remove the link to disconnect your Smart Plug.",

"How do I unlink TP-Link Kasa Smart Plug from Amazon Alexa?" : "Open the Alexa app, go to 'Devices,' select your Smart Plug, and tap 'Remove' to unlink it from Alexa.",

"How do I enable sunrise/sunset scheduling for TP-Link Kasa Smart Plug?" : "Open the Kasa app, go to 'Schedule,' and select 'Sunrise & Sunset' to automatically turn the plug on or off based on local times.",

"How do I add TP-Link Kasa Smart Plug to a scene?" : "Open the Kasa app, go to 'Scenes,' and add your Smart Plug to an existing scene for customized automation.",

"How do I enable third-party services for TP-Link Kasa Smart Plug?" : "Open the Kasa app, go to 'Settings,' and enable third-party services like Alexa, Google Home, or IFTTT.",

"How do I use TP-Link Kasa Smart Plug with SmartThings?" : "Open the SmartThings app, tap 'Add Device,' search for 'Kasa Smart Plug,' and follow the prompts to link your account.",

"How do I disconnect TP-Link Kasa Smart Plug from Wi-Fi?" : "To disconnect, press and hold the power button for 5 seconds until the LED starts blinking amber, then remove it from the app.",

"How do I control TP-Link Kasa Smart Plug with Siri Shortcuts?" : "Open the Shortcuts app on your iOS device, create a new shortcut, and link it to your Kasa Smart Plug via the Kasa app.",

"How do I share control of TP-Link Kasa Smart Plug with family members?" : "Open the Kasa app, select your Smart Plug, go to 'Settings,' and invite other users to share control of the plug.",

"How do I reset TP-Link Kasa Smart Plug after a power outage?" : "If the plug doesn't reconnect automatically, press and hold the power button for 10 seconds to reset and reconnect it.",

"How do I link multiple TP-Link Kasa Smart Plugs for simultaneous control?" : "Open the Kasa app, create a group under 'Groups,' and add multiple Smart Plugs for simultaneous control.",

"How do I update the default power-on state for TP-Link Kasa Smart Plug?" : "Open the Kasa app, select your Smart Plug, and go to 'Settings' to set the default power-on state.",

"How can I update the firmware for Wemo Mini Smart Plug?" : "To update the firmware, open the Wemo app, go to 'Devices,' select your Smart Plug, and check for available firmware updates. Follow the instructions to complete the update.",

"How do I connect Wemo Mini Smart Plug to Wi-Fi?" : "Open the Wemo app, tap 'Add Device,' select your Smart Plug, and follow the prompts to connect it to your Wi-Fi network.",

"How do I control Wemo Mini Smart Plug using voice commands?" : "Link your Wemo Mini Smart Plug to Amazon Alexa, Google Assistant, or Apple HomeKit, then use voice commands like 'Turn on the Smart Plug.'",

"How do I rename Wemo Mini Smart Plug?" : "Open the Wemo app, select your Smart Plug, go to 'Settings,' and tap on the name to edit it.",

"How do I integrate Wemo Mini Smart Plug with Google Home?" : "Open the Google Home app, tap 'Add Device,' select 'Works with Google,' and link your Wemo account to control the plug via Google Home.",

"How do I enable voice control for Wemo Mini Smart Plug?" : "Open the Wemo app, go to 'Integrations,' and link the plug to your preferred voice assistant like Amazon Alexa, Google Assistant, or Apple HomeKit.",

"How do I enable IFTTT integration for Wemo Mini Smart Plug?" : "To enable IFTTT integration, go to the IFTTT app or website, search for Wemo, and link your account to create applets for automation.",

"How do I set up a group for Wemo Mini Smart Plugs?" : "Open the Wemo app, go to 'Groups,' and add multiple Smart Plugs to a group for simultaneous control.",

"How do I adjust power-on behavior for Wemo Mini Smart Plug?" : "Open the Wemo app, select your Smart Plug, and go to 'Settings' to set the default behavior when the plug is powered on.",

"How do I use Wemo Mini Smart Plug with a smart hub?" : "Check if your smart hub is compatible with Wemo, then link your account using the hub's app to control the plug.",

"How do I enable cloud access for Wemo Mini Smart Plug?" : "Open the Wemo app, go to 'Settings,' and enable 'Remote Control' to allow cloud access for controlling the plug remotely.",

"How do I control Wemo Mini Smart Plug from a smartwatch?" : "Install the Wemo app on your smartwatch, and use it to control your Wemo Mini Smart Plug directly from your wrist.",

"How do I reset Wi-Fi settings on Wemo Mini Smart Plug?" : "To reset Wi-Fi settings, press and hold the reset button for 10 seconds, then reconnect the plug through the Wemo app.",

"How do I unlink Wemo Mini Smart Plug from Google Home?" : "Open the Google Home app, go to 'Linked Services,' select 'Wemo,' and remove the link to disconnect your Smart Plug.",

"How do I unlink Wemo Mini Smart Plug from Amazon Alexa?" : "Open the Alexa app, go to 'Devices,' select your Smart Plug, and tap 'Remove' to unlink it from Alexa.",

"How do I enable sunrise/sunset scheduling for Wemo Mini Smart Plug?" : "Open the Wemo app, go to 'Rules,' and select 'Sunrise & Sunset' to automatically turn the plug on or off based on local times.",

"How do I set a recurring timer for Wemo Mini Smart Plug?" : "Open the Wemo app, select your Smart Plug, and go to 'Timer' to set a recurring countdown timer.",

"How do I add Wemo Mini Smart Plug to a scene?" : "Open the Wemo app, go to 'Scenes,' and add your Smart Plug to an existing scene for customized automation.",

"How do I enable third-party services for Wemo Mini Smart Plug?" : "Open the Wemo app, go to 'Settings,' and enable third-party services like Alexa, Google Home, or IFTTT.",

"How do I use Wemo Mini Smart Plug with Apple HomeKit?" : "Open the Home app on your iOS device, tap 'Add Accessory,' and scan the HomeKit code found on the Wemo Mini Smart Plug.",

"How do I disconnect Wemo Mini Smart Plug from Wi-Fi?" : "To disconnect, press and hold the reset button for 5 seconds until the LED starts blinking, then remove it from the app.",

"How do I control Wemo Mini Smart Plug with Siri Shortcuts?" : "Open the Shortcuts app on your iOS device, create a new shortcut, and link it to your Wemo Mini Smart Plug via the Wemo app.",

"How do I reset Wemo Mini Smart Plug after a power outage?" : "If the plug doesn't reconnect automatically, press and hold the reset button for 10 seconds to reset and reconnect it.",

"How do I enable notifications for Wemo Mini Smart Plug?" : "Open the Wemo app, go to 'Settings,' and enable notifications to receive alerts about the status of your Smart Plug.",

"How do I control Wemo Mini Smart Plug with a third-party automation system?" : "Ensure compatibility, then link your Wemo Mini Smart Plug with the third-party automation system through their respective app.",

"How do I update multiple Wemo Mini Smart Plugs simultaneously?" : "Open the Wemo app, go to 'Devices,' and check for available firmware updates to apply them to all plugs simultaneously.",

"How do I adjust the LED indicator on Wemo Mini Smart Plug?" : "Open the Wemo app, select your Smart Plug, go to 'Settings,' and adjust the LED indicator's behavior or brightness level.",

"How can I update the firmware for August Smart Lock?" : "To update the firmware, open the August app, go to 'Settings,' select your Smart Lock, and check for available firmware updates. Follow the instructions to complete the update.",

"How do I reset August Smart Lock to factory settings?" : "To reset the August Smart Lock, open the August app, go to 'Settings,' select your lock, and choose 'Factory Reset.' Follow the on-screen instructions.",

"How do I connect August Smart Lock to Wi-Fi?" : "To connect August Smart Lock to Wi-Fi, you need the August Connect or Wi-Fi Bridge. Open the August app, go to 'Set Up Device,' and follow the prompts to connect it to your Wi-Fi network.",

"How do I control August Smart Lock remotely?" : "To control the August Smart Lock remotely, ensure it is connected to Wi-Fi via the August Connect or Wi-Fi Bridge, then use the August app to lock or unlock from anywhere.",

"How do I share access to August Smart Lock with others?" : "Open the August app, select your Smart Lock, go to 'Guest List,' and invite others by entering their email address or phone number.",

"How do I enable Auto-Unlock for August Smart Lock?" : "To enable Auto-Unlock, open the August app, go to 'Settings,' select 'Auto-Unlock,' and toggle it on to unlock the door automatically when you approach.",

"How do I check the battery level of August Smart Lock?" : "Open the August app, select your Smart Lock, and go to 'Settings' to view the current battery level.",

"How do I set up DoorSense with August Smart Lock?" : "To set up DoorSense, follow the in-app setup instructions during installation to position the DoorSense sensor properly and calibrate it.",

"How do I lock and unlock August Smart Lock using voice commands?" : "Link your August Smart Lock to Amazon Alexa, Google Assistant, or Apple HomeKit, then use voice commands like 'Lock the front door.'",

"How do I integrate August Smart Lock with Amazon Alexa?" : "Open the Alexa app, go to 'Devices,' tap on 'Add Device,' and select 'August' to link your account and control the lock using Alexa.",

"How do I enable voice control for August Smart Lock?" : "Open the August app, go to 'Integrations,' and link the lock to your preferred voice assistant like Amazon Alexa, Google Assistant, or Apple HomeKit.",

"How do I update the Wi-Fi settings for August Smart Lock?" : "To update Wi-Fi settings, reset the Wi-Fi Bridge or Connect, then reconnect it through the August app by following the setup instructions.",

"How do I set up Smart Alerts for August Smart Lock?" : "Open the August app, go to 'Settings,' select 'Smart Alerts,' and configure notifications for activities like locking, unlocking, and door status.",

"How do I unlink August Smart Lock from Google Home?" : "Open the Google Home app, go to 'Linked Services,' select 'August,' and remove the link to disconnect your Smart Lock.",

"How do I unlink August Smart Lock from Amazon Alexa?" : "Open the Alexa app, go to 'Devices,' select your Smart Lock, and tap 'Remove' to unlink it from Alexa.",

"How do I add August Smart Lock to a scene?" : "Open the August app, go to 'Scenes,' and add your Smart Lock to an existing scene for customized automation.",

"How do I enable third-party services for August Smart Lock?" : "Open the August app, go to 'Settings,' and enable third-party services like Alexa, Google Home, or IFTTT.",

"How do I calibrate DoorSense for August Smart Lock?" : "Open the August app, go to 'Settings,' select 'DoorSense,' and follow the calibration instructions to ensure accurate door status detection.",

"How do I disconnect August Smart Lock from Wi-Fi?" : "To disconnect, reset the Wi-Fi Bridge or Connect by pressing and holding the reset button, then remove the lock from the app.",

"How do I control August Smart Lock with Siri Shortcuts?" : "Open the Shortcuts app on your iOS device, create a new shortcut, and link it to your August Smart Lock via the August app.",

"How do I update the default lock settings for August Smart Lock?" : "Open the August app, go to 'Settings,' select 'Default Lock Settings,' and adjust the preferences for Auto-Lock and Auto-Unlock.",

"How do I control August Smart Lock with a third-party automation system?" : "Ensure compatibility, then link your August Smart Lock with the third-party automation system through their respective app.",

"How do I add August Smart Lock to my Favorites in the August app?" : "Open the August app, select your Smart Lock, go to 'Settings,' and tap 'Add to Favorites' for quicker access.",

"How do I update multiple August Smart Locks simultaneously?" : "Open the August app, go to 'Devices,' and check for available firmware updates to apply them to all locks simultaneously.",

"How do I adjust the LED indicator on August Smart Lock?" : "Open the August app, select your Smart Lock, go to 'Settings,' and adjust the LED indicator's behavior or brightness level.",

"How do I enable notifications for August Smart Lock?" : "Open the August app, go to 'Settings,' and enable notifications to receive alerts about the status of your Smart Lock.",

"How do I reset August Smart Lock after a power outage?" : "If the lock doesn't reconnect automatically, press and hold the reset button for 10 seconds to reset and reconnect it.",

"How do I link multiple August Smart Locks for simultaneous control?" : "Open the August app, create a group under 'Groups,' and add multiple Smart Locks for simultaneous control.",

"How do I update the home location for August Smart Lock?" : "Open the August app, go to 'Settings,' select 'Home Location,' and update your address information.",

"How can I update the firmware for Arlo Pro?" : "To update the firmware, ensure your Arlo Pro is connected to Wi-Fi. The firmware will be updated automatically when a new version is available.",

"How do I connect Arlo Pro to Wi-Fi?" : "To connect Arlo Pro to Wi-Fi, open the Arlo app, go to 'Devices,' select your camera, and follow the on-screen instructions to connect it to your network.",

"How do I share access to Arlo Pro with others?" : "Open the Arlo app, go to 'Settings,' select 'Grant Access,' and invite others by entering their email address.",

"How do I set up activity zones for Arlo Pro?" : "Open the Arlo app, select your camera, go to 'Settings,' then 'Activity Zones,' and draw zones where you want to monitor motion.",

"How do I enable night vision for Arlo Pro?" : "Open the Arlo app, select your camera, go to 'Settings,' and enable 'Night Vision' for low-light recording.",

"How do I enable two-way audio for Arlo Pro?" : "To enable two-way audio, open the Arlo app, go to live view, and press the microphone icon to talk through the camera.",

"How do I integrate Arlo Pro with Amazon Alexa?" : "Open the Alexa app, go to 'Devices,' tap on 'Add Device,' and select 'Arlo' to link your account and control the camera using Alexa.",

"How do I update the Wi-Fi settings for Arlo Pro?" : "To update Wi-Fi settings, remove the camera from your account, then reconnect it through the Arlo app by following the setup instructions.",

"How do I delete an Arlo Pro camera from the app?" : "Open the Arlo app, select your camera, go to 'Settings,' and tap 'Remove Device.'",

"How do I enable geofencing for Arlo Pro?" : "Open the Arlo app, go to 'Mode,' select your camera, and enable 'Geofencing' to automatically arm or disarm based on your location.",

"How do I rename my Arlo Pro camera?" : "Open the Arlo app, select your camera, go to 'Settings,' and tap on the name to edit it.",

"How do I enable push notifications for Arlo Pro?" : "Open the Arlo app, go to 'Settings,' select 'Notifications,' and enable push notifications for motion or sound alerts.",

"How do I use Arlo Pro with Apple HomeKit?" : "Open the Home app on your iOS device, tap 'Add Accessory,' and scan the HomeKit code found on the Arlo Pro base station to integrate it.",

"How do I reset Wi-Fi settings on Arlo Pro?" : "To reset Wi-Fi settings, remove the camera from the Arlo app, then reconnect it by following the setup process.",

"How do I unlink Arlo Pro from Google Home?" : "Open the Google Home app, go to 'Linked Services,' select 'Arlo,' and remove the link to disconnect your camera.",

"How do I set up a schedule for Arlo Pro?" : "Open the Arlo app, go to 'Mode,' select 'Schedule,' and set up a custom schedule to arm or disarm your camera.",

"How do I check the activity log for Arlo Pro?" : "Open the Arlo app, select your camera, and go to 'Library' to view the log of recorded events.",

"How do I adjust video quality for Arlo Pro?" : "Open the Arlo app, select your camera, go to 'Settings,' then 'Video Settings,' and adjust the video quality to your preference.",

"How do I enable continuous recording for Arlo Pro?" : "To enable continuous recording, subscribe to an Arlo CVR (Continuous Video Recording) plan and enable it in the app.",

"How do I disconnect Arlo Pro from Wi-Fi?" : "To disconnect, remove the camera from the Arlo app, and reset the base station if needed.",

"How do I update multiple Arlo Pro cameras simultaneously?" : "Open the Arlo app, go to 'Devices,' and check for available firmware updates to apply them to all cameras simultaneously.",

"How do I adjust the LED indicator on Arlo Pro?" : "Open the Arlo app, select your camera, go to 'Settings,' and adjust the LED indicator's behavior or brightness level.",

"How do I enable notifications for Arlo Pro?" : "Open the Arlo app, go to 'Settings,' and enable notifications to receive alerts about motion, sound, and other events.",

"How do I link multiple Arlo Pro cameras for simultaneous control?" : "Open the Arlo app, create a group under 'Groups,' and add multiple cameras for simultaneous control.",

"How do I set up local storage for Arlo Pro?" : "Connect a USB drive to the Arlo base station, then enable local storage in the Arlo app under 'Storage Settings.'",

"How do I update the home location for Arlo Pro?" : "Open the Arlo app, go to 'Settings,' select 'Home Location,' and update your address information.",

"How can I update the firmware for Ring Video Doorbell?" : "To update the firmware, ensure your Ring Video Doorbell is connected to Wi-Fi. The firmware will be updated automatically when a new version is available.",

"How do I reset Ring Video Doorbell to factory settings?" : "To reset the Ring Video Doorbell, press and hold the setup button for 15 seconds until the light flashes, indicating a reset.",

"How do I connect Ring Video Doorbell to Wi-Fi?" : "To connect Ring Video Doorbell to Wi-Fi, open the Ring app, tap 'Set Up Device,' and follow the on-screen instructions to connect it to your network.",

"How do I share access to Ring Video Doorbell with others?" : "Open the Ring app, go to 'Settings,' select 'Shared Users,' and invite others by entering their email address.",

"How do I check the battery level of Ring Video Doorbell?" : "Open the Ring app, select your doorbell, and check the battery level displayed in the device settings.",

"How do I enable night vision for Ring Video Doorbell?" : "Night vision is enabled by default on the Ring Video Doorbell. It will automatically activate in low-light conditions.",

"How do I enable two-way audio for Ring Video Doorbell?" : "To enable two-way audio, open the Ring app, go to live view, and press the microphone icon to talk to visitors.",

"How do I integrate Ring Video Doorbell with Google Home?" : "Open the Google Home app, tap 'Add Device,' select 'Works with Google,' and link your Ring account to control the doorbell via Google Home.",

"How do I integrate Ring Video Doorbell with Amazon Alexa?" : "Open the Alexa app, go to 'Devices,' tap on 'Add Device,' and select 'Ring' to link your account and control the doorbell using Alexa.",

"How do I enable voice control for Ring Video Doorbell?" : "Link your Ring Video Doorbell to Amazon Alexa or Google Assistant to use voice commands for controlling the doorbell.",

"How do I update the Wi-Fi settings for Ring Video Doorbell?" : "To update Wi-Fi settings, remove the doorbell from your account, then reconnect it through the Ring app by following the setup instructions.",

"How do I rename my Ring Video Doorbell?" : "Open the Ring app, select your doorbell, go to 'Device Settings,' and tap on the name to edit it.",

"How do I adjust motion sensitivity for Ring Video Doorbell?" : "Open the Ring app, select your doorbell, go to 'Motion Settings,' then 'Motion Sensitivity,' and adjust the sensitivity level.",

"How do I use Ring Video Doorbell with Apple HomeKit?" : "Ring Video Doorbell does not have native support for Apple HomeKit, but you can use third-party solutions like Homebridge to integrate it.",

"How do I reset Wi-Fi settings on Ring Video Doorbell?" : "To reset Wi-Fi settings, press and hold the setup button until the light starts flashing, then reconnect the doorbell through the Ring app.",

"How do I unlink Ring Video Doorbell from Amazon Alexa?" : "Open the Alexa app, go to 'Devices,' select your doorbell, and tap 'Remove' to unlink it from Alexa.",

"How do I add Ring Video Doorbell to a scene?" : "Open the Ring app, go to 'Modes,' and add your doorbell to an existing mode for customized automation.",

"How do I check the activity log for Ring Video Doorbell?" : "Open the Ring app, select your doorbell, and go to 'Event History' to view the log of recorded events.",

"How do I enable snapshot capture for Ring Video Doorbell?" : "Open the Ring app, select your doorbell, go to 'Device Settings,' then 'Snapshot Capture,' and enable it to take periodic snapshots.",

"How do I control Ring Video Doorbell with Siri Shortcuts?" : "Open the Shortcuts app on your iOS device, create a new shortcut, and link it to your Ring Video Doorbell via the Ring app.",

"How do I control Ring Video Doorbell with a third-party automation system?" : "Ensure compatibility, then link your Ring Video Doorbell with the third-party automation system through their respective app.",

"How do I add Ring Video Doorbell to my Favorites in the Ring app?" : "Open the Ring app, select your doorbell, go to 'Settings,' and tap 'Add to Favorites' for quicker access.",

"How do I adjust the LED indicator on Ring Video Doorbell?" : "Open the Ring app, select your doorbell, go to 'Device Settings,' and adjust the LED indicator's behavior or brightness level.",

"How do I enable notifications for Ring Video Doorbell?" : "Open the Ring app, go to 'Settings,' and enable notifications to receive alerts about motion, rings, and other events.",

"How do I disable audio recording on Ring Video Doorbell?" : "Open the Ring app, select your doorbell, go to 'Audio Settings,' and toggle off the audio recording option.",

"How can I update the firmware for Samsung Family Hub Refrigerator?" : "To update the firmware, connect the refrigerator to Wi-Fi, open the Family Hub app, go to 'Settings,' and select 'Software Update' to check for available updates.",

"How do I reset Samsung Family Hub Refrigerator to factory settings?" : "To reset the Samsung Family Hub Refrigerator, open the Family Hub screen, go to 'Settings,' and select 'Factory Data Reset.'",

"How do I set up Family Board on Samsung Family Hub Refrigerator?" : "Open the Family Hub screen, select 'Family Board,' and follow the prompts to personalize the board with photos, notes, and stickers.",

"How do I add a family member to the Samsung Family Hub account?" : "Open the Family Hub app, go to 'Settings,' select 'Users,' and add a new family member by entering their email address.",

"How do I enable Bixby on Samsung Family Hub Refrigerator?" : "Open the Family Hub screen, go to 'Settings,' select 'Voice Assistant,' and enable Bixby for voice commands.",

"How do I set reminders on Samsung Family Hub Refrigerator?" : "To set reminders, go to the Family Hub screen, select 'Reminders,' and enter the details of your reminder, including date and time.",

"How do I connect Samsung Family Hub Refrigerator to SmartThings?" : "Open the SmartThings app, tap 'Add Device,' select 'Refrigerator,' and follow the prompts to link your Samsung Family Hub Refrigerator.",

"How do I enable voice commands for Samsung Family Hub Refrigerator?" : "To enable voice commands, open the Family Hub screen, go to 'Settings,' select 'Voice Control,' and turn on Bixby voice assistant.",

"How do I add an app to the home screen on Samsung Family Hub Refrigerator?" : "Open the Family Hub screen, go to 'Apps,' select the app you want to add, and tap 'Add to Home Screen.'",

"How do I update the shopping list on Samsung Family Hub Refrigerator?" : "To update the shopping list, open the Family Hub screen, select 'Shopping List,' and add or remove items as needed.",

"How do I use the whiteboard feature on Samsung Family Hub Refrigerator?" : "Open the Family Hub screen, go to 'Whiteboard,' and use your finger or stylus to write notes, draw pictures, or add stickers.",

"How do I play music on Samsung Family Hub Refrigerator?" : "Open the Family Hub screen, go to 'Music,' select your preferred streaming service, and start playing music.",

"How do I connect Samsung Family Hub Refrigerator to Amazon Alexa?" : "Open the Alexa app, tap 'Add Device,' select 'Refrigerator,' and follow the prompts to link your Samsung Family Hub.",

"How do I enable energy-saving mode on Samsung Family Hub Refrigerator?" : "Open the Family Hub screen, go to 'Settings,' select 'Energy Saving,' and enable the mode to reduce power consumption.",

"How do I connect Samsung Family Hub Refrigerator to Bluetooth speakers?" : "Open the Family Hub screen, go to 'Settings,' select 'Bluetooth,' and pair with your Bluetooth speakers.",

"How do I add a calendar event on Samsung Family Hub Refrigerator?" : "Open the Family Hub screen, go to 'Calendar,' and tap 'Add Event' to input the event details.",

"How do I change the time and date on Samsung Family Hub Refrigerator?" : "Open the Family Hub screen, go to 'Settings,' select 'Time and Date,' and adjust the settings as needed.",

"How do I enable notifications for Samsung Family Hub Refrigerator?" : "Open the Family Hub app on your smartphone, go to 'Settings,' select 'Notifications,' and enable the alerts you want to receive.",

"How do I connect Samsung Family Hub Refrigerator to a smart TV?" : "Open the Family Hub screen, go to 'Smart View,' select your smart TV, and follow the prompts to connect.",

"How do I lock the screen of Samsung Family Hub Refrigerator?" : "Open the Family Hub screen, go to 'Settings,' select 'Screen Lock,' and set a PIN to lock the screen.",

"How do I adjust the ice maker settings on Samsung Family Hub Refrigerator?" : "Open the Family Hub screen, go to 'Fridge Manager,' select 'Ice Maker,' and adjust the settings as needed.",

"How do I disable notifications for Samsung Family Hub Refrigerator?" : "Open the Family Hub app on your smartphone, go to 'Settings,' select 'Notifications,' and disable the alerts you don't want to receive.",

"How do I change the language on Samsung Family Hub Refrigerator?" : "Open the Family Hub screen, go to 'Settings,' select 'Language,' and choose your preferred language.",

"How do I set a vacation mode for Samsung Family Hub Refrigerator?" : "Open the Family Hub screen, go to 'Settings,' select 'Vacation Mode,' and enable it to conserve energy while you're away.",

"How do I delete a user profile on Samsung Family Hub Refrigerator?" : "Open the Family Hub screen, go to 'Settings,' select 'Users,' and choose the profile you want to delete.",

"How do I connect Samsung Family Hub Refrigerator to a doorbell camera?" : "Open the SmartThings app, add your doorbell camera, and link it to the Family Hub Refrigerator for live video feed.",

"How do I turn off the screen on Samsung Family Hub Refrigerator?" : "Open the Family Hub screen, go to 'Settings,' select 'Display,' and choose 'Turn Off Screen' to save energy.",

"How do I view recent updates on Samsung Family Hub Refrigerator?" : "Open the Family Hub screen, go to 'Settings,' and select 'About Device' to view recent software updates and features.",

"How do I set up multiple calendars on Samsung Family Hub Refrigerator?" : "Open the Family Hub screen, go to 'Calendar,' and link multiple Google or Microsoft calendars to view them in one place.",

"How do I control Samsung Family Hub Refrigerator with SmartThings?" : "Open the SmartThings app, select your refrigerator, and use the app to adjust settings, view status, and control features remotely.",

"How do I adjust the brightness of the screen on Samsung Family Hub Refrigerator?" : "Open the Family Hub screen, go to 'Settings,' select 'Display,' and adjust the brightness level to your preference.",

"How do I install new apps on Samsung Family Hub Refrigerator?" : "Open the Family Hub screen, go to 'Apps,' tap 'App Store,' and browse or search for new apps to install.",

"How do I delete an app from Samsung Family Hub Refrigerator?" : "Open the Family Hub screen, go to 'Apps,' select the app you want to delete, and tap 'Uninstall.'",

"How do I set up Spotify on Samsung Family Hub Refrigerator?" : "Open the Family Hub screen, go to 'Music,' select 'Spotify,' and log in to your account to start playing music.",

"How can I update the software on my Apple Watch?" : "To update the software, open the Watch app on your iPhone, go to 'General,' select 'Software Update,' and follow the prompts to install the latest version.",

"How do I reset my Apple Watch to factory settings?" : "To reset your Apple Watch, go to 'Settings' on the watch, select 'General,' then 'Reset,' and choose 'Erase All Content and Settings.'",

"How do I pair my Apple Watch with my iPhone?" : "To pair your Apple Watch with your iPhone, open the Watch app on your iPhone, then follow the on-screen instructions to complete the pairing process.",

"How do I change the watch face on my Apple Watch?" : "To change the watch face, press and hold the current watch face, swipe left or right to select a new one, or tap '+' to add a new watch face.",

"How do I take a screenshot on my Apple Watch?" : "To take a screenshot, press the Digital Crown and the side button at the same time. Make sure screenshot functionality is enabled in the Watch app under 'General.'",

"How do I use Siri on my Apple Watch?" : "To use Siri, press and hold the Digital Crown or raise your wrist and say 'Hey Siri,' then speak your request.",

"How do I track my workouts using Apple Watch?" : "To track a workout, open the 'Workout' app on your Apple Watch, select your desired activity, and tap 'Start.'",

"How do I set up Apple Pay on my Apple Watch?" : "To set up Apple Pay, open the Watch app on your iPhone, go to 'Wallet & Apple Pay,' and follow the prompts to add a new card.",

"How do I enable Fall Detection on my Apple Watch?" : "To enable Fall Detection, open the Watch app on your iPhone, go to 'Emergency SOS,' and toggle on 'Fall Detection.'",

"How do I customize notifications on my Apple Watch?" : "To customize notifications, open the Watch app on your iPhone, go to 'Notifications,' and select which apps you want to receive notifications from.",

"How do I track my sleep using Apple Watch?" : "To track your sleep, open the 'Sleep' app on your Apple Watch, set your sleep schedule, and wear the watch to bed to monitor your sleep.",

"How do I change the passcode on my Apple Watch?" : "To change the passcode, open 'Settings' on your Apple Watch, go to 'Passcode,' and select 'Change Passcode.'",

"How do I enable Theater Mode on my Apple Watch?" : "To enable Theater Mode, swipe up from the bottom of the watch face to open Control Center, then tap the Theater Mode icon (two masks).",

"How do I use the ECG feature on Apple Watch?" : "To use the ECG feature, open the 'ECG' app on your Apple Watch, rest your arm on a table, and hold your finger on the Digital Crown for 30 seconds.",

"How do I update apps on my Apple Watch?" : "To update apps, open the Watch app on your iPhone, go to 'App Store,' and select 'Updates' to install available updates for your watch apps.",

"How do I find my iPhone using Apple Watch?" : "To find your iPhone, swipe up from the bottom of the watch face to open Control Center, then tap the 'Ping iPhone' button.",

"How do I use Apple Watch to make phone calls?" : "To make phone calls, open the 'Phone' app on your Apple Watch, select a contact, and tap the phone icon to initiate a call.",

"How do I customize the Dock on my Apple Watch?" : "To customize the Dock, open the Watch app on your iPhone, go to 'Dock,' and select 'Favorites' to choose which apps appear in the Dock.",

"How do I use Apple Watch to control music playback?" : "To control music playback, open the 'Now Playing' app on your Apple Watch, or use the Music app to play, pause, or skip tracks.",

"How do I silence my Apple Watch?" : "To silence your Apple Watch, swipe up from the bottom of the watch face to open Control Center, then tap the bell icon to enable Silent Mode.",

"How do I use the Timer app on my Apple Watch?" : "To use the Timer app, open 'Timer' on your Apple Watch, select a preset time or set a custom duration, and tap 'Start.'",

"How do I enable Activity Sharing on my Apple Watch?" : "To enable Activity Sharing, open the Activity app on your Apple Watch, swipe left, tap 'Add Friend,' and select a contact to share your activity with.",

"How do I delete an app from my Apple Watch?" : "To delete an app, press and hold the app icon on the watch face, tap the 'X' on the app you want to delete, then confirm.",

"How do I check my daily activity on Apple Watch?" : "To check your daily activity, open the 'Activity' app on your Apple Watch to view your Move, Exercise, and Stand rings.",

"How do I use Apple Watch for navigation?" : "To use navigation, open the 'Maps' app on your Apple Watch, search for a destination, and follow the directions provided on the watch.",

"How do I use the Walkie-Talkie feature on Apple Watch?" : "To use Walkie-Talkie, open the 'Walkie-Talkie' app on your Apple Watch, select a contact, and press and hold the 'Talk' button to communicate.",

"How do I locate my Apple Watch if it's lost?" : "To locate your Apple Watch, open the 'Find My' app on your iPhone, select 'Devices,' and choose your Apple Watch to view its location.",

"How do I enable Noise app notifications on my Apple Watch?" : "To enable Noise app notifications, open the Watch app on your iPhone, go to 'Noise,' and set the decibel level for notifications.",

"How do I use the Compass app on Apple Watch?" : "To use the Compass app, open the 'Compass' app on your Apple Watch to determine your direction, elevation, and coordinates.",

"How do I customize the Control Center on my Apple Watch?" : "To customize the Control Center, swipe up from the watch face, scroll to the bottom, tap 'Edit,' and rearrange or remove controls.",

"How do I track my menstrual cycle using Apple Watch?" : "To track your menstrual cycle, open the 'Cycle Tracking' app on your Apple Watch and log your period and symptoms.",

"How do I rearrange apps on my Apple Watch home screen?" : "To rearrange apps, press and hold an app icon until they jiggle, then drag them to your desired position.",

"How do I use Apple Watch to unlock my Mac?" : "To use your Apple Watch to unlock your Mac, open 'System Preferences' on your Mac, go to 'Security & Privacy,' and enable 'Allow your Apple Watch to unlock your Mac.'",

"How do I update the firmware on Fitbit Charge?" : "To update the firmware, open the Fitbit app on your phone, tap on your profile picture, select your Fitbit Charge, and follow the prompts to update the firmware if an update is available.",

"How do I pair my Fitbit Charge with my smartphone?" : "To pair your Fitbit Charge, open the Fitbit app on your smartphone, tap 'Set Up a Device,' and follow the on-screen instructions to complete the pairing process.",

"How do I track workouts using Fitbit Charge?" : "To track workouts, open the 'Exercise' app on your Fitbit Charge, select the desired workout, and press the button to start tracking.",

"How do I view my daily activity on Fitbit Charge?" : "To view your daily activity, swipe up on the clock face of your Fitbit Charge to see your step count, distance, calories burned, and more.",

"How do I customize notifications on Fitbit Charge?" : "To customize notifications, open the Fitbit app, tap on your profile picture, select your Fitbit Charge, and go to 'Notifications' to choose which alerts you want to receive.",

"How do I track my sleep with Fitbit Charge?" : "To track your sleep, wear your Fitbit Charge to bed, and open the Fitbit app in the morning to view your sleep stats.",

"How do I enable Do Not Disturb mode on Fitbit Charge?" : "To enable Do Not Disturb mode, swipe down on the clock face of your Fitbit Charge and tap the 'Do Not Disturb' icon.",

"How do I check the battery level of my Fitbit Charge?" : "To check the battery level, swipe down on the clock face of your Fitbit Charge or open the Fitbit app on your smartphone.",

"How do I enable water lock on Fitbit Charge?" : "To enable water lock, press and hold the button on your Fitbit Charge until you see the water lock icon, then tap to enable it.",

"How do I clean my Fitbit Charge?" : "To clean your Fitbit Charge, use a soft cloth with a small amount of water. Avoid using soaps or harsh cleaning agents.",

"How do I use Fitbit Charge to track my menstrual cycle?" : "To track your menstrual cycle, open the Fitbit app, go to 'Discover,' select 'Health & Fitness Stats,' and tap 'Menstrual Health Tracking' to log your cycle.",

"How do I enable reminders to move on Fitbit Charge?" : "To enable reminders to move, open the Fitbit app, tap on your profile picture, select your Fitbit Charge, and toggle on 'Reminders to Move.'",

"How do I adjust brightness on Fitbit Charge?" : "To adjust brightness, open the 'Settings' app on your Fitbit Charge and select 'Brightness' to choose between dim, normal, or max.",

"How do I track my heart rate zones on Fitbit Charge?" : "To track your heart rate zones, start a workout, and check the Fitbit app afterward to see time spent in different heart rate zones.",

"How do I disable notifications on Fitbit Charge?" : "To disable notifications, swipe down on the clock face of your Fitbit Charge and toggle off the 'Notifications' icon.",

"How do I use Fitbit Charge to control music playback?" : "To control music playback, open the 'Settings' app on your Fitbit Charge, and enable 'Music Control.' Make sure your phone is nearby.",

"How do I set a goal for my steps on Fitbit Charge?" : "To set a step goal, open the Fitbit app, go to 'Activity & Wellness,' select 'Daily Goals,' and set your desired step count goal.",

"How do I silence my Fitbit Charge?" : "To silence your Fitbit Charge, swipe down on the clock face and tap the 'Do Not Disturb' icon to mute notifications.",

"How do I restart my Fitbit Charge?" : "To restart your Fitbit Charge, press and hold the button on the side of the tracker until the Fitbit logo appears, then release.",

"How do I enable GPS on Fitbit Charge?" : "To enable GPS, open the Fitbit app, select your Fitbit Charge, and toggle on 'Connected GPS.' Ensure your phone's GPS is also enabled.",

"How do I log food intake using Fitbit Charge?" : "To log food intake, open the Fitbit app, go to 'Discover,' select 'Health & Fitness Stats,' and tap 'Food' to log your meals.",

"How do I use Fitbit Charge to monitor stress?" : "To monitor stress, open the Fitbit app, go to 'Discover,' select 'Mindfulness,' and follow the guided breathing sessions.",

"How do I find my phone using Fitbit Charge?" : "To find your phone, swipe down on the clock face of your Fitbit Charge and tap the 'Find Phone' icon.",

"How do I use Fitbit Charge to unlock my computer?" : "Fitbit Charge does not support unlocking computers directly, but you can use third-party apps like Fitbit Connect for this feature.",

"How do I enable Quick View on Fitbit Charge?" : "To enable Quick View, open the Fitbit app, tap on your profile picture, select your Fitbit Charge, and toggle on 'Quick View.'",

"How do I set a hydration goal on Fitbit Charge?" : "To set a hydration goal, open the Fitbit app, go to 'Discover,' select 'Health & Fitness Stats,' tap 'Water,' and set your daily goal.",

"How do I customize my Fitbit Charge display settings?" : "To customize display settings, open the Fitbit app, tap on your profile picture, select your Fitbit Charge, and go to 'Settings' to adjust screen orientation and other options.",

"How do I disable screen wake on Fitbit Charge?" : "To disable screen wake, swipe down on the clock face of your Fitbit Charge and toggle off the 'Screen Wake' icon.",

"How do I view notifications on Fitbit Charge?" : "To view notifications, swipe down on the clock face of your Fitbit Charge to see incoming messages and alerts.",

"How do I pair Withings Body+ Smart Scale with my smartphone?" : "To pair the scale, open the Withings Health Mate app, tap 'Add a Device,' select 'Body+,' and follow the on-screen instructions to complete the pairing.",

"How do I add a user to Withings Body+ Smart Scale?" : "Open the Health Mate app, go to 'Users,' tap 'Add a User,' and follow the prompts to add a new user to your Body+ Smart Scale.",

"How do I enable Wi-Fi synchronization on Withings Body+ Smart Scale?" : "To enable Wi-Fi synchronization, open the Health Mate app, go to 'Devices,' select your scale, and ensure Wi-Fi is connected for automatic data sync.",

"How do I use Withings Body+ Smart Scale to measure body composition?" : "To measure body composition, step on the scale with bare feet. The scale will measure weight, body fat percentage, muscle mass, and more.",

"How do I share my weight data from Withings Body+ Smart Scale?" : "To share your weight data, open the Health Mate app, go to 'Dashboard,' tap 'Weight,' and select 'Share' to send your data to others.",

"How do I update the profile information for a user on Withings Body+ Smart Scale?" : "Open the Health Mate app, go to 'Profile,' select the user, and update their personal information as needed.",

"How do I disable Wi-Fi on Withings Body+ Smart Scale?" : "To disable Wi-Fi, open the Health Mate app, select your scale, and toggle off Wi-Fi synchronization in the settings.",

"How do I enable athlete mode on Withings Body+ Smart Scale?" : "To enable athlete mode, open the Health Mate app, go to 'Profile,' select 'Athlete Mode,' and toggle it on for more accurate body composition measurements.",

"How do I enable weather display on Withings Body+ Smart Scale?" : "To enable the weather display, open the Health Mate app, select your Body+ scale, and toggle on the 'Weather Forecast' option.",

"How do I troubleshoot connectivity issues with Withings Body+ Smart Scale?" : "If experiencing connectivity issues, make sure the scale is within Wi-Fi range, restart your router, and reattempt connecting through the Health Mate app.",

"How do I delete a user from Withings Body+ Smart Scale?" : "To delete a user, open the Health Mate app, go to 'Users,' select the user you want to remove, and tap 'Delete User.'",

"How do I view my BMI on Withings Body+ Smart Scale?" : "To view your BMI, step on the scale to weigh yourself, and the BMI will be displayed. You can also view it in the Health Mate app.",

"How do I remove Withings Body+ Smart Scale from my account?" : "Open the Health Mate app, go to 'Devices,' select your Body+ scale, and tap 'Remove This Product.'",

"How do I clean my Withings Body+ Smart Scale?" : "To clean the scale, use a soft cloth slightly dampened with water. Avoid using harsh chemicals or submerging the scale in water.",

"How do I check the battery level of Withings Body+ Smart Scale?" : "To check the battery level, open the Health Mate app, go to 'Devices,' and select your Body+ scale to view the battery status.",

"How do I enable automatic recognition for multiple users on Withings Body+ Smart Scale?" : "To enable automatic recognition, open the Health Mate app, select your scale, and ensure that each user has their profile set up correctly.",

"How do I disable body fat measurement on Withings Body+ Smart Scale?" : "To disable body fat measurement, open the Health Mate app, select your scale, and toggle off body composition measurements.",

"How do I set up reminders for weigh-ins on Withings Body+ Smart Scale?" : "To set up reminders, open the Health Mate app, go to 'Reminders,' and set a daily or weekly reminder to weigh yourself.",

"How do I reset the weight history on Withings Body+ Smart Scale?" : "To reset weight history, open the Health Mate app, go to 'Profile,' select your data, and delete the weight entries you want to remove.",

"How do I weigh myself in pregnancy mode on Withings Body+ Smart Scale?" : "Ensure pregnancy mode is enabled in the Health Mate app, then step on the scale to weigh yourself and see adjusted metrics.",

"How do I use Withings Body+ Smart Scale to track muscle mass?" : "Step on the scale with bare feet, and the scale will automatically measure and display your muscle mass.",

"How do I connect Withings Body+ Smart Scale to Apple Health?" : "To connect to Apple Health, open the Health Mate app, go to 'Profile,' select 'Partners,' and link your Apple Health account.",

"How do I perform a firmware update on Withings Body+ Smart Scale?" : "To perform a firmware update, open the Health Mate app, select your scale, and follow the prompts if a firmware update is available.",

"How do I change the language on Withings Body+ Smart Scale?" : "The language on the Body+ scale is automatically set based on the language of your paired smartphone. Update your phone's language to change it.",

"How do I set up data sharing for Withings Body+ Smart Scale with my doctor?" : "Open the Health Mate app, go to 'Profile,' tap 'Data Sharing,' and set up data sharing with your doctor via email or compatible health platforms.",

"How do I enable athlete mode for accurate body composition on Withings Body+ Smart Scale?" : "Open the Health Mate app, go to 'Profile,' select 'Athlete Mode,' and toggle it on to improve the accuracy of body composition measurements.",

"How do I update the firmware on Withings Body+ Smart Scale?" : "To update the firmware, open the Withings Health Mate app, go to 'Devices,' select your Body+ Smart Scale, and follow the prompts if an update is available.",

"How do I pair Withings Body+ Smart Scale with my smartphone?" : "To pair the scale, open the Withings Health Mate app, tap 'Add a Device,' select 'Body+,' and follow the on-screen instructions to complete the pairing.",

"How do I change the units of measurement on Withings Body+ Smart Scale?" : "To change the units of measurement, open the Health Mate app, select your Body+ scale, and choose between kg, lb, or st in the 'Device Settings.'",

"How do I view my weight history using Withings Body+ Smart Scale?" : "To view your weight history, open the Withings Health Mate app, go to 'Dashboard,' and select 'Weight' to see your recorded data over time.",

"How do I enable Wi-Fi synchronization on Withings Body+ Smart Scale?" : "To enable Wi-Fi synchronization, open the Health Mate app, go to 'Devices,' select your scale, and ensure Wi-Fi is connected for automatic data sync.",

"How do I calibrate Withings Body+ Smart Scale?" : "To calibrate the scale, step on the scale briefly and then step off. Wait for it to display '0.0' before stepping back on to weigh yourself.",

"How do I enable pregnancy mode on Withings Body+ Smart Scale?" : "To enable pregnancy mode, open the Health Mate app, go to 'Profile,' select 'Pregnancy Mode,' and follow the instructions to activate it.",

"How do I share my weight data from Withings Body+ Smart Scale?" : "To share your weight data, open the Health Mate app, go to 'Dashboard,' tap 'Weight,' and select 'Share' to send your data to others.",

"How do I set up baby mode on Withings Body+ Smart Scale?" : "To set up baby mode, open the Health Mate app, go to 'Profile,' select 'Baby Mode,' and follow the prompts to weigh your baby accurately.",

"How do I customize the display on Withings Body+ Smart Scale?" : "Open the Health Mate app, go to 'Devices,' select your scale, and customize the metrics displayed during weigh-ins.",

"How do I enable weather display on Withings Body+ Smart Scale?" : "To enable the weather display, open the Health Mate app, select your Body+ scale, and toggle on the 'Weather Forecast' option.",

"How do I troubleshoot connectivity issues with Withings Body+ Smart Scale?" : "If experiencing connectivity issues, make sure the scale is within Wi-Fi range, restart your router, and reattempt connecting through the Health Mate app.",

"How do I delete a user from Withings Body+ Smart Scale?" : "To delete a user, open the Health Mate app, go to 'Users,' select the user you want to remove, and tap 'Delete User.'",

"How do I view my BMI on Withings Body+ Smart Scale?" : "To view your BMI, step on the scale to weigh yourself, and the BMI will be displayed. You can also view it in the Health Mate app.",

"How do I remove Withings Body+ Smart Scale from my account?" : "Open the Health Mate app, go to 'Devices,' select your Body+ scale, and tap 'Remove This Product.'",

"How do I enable guest mode on Withings Body+ Smart Scale?" : "To enable guest mode, open the Health Mate app, select your scale, and toggle on 'Guest Mode' to allow others to use the scale without saving data.",

"How do I synchronize data manually on Withings Body+ Smart Scale?" : "To synchronize data manually, step on the scale to trigger a weigh-in, and ensure your phone is nearby with Bluetooth enabled.",

"How do I clean my Withings Body+ Smart Scale?" : "To clean the scale, use a soft cloth slightly dampened with water. Avoid using harsh chemicals or submerging the scale in water.",

"How do I check the battery level of Withings Body+ Smart Scale?" : "To check the battery level, open the Health Mate app, go to 'Devices,' and select your Body+ scale to view the battery status.",

"How do I link Withings Body+ Smart Scale to Google Fit?" : "To link Google Fit, open the Health Mate app, go to 'Profile,' select 'Partners,' and link your Google Fit account.",

"How do I enable automatic recognition for multiple users on Withings Body+ Smart Scale?" : "To enable automatic recognition, open the Health Mate app, select your scale, and ensure that each user has their profile set up correctly.",

"How do I disable body fat measurement on Withings Body+ Smart Scale?" : "To disable body fat measurement, open the Health Mate app, select your scale, and toggle off body composition measurements.",

"How do I set up reminders for weigh-ins on Withings Body+ Smart Scale?" : "To set up reminders, open the Health Mate app, go to 'Reminders,' and set a daily or weekly reminder to weigh yourself.",

"How do I reset the weight history on Withings Body+ Smart Scale?" : "To reset weight history, open the Health Mate app, go to 'Profile,' select your data, and delete the weight entries you want to remove.",

"How do I switch between Bluetooth and Wi-Fi on Withings Body+ Smart Scale?" : "Open the Health Mate app, select your scale, and choose either Bluetooth or Wi-Fi for data synchronization.",

"How do I weigh myself in pregnancy mode on Withings Body+ Smart Scale?" : "Ensure pregnancy mode is enabled in the Health Mate app, then step on the scale to weigh yourself and see adjusted metrics.",

"How do I connect Withings Body+ Smart Scale to Apple Health?" : "To connect to Apple Health, open the Health Mate app, go to 'Profile,' select 'Partners,' and link your Apple Health account.",

"How do I perform a firmware update on Withings Body+ Smart Scale?" : "To perform a firmware update, open the Health Mate app, select your scale, and follow the prompts if a firmware update is available.",

"How do I change the language on Withings Body+ Smart Scale?" : "The language on the Body+ scale is automatically set based on the language of your paired smartphone. Update your phone's language to change it.",

"How do I enable athlete mode for accurate body composition on Withings Body+ Smart Scale?" : "Open the Health Mate app, go to 'Profile,' select 'Athlete Mode,' and toggle it on to improve the accuracy of body composition measurements.",

"How do I install SimpliSafe door/window sensors?" : "To install door/window sensors, peel off the adhesive backing, place one part on the door or window, and the other part on the frame, making sure they align correctly.",

"How do I connect SimpliSafe to Wi-Fi?" : "To connect your SimpliSafe system to Wi-Fi, press the menu button on the keypad, go to 'System Settings,' and select 'Wi-Fi' to enter your network credentials.",

"How do I disarm SimpliSafe Home Security system?" : "To disarm the system, press the 'Off' button on the keypad or use the SimpliSafe app to turn off the security features.",

"How do I set up a PIN for SimpliSafe Home Security system?" : "To set up a PIN, press the menu button on the keypad, navigate to 'System Settings,' select 'PINs,' and follow the prompts to create or update your PIN.",

"How do I test SimpliSafe sensors?" : "To test sensors, press the menu button on the keypad, go to 'System Settings,' select 'Test Mode,' and trigger each sensor to ensure they are working properly.",

"How do I set up SimpliSafe camera?" : "To set up a SimpliSafe camera, plug it in, open the SimpliSafe app, select 'Set Up a Camera,' and follow the prompts to connect it to your Wi-Fi network.",

"How do I change the volume of the SimpliSafe base station?" : "To change the volume, press the menu button on the keypad, go to 'System Settings,' select 'Base Station Volume,' and adjust it as needed.",

"How do I replace the battery in SimpliSafe sensors?" : "To replace the battery, remove the sensor from its mount, open the back cover, and replace the battery with a new one of the same type.",

"How do I enable SimpliSafe Away mode with a delay?" : "To enable Away mode with a delay, press 'Away' on the keypad and wait for the countdown to finish, or customize the delay time in the app under 'System Settings.'",

"How do I check for firmware updates on SimpliSafe devices?" : "To check for firmware updates, open the SimpliSafe app, go to 'System Settings,' and select 'Check for Updates.' Follow the prompts if an update is available.",

"How do I add a new device to my SimpliSafe system?" : "To add a new device, press the menu button on the keypad, go to 'Devices,' select 'Add Device,' and follow the prompts to add and configure the new component.",

"How do I set up SimpliSafe Panic Button?" : "To set up the Panic Button, mount it in a convenient location, press the menu button on the keypad, go to 'Devices,' select 'Add Device,' and follow the prompts.",

"How do I enable Duress PIN on SimpliSafe?" : "To enable a Duress PIN, press the menu button on the keypad, go to 'System Settings,' select 'PINs,' and set up a PIN that will silently alert the monitoring service in an emergency.",

"How do I adjust the entry delay for SimpliSafe?" : "To adjust the entry delay, press the menu button on the keypad, go to 'System Settings,' select 'Entry Delay,' and set the desired time.",

"How do I remove a device from my SimpliSafe system?" : "To remove a device, press the menu button on the keypad, go to 'Devices,' select the device you want to remove, and follow the prompts to delete it.",

"How do I arm SimpliSafe in Home mode?" : "To arm the system in Home mode, press the 'Home' button on the keypad or use the SimpliSafe app to activate Home mode while you're inside.",

"How do I silence the SimpliSafe alarm?" : "To silence the alarm, press the 'Off' button on the keypad or use the SimpliSafe app to disarm the system.",

"How do I troubleshoot connectivity issues with SimpliSafe?" : "If experiencing connectivity issues, ensure the base station is within range of your router, restart your router, and reattempt connecting through the SimpliSafe app.",

"How do I view the event history on SimpliSafe?" : "To view event history, open the SimpliSafe app, go to 'Timeline,' and review the list of past events recorded by the system.",

"How do I perform a system test on SimpliSafe?" : "To perform a system test, press the menu button on the keypad, go to 'System Settings,' and select 'Test Mode' to ensure all devices are functioning properly.",

"How do I enable SimpliSafe integration with Google Home?" : "To integrate with Google Home, open the Google Home app, tap 'Add,' select 'Set Up Device,' and link your SimpliSafe account.",

"How do I adjust motion sensitivity for SimpliSafe motion sensors?" : "To adjust motion sensitivity, press the menu button on the keypad, go to 'Devices,' select the motion sensor, and adjust the sensitivity level.",

"How do I enable voice prompts on SimpliSafe base station?" : "To enable voice prompts, press the menu button on the keypad, go to 'System Settings,' select 'Voice Prompts,' and toggle it on.",

"How do I reset the SimpliSafe base station?" : "To reset the base station, unplug it, remove the battery, wait for a few seconds, then reinsert the battery and plug it back in.",

"How do I mount the SimpliSafe outdoor camera?" : "To mount the outdoor camera, use the provided screws and wall anchors to secure the mounting bracket, then attach the camera to the bracket.",

"How do I adjust the brightness of the SimpliSafe keypad?" : "To adjust the brightness, press the menu button on the keypad, go to 'System Settings,' select 'Keypad Brightness,' and adjust as needed.",

"How do I set up smart locks with SimpliSafe?" : "To set up a smart lock, install the lock on your door, open the SimpliSafe app, go to 'Devices,' and add the smart lock following the on-screen prompts.",

"How do I activate SimpliSafe monitoring service?" : "To activate monitoring, open the SimpliSafe app, go to 'Settings,' select 'Monitoring,' and choose a monitoring plan to activate professional monitoring.",

"How do I replace the backup battery in the SimpliSafe base station?" : "To replace the backup battery, unplug the base station, remove the battery cover, replace the battery, and plug the base station back in.",

"How do I change the Wi-Fi network for SimpliSafe?" : "To change the Wi-Fi network, press the menu button on the keypad, go to 'System Settings,' select 'Wi-Fi,' and enter the new network credentials.",

"How do I set up SimpliSafe temperature sensor?" : "To set up the temperature sensor, place it in the desired location, press the menu button on the keypad, go to 'Devices,' and add the sensor.",

"How do I enable instant trigger on SimpliSafe entry sensors?" : "To enable instant trigger, press the menu button on the keypad, go to 'Devices,' select the entry sensor, and toggle on 'Instant Trigger.'",

"How do I enable two-factor authentication for SimpliSafe?" : "To enable two-factor authentication, open the SimpliSafe app, go to 'Account Settings,' select 'Two-Factor Authentication,' and follow the prompts to set it up.",

"How do I add a new device to Samsung SmartThings Hub?" : "To add a new device, open the SmartThings app, tap 'Add Device,' select the type of device you want to add, and follow the setup instructions.",

"How do I reset Samsung SmartThings Hub to factory settings?" : "To reset the SmartThings Hub, press and hold the reset button on the back of the hub until the LED starts flashing, indicating the reset process has begun.",

"How do I enable Zigbee and Z-Wave devices on Samsung SmartThings Hub?" : "To enable Zigbee and Z-Wave devices, open the SmartThings app, tap 'Add Device,' and select the type of Zigbee or Z-Wave device you want to connect.",

"How do I create automation routines with Samsung SmartThings Hub?" : "To create automation routines, open the SmartThings app, go to 'Automations,' and set up triggers and actions for your devices based on your preferences.",

"How do I set up voice control with Samsung SmartThings Hub?" : "To set up voice control, link your SmartThings Hub with Amazon Alexa or Google Assistant through their respective apps to control devices using voice commands.",

"How do I update the firmware on Samsung SmartThings Hub?" : "Firmware updates are installed automatically. To check for updates, open the SmartThings app, go to 'Settings,' and select 'Hub Information.'",

"How do I monitor connected devices with Samsung SmartThings Hub?" : "To monitor connected devices, open the SmartThings app, go to 'Devices,' and view the status of all devices connected to your hub.",

"How do I enable push notifications for Samsung SmartThings Hub?" : "To enable push notifications, open the SmartThings app, go to 'Settings,' select 'Notifications,' and toggle on alerts for the devices you want to monitor.",

"How do I create a custom scene with Samsung SmartThings Hub?" : "To create a custom scene, open the SmartThings app, go to 'Scenes,' and add actions for different devices to create a personalized automation sequence.",

"How do I integrate Samsung SmartThings Hub with Amazon Alexa?" : "To integrate with Alexa, open the Alexa app, go to 'Skills & Games,' search for 'SmartThings,' enable the skill, and link your SmartThings account.",

"How do I enable location-based automation for Samsung SmartThings Hub?" : "To enable location-based automation, open the SmartThings app, go to 'Automations,' and set up routines based on your phone's GPS location.",

"How do I set up SmartThings Energy Monitoring?" : "To set up energy monitoring, connect a compatible energy monitoring device, then open the SmartThings app and follow the setup prompts to track energy usage.",

"How do I use SmartThings Hub to control lighting?" : "To control lighting, connect your smart bulbs or light switches to the hub, then use the SmartThings app to turn lights on or off or create schedules.",

"How do I delete a device from Samsung SmartThings Hub?" : "To delete a device, open the SmartThings app, go to 'Devices,' select the device you want to remove, and tap 'Remove Device.'",

"How do I perform a firmware update for devices connected to Samsung SmartThings Hub?" : "Firmware updates for connected devices are usually automatic. To manually check, open the SmartThings app, go to 'Devices,' and look for update notifications.",

"How do I integrate Samsung SmartThings Hub with IFTTT?" : "To integrate with IFTTT, open the IFTTT app, search for 'SmartThings,' and connect your account to create applets for automation.",

"How do I adjust notification settings for Samsung SmartThings Hub?" : "To adjust notification settings, open the SmartThings app, go to 'Settings,' and customize the notifications for each device connected to the hub.",

"How do I enable Smart Home Monitor in Samsung SmartThings Hub?" : "To enable Smart Home Monitor, open the SmartThings app, go to 'SmartApps,' and set up Smart Home Monitor to receive alerts for security, smoke, or leaks.",

"How do I calibrate a Samsung SmartThings door sensor?" : "Door sensors do not typically require calibration. Ensure the sensor and magnet are properly aligned for accurate detection.",

"How do I integrate Samsung SmartThings Hub with Philips Hue?" : "To integrate with Philips Hue, open the SmartThings app, tap 'Add Device,' select 'Lighting,' and follow the prompts to connect your Hue lights.",

"How do I enable two-factor authentication for Samsung SmartThings Hub?" : "To enable two-factor authentication, open the SmartThings app, go to 'Account Settings,' select 'Two-Factor Authentication,' and follow the prompts to set it up.",

"How do I use Samsung SmartThings Hub to monitor humidity sensors?" : "To monitor humidity sensors, connect the sensors to your hub, then use the SmartThings app to view the humidity levels in real-time.",

"How do I enable SmartThings Edge drivers for Samsung SmartThings Hub?" : "To enable SmartThings Edge drivers, open the SmartThings app, go to 'Settings,' select 'Advanced Settings,' and enable Edge drivers to use local device processing.",

"What are the control panel features of LG Washer and Dryer (Model WM3998HBA)?" :

"Control Panel Features
a Power On/Off Button • Press this button to turn the washer on or off. • Pressing this button during a cycle will cancel that cycle and any load settings will be lost. • The door will unlock after a brief pause. NOTE • If there is any water remaining in the drum after the washer shuts off, it will drain after a delay. The washer can be restarted at any time before the drain begins. However, once the water begins to drain, all functions will be suspended until the water has been completely drained and the washer shuts off.
b Cycle Selector Knob • Turn this knob to select the desired cycle. • Once the desired cycle has been selected, the standard presets will appear in the display. These settings can be adjusted using the Cycle Modifier buttons at any time before starting the cycle.
c Start/Pause Button • Press this button to start the selected cycle. • If the washer is running, use this button to pause the cycle without losing the current settings. NOTE • If the Start/Pause button is not pressed to start the selected cycle, after a delay the washer automatically turns off and all cycle settings are lost. Any water remaining in the drum will be drained.
d Cycle Modifier Buttons • Use

these buttons to adjust the wash temperature, spin speed and soil level settings for the selected cycle. • The current settings are shown in the display. • Press the button for that option to select other settings.e",

"What does the time and status display indicate on LG Washer and Dryer (Model WM3998HBA)?" : "Time and Status Display a Cycle Status Indicators • These LEDs will blink when a cycle is selected to indicate which stages will run. • When a cycle is running, the LED for the active stage will blink, and the LEDs for the remaining stages will remain steady. Once a stage is complete, the LED will turn off. If a cycle is paused, the active stage LED will stop blinking.b Estimated Time Remaining • When a cycle is selected, the default time for that cycle is displayed. This time will change as modifiers or options are selected. • If the display shows ---, then the time will be displayed after the load sensing has detected the load size. • The time shown is only an estimate. This time is based on normal operating conditions. Several external factors (load size, room temperature, incoming water temperature, etc.) can affect the actual time.NOTE • Once the Start/Pause button is pressed, the washer will measure the size of the load. The estimated time may change once the load size has been measured. • If the Delay Wash function is set, the remaining delay time counts down until the cycle begins.c Door Lock Indicator • This indicator lights up when the cycle starts and the door is locked. • The indicator light stays on until the cycle is paused, stopped or has finished.d Control Lock Indicator • This indicator lights up when the control panel is locked. • CL and the remaining wash time are displayed, in turn, on the time remaining display. • When this function is set, all controls are disabled except for the Power button.e Fresh Care Indicator • This indicator lights up when the Fresh Care option is selected.f Wi-Fi Indicator • This indicator is lit when the product is connected to a home Wi-Fi network.",

"How do cycle modifiers work on LG Washer and Dryer (Model WM3998HBA)?" : "Cycle Modifiers About Modifier Buttons Each cycle has default settings that are selected automatically. You can also customize these settings using the cycle modifier buttons. • Repeatedly press the button for the desired modifier until the indicator light for the desired setting is lit. • The washer automatically adjusts the water level for the type and size of wash load for best results and maximum efficiency. • This is a high-efficiency washer, and the water levels may be much lower than you expect. This is normal, and cleaning/rinsing performance will not be compromised.NOTE • The LED next to the setting lights up when the setting is selected. • To protect your garments, not every wash temperature, spin speed, soil level, or option is available with every cycle. • A chime will sound twice and the LED will not light if the desired setting is not allowed for the selected cycle. • Follow the fabric care labels on the garment for best results.Temp. Make sure the wash temperature is suitable for the type of load you are washing. • Press the Temp. button repeatedly to select the wash and rinse temperature combination for the selected cycle. • All rinses use unheated cold water. • Cold rinses use less energy. The actual cold rinse temperature depends on the temperature of the cold water at the faucet. • Your washer features a heating element to boost the hot water temperature for Extra Hot settings. This provides improved wash performance at normal water heater settings.Spin Higher spin speeds extract more water from clothes, reducing drying time and saving energy. • P r e s s t h

• Press the Spin button repeatedly until the desired speed is selected. • Some fabrics, such as delicates, require a slower spin speed. • Adjusting the soil level setting will modify the cycle times and/or wash actions. • Press the Soil button repeatedly until the desired soil level is selected. • The Heavy soil setting may increase cycle times. The Light soil setting may decrease cycle times."

"What are the general tips for drying on LG Washer and Dryer (Model WM3998HBA)?" :

Dry Cycles
General Tips for Drying Use the automatic programmes to dry most loads. Electronic sensors measure the temperature of the exhaust to increase or decrease drying temperatures for faster reaction time and tighter temperature control. • Cold water tap must be left on during drying cycles. • This appliance's automatic process from washing to drying can be selected easily. • For most drying, make sure all clothes are similar in material and thickness. • Do not overload the appliance by stuffing too many articles into the drum. Items must be able to tumble freely. • If you open the door and remove the load before the appliance has finished its programme, remember to press the Start/Pause button. • After the drying is finished, END appears on the display. If the clothes are not unloaded from the drum in a period of time, CD appears on the display and the appliance tumbles the clothes periodically for about 4 hours to reduce creases. To stop this function, press any button and unload the clothes from the drum.
Woolen Articles Do not tumble dry woolen articles. Pull them to their original shape and dry them flat.
Woven and Loopknit Materials Some woven and loopknit materials may shrink, by varying amounts, depending on their quality."

"What options and extra functions are available on LG Washer and Dryer (Model WM3998HBA)?" :
Options and Extra Functions Your washer includes several additional cycle options to customize cycles to meet your individual needs. • Select the desired option after selecting the desired cycle and settings. **NOTE** • The LED for the option will light when the option is selected. • To protect your garments, not every option is available with every cycle. • A chime will sound twice and the LED will not light if the selected option is not allowed for the selected cycle.
Steam Adding this option to a wash cycle helps provide superior cleaning performance. Using steam gives fabrics the cleaning benefits of a very hot wash. • Steam may not be clearly visible during steam cycles. This is normal. Too much steam could damage clothing. • Do not use steam with delicate fabrics such as wool and silk, or easily discolored fabrics. **WARNING** • Do not touch the door during steam cycles. The door surface can become very hot and can cause severe burns. Allow the door lock to release before opening the door. • Do not attempt to override the door lock mechanism or reach into the washer during a steam cycle. Steam can cause severe burns.
Fresh Care Use this function when you will not be able to unload your clothes immediately after the wash cycle ends. • The drum will tumble periodically for up to 19 hours to prevent wrinkles.
1 Turn on the power. **2** Select the desired cycle. **3** Press and hold the Steam button for 3 seconds to select this function. **4** Press the Start/Pause or Power button at anytime to unload laundry.
Using the Pre-wash Option This option adds a pre-wash (for about 15 - 17 minutes) for improved cleaning of heavily soiled or stained clothing. **NOTE** • If you select Pre-wash after putting the detergent directly in the drum, the detergent may be washed away, reducing

the washing performance. **Delay Wash** Once you have selected the cycle and other settings, press the Delay Wash button to delay the start of the wash cycle. • Each press of this button increases the delay time by 1 hour, for up to 19 hours. • Once the desired delay time is set, press the Start/Pause button to start the delay time. **NOTE** • If the Start/Pause button is not pressed to begin the delay time, the washer automatically turns off after a certain time and all cycle settings are lost. **Add Garments** Use this function to add garments or remove foreign objects like coins or keys after the cycle has started. 1 Press the Add Garments button while the wash cycle is running. • The cycle pauses and the door unlocks. 2 Open the door, add garments or remove foreign objects, and close the door. 3 Press the Start/Pause button to resume the cycle. The cycle continues automatically. **32 OPERATION WARNING** • Do not attempt to force the door to open when locked. Doing so could result in damage to the appliance, malfunction, or personal injury. **NOTE** • If the water level and temperature are safe, the door lock LED turns off and the door unlocks once the wash movement has stopped. • If the water level is too high, the door will not unlock, and this function cannot be used. • If the temperature in the drum is higher than 113 °F (45 °C), a short warning chime sounds and this function is not allowed for safety. • This function is disabled during the Tub Clean cycle. • To preserve wash performance, wash time may be extended depending on when garments are added to a cycle. • Be careful when opening the door as wet laundry may drip or fall out. **Turbo Wash™** Adding this option reduces the cycle time while still providing similar wash performance to the same cycle without Turbo Wash™. **NOTE** • This option cannot be used with all cycles. • This option defaults to on for Normal, Heavy Duty and Perm. Press wash cycles. **Cold Wash** Press the Cold Wash button to save energy by using cooler water. It will increase the wash and rinse times to maintain wash performance. • Wash time will increase up to several minutes with this option. • For best wash results, only wash small loads (less than 8 lb) with this option. **Extra Rinse** This option adds an extra rinse to the selected cycle. Use this option to help ensure the removal of detergent or bleach residue from fabrics. • Press the Extra Rinse button to add additional rinses to the cycle. **Rinse+Spin** Select this option to rinse and spin a load separately from a regular cycle. This can be helpful in preventing fresh stains from setting in fabrics. 1 Press the Power button to turn on the washer. • Do not select a cycle. 2 Press the Rinse+Spin button. • You can change the spin speed by pressing the Spin button. 3 Press the Start/Pause button. **Control Lock** Use this function to disable the controls. This function can prevent children from changing cycles or operating this washer. **NOTE** • The function does not lock the door. • Once this function is set, all buttons are locked except the Power button. • When the controls are locked, CL and the remaining time are alternately shown on the display during the wash cycle. • Turning off the power will not reset this function. You must deactivate this function before you can access any other options and functions. **Locking/Unlocking the Control Panel** 1 Turn on the power. 2 Press and hold the Rinse+Spin button for 3 seconds to activate/deactivate this function. • When the function is deactivated, a chime will sound and the remaining time for the current cycle will reappear on the display. **33"**

"How do I use Delay Wash on LG Washer and Dryer (Model WM3998HBA)?" : "Delay Wash Once you have selected the cycle and other settings, press the Delay Wash button to delay the start of the wash cycle. • Each press of this button increases the delay time by 1

hour, for up to 19 hours. • Once the desired delay time is set, press the Start/Pause button to start the delay time. NOTE • If the Start/Pause button is not pressed to begin the delay time, the washer automatically turns off after a certain time and all cycle settings are lost.",

"How do I use Add Garments on LG Washer and Dryer (Model WM3998HBA)?" : "Add Garments Use this function to add garments or remove foreign objects like coins or keys after the cycle has started. 1 Press the Add Garments button while the wash cycle is running. • The cycle pauses and the door unlocks. 2 Open the door, add garments or remove foreign objects, and close the door. 3 Press the Start/Pause button to resume the cycle. The cycle continues automatically.",

"How do I use Control Lock on LG Washer and Dryer (Model WM3998HBA)?" : "Control Lock Use this function to disable the controls. This function can prevent children from changing cycles or operating this washer. NOTE • The function does not lock the door. • Once this function is set, all buttons are locked except the Power button. • When the controls are locked, CL and the remaining time are alternately shown on the display during the wash cycle. • Turning off the power will not reset this function. You must deactivate this function before you can access any other options and functions.",

"How do I lock or unlock the control panel on LG Washer and Dryer (Model WM3998HBA)?" : "Locking/Unlocking the Control Panel 1 Turn on the power. 2 Press and hold the Rinse+Spin button for 3 seconds to activate/deactivate this function. • When the function is deactivated, a chime will sound and the remaining time for the current cycle will reappear on the display.",

"What LG ThinQ application features are available for LG Washer and Dryer (Model WM3998HBA)?" : "LG ThinQ Application Features For the product that contains the Wireless LAN module. • Remote Start- Control the appliance remotely from the LG ThinQ application. • Downloaded- Download new and specialized cycles that are not included in the standard cycles on the appliance. • Tub Clean Coach- Find out how many cycles remain before it is time to run the Tub Clean cycle. • Energy Monitoring- Keep track of the washer's power consumption and how it is affected by your selected wash cycles and options. • Smart Diagnosis™- This function provides useful information for diagnosing and solving issues with the appliance based on the pattern of use. • Push Alerts- When the cycle is complete or the appliance has problems, you will receive a push message. • Settings- Set various options on the appliance and in the application.",

"How do I use LG ThinQ to diagnose issues on LG Washer and Dryer (Model WM3998HBA)?" : "Using LG ThinQ to Diagnose Issues If you experience a problem with your Wi-Fi equipped appliance, it can transmit troubleshooting data to a smartphone using the LG ThinQ application. • Launch the LG ThinQ application and select the Smart Diagnosis™ feature in the menu. Follow the instructions provided in the LG ThinQ application.",

"How do I use audible diagnosis to diagnose issues on LG Washer and Dryer (Model WM3998HBA)?" : "Using Audible Diagnosis to Diagnose Issues Follow the instructions below to use the audible diagnosis method. • Launch the LG ThinQ application and select the Smart

Diagnosis™ feature in the menu. Follow the instructions for audible diagnosis provided in the LG ThinQ application.

- 1 Press the Power button to turn on the appliance.
- Do not press any other buttons.
- 2 Place the mouthpiece of your smartphone close to the c or d logo.
- 3 Press and hold the Temp. button for 3 seconds or until the audible tones start. Hold the smartphone mouthpiece to the logo until the data transfer is complete.
- Keep the smartphone in place until the data transfer has finished. Time remaining for data transfer is displayed.
- 4 After the data transfer is complete, the diagnosis will be displayed in the application."

"How should I sort laundry before using LG Washer and Dryer (Model WM3998HBA)?" :

"Sorting Laundry CAUTION • Clothing or articles that are waterproof or water-resistant must be washed in the Waterproof, Bedding, Bulky/Large, or Jumbo Wash cycle only. (Examples include water resistant clothing, mattress covers, outdoor clothes, and plastic mats.) Failure to do so may result in personal injury or damage to the washer, clothes, walls, floor, and surrounding objects due to abnormal vibration. • Remove the stuffing from pillows and cushions before washing the covers. Failure to do so can cause excessive vibration, resulting in damage to the washer, clothes, nearby objects, walls, and floor.

Grouping Similar Items For the best washing results, and to reduce the possibility of damage to clothing, sort clothing into loads made up of similar items. Mixing different fabric types and/or soil levels can result in poor wash performance, color transfer, discoloration, fabric damage or linting. Fabrics should be sorted into groups as described below.

Colors Sort articles by color. Wash dark clothes separately from light colors or whites. Mixing dark clothes with light clothes can result in dye transfer or discoloration of the lighter clothes.

Soil Level Wash heavily soiled clothing together. Washing lightly soiled clothing in the same load with heavily soiled clothing could result in poor wash performance for the lightly soiled clothing.

Fabric Type Delicate articles should not be mixed with heavy or sturdy fabric types. Washing heavy fabrics with delicates can result in poor wash performance for the heavy fabrics and possible damage to the delicates.

Lint Type Some fabrics attract and bind lint to them while others give off lint in the laundry process. Avoid mixing these lint collectors and lint producers in the same load. Mixing these fabrics will result in pilling and linting on the lint collectors. (For example, lint collector - knit sweater; lint producer - terry cloth towels.)

How to Sort Laundry By Colors By Soil By Fabric By Lint White Heavy Delicates Lint Producer",

"How do I use fabric care labels with LG Washer and Dryer (Model WM3998HBA)?" : "Fabric Care Labels Many articles of clothing include a fabric care label. Using the chart below, adjust the cycle and option selections to care for your clothing according to the manufacturer's recommendations."

"How do I load the washer on LG Washer and Dryer (Model WM3998HBA)?" : "Loading the Washer CAUTION • Clothing or articles that are waterproof or water-resistant must be washed in the Waterproof, Bedding, Bulky/Large, or Jumbo Wash cycle only. (Examples include water resistant clothing, mattress covers, outdoor clothes, and plastic mats.) Failure to do so may result in personal injury or damage to the washer, clothes, walls, floor, and surrounding objects due to abnormal vibration.

General Tips • Check and empty pockets.

Paper clips, coins, matches, and other items can damage clothing and the washer. • Close zippers and hooks, and tie drawstrings to prevent snagging or tangling of clothes. • Pretreat heavily stained areas for best results. • Brush off heavy soil, dust, and hair from items before washing. Excess dirt or sand can abrade other fabrics and lead to poor wash performance. • For best performance, load clothes as shown. - Do not press down on items while stacking them in the drum. - Load clothes loosely, and do not overfill the drum. Clothes need room to circulate in order to get clean. Lights Normal Easy Care Lint Collector Darks Light Sturdy Category Label Directions Washing Hand wash Machine wash, Normal cycle Perm Press/Wrinkle Resistant setting (which has a cool down or cold spray before the slower spin) Gentle/Delicate setting (slow agitation and/or reduced wash time) Do not wash Do not wring Water Temperature Hot Warm Cold/Cool Bleach Symbols Any bleach (when needed) Only non-chlorine bleach (when needed) Do not bleach By Colors By Soil By Fabric By Lint 132420 OPERATION • Combine large and small items in the drum. Load large items first. Large items should not be more than half of the total load. • The washer can be fully loaded, but the drum should not be tightly packed with items. The door of the washer must close easily. • The washer will not fill or operate with the door open. Bulky Items • Wash thick, bulky items individually. Heavy blankets, comforters, bedspreads, or pet beds can get tangled or cause an unbalanced load if combined with other items. Small Items • Do not wash a single small item. Add enough similar items to the load to prevent an out-of-balance load. • Wash small, light items in a mesh bag. Small items can get caught in the impeller at the bottom of the drum, and brassiere hooks can snag on other clothing or the drum.",

"What detergent use guidance applies to LG Washer and Dryer (Model WM3998HBA)?" : "About Detergent Use This washer is designed for use with only HE (High-Efficiency) detergents. • HE detergents produce fewer suds, dissolve more efficiently to improve washing and rinsing performance, and help to keep the interior of the washer clean. Using detergent that is not HE may cause oversudsing and unsatisfactory performance which could result in error codes, cycle failure, and washer damage. • Detergents designated as HE-compatible may not provide optimal results. • For proper wash performance, always measure detergent using the measuring device provided by the detergent manufacturer. For an average load, use less than half of the recommended maximum. Use less detergent for soft water, light soil, or smaller loads. • Use extra care when measuring 2X and 3X concentrated detergents because even a small amount of extra detergent can lead to problems. • Never use more than the maximum amount of detergent recommended by the manufacturer. Using too much detergent can lead to oversudsing, poor rinsing, detergent buildup in clothing, and residue buildup that can contribute to odors in the washer. • Do not use more than one single-use detergent pack in the washer. Using too much detergent may cause oversudsing and unsatisfactory performance. Reduce detergent amount or add an extra rinse if detergent residue is left on fabrics. To add an extra rinse, select the Extra Rinse option. a Maximum fill line b Average load fill line c Liquid detergent d Powdered detergent",

"How do I use single-use detergent packs, gel, or tablet detergents with LG Washer and Dryer (Model WM3998HBA)?" : "Single-Use Detergent Packs / Gel or Tablet Detergents Place

liquid or powdered detergent packs, or gel or tablet detergents in the drum before loading laundry. Do not place these detergents in the dispenser.",

"What is the pre-wash detergent compartment guidance for LG Washer and Dryer (Model WM3998HBA)?" : "Pre-wash detergent compartment (on some models) b Liquid detergent cup c",

"What is the main wash detergent compartment guidance for LG Washer and Dryer (Model WM3998HBA)?" : "Main wash detergent compartment d Liquid fabric softener compartment e Liquid chlorine bleach compartment 3 Gently close the detergent dispenser drawer before starting the cycle. • Slamming the drawer closed may result in the detergent overflowing into another compartment or dispensing into the drum earlier than programmed. • Be careful not to get a hand caught in the drawer while closing. • It is normal for a small amount of water to remain in the dispenser compartments at the end of the cycle. CAUTION • Do not place or store laundry products, such as detergent, bleach, or liquid fabric softener, on top of your washer. These products can damage the washer's finish and controls. Pre-wash Detergent Compartment Add liquid or powdered detergent to this compartment when using the Pre-wash option. Always use HE (High-Efficiency) detergent with your washer. • When using the Pre-wash option, liquid detergent for the main wash needs to be loaded in the liquid detergent cup accessory in the main wash dispenser (where applicable), to prevent it from being dispensed with the pre-wash detergent. • The amount of detergent added for the Pre-wash option is 1/2 the amount recommended for the main wash cycle. For example, if the main wash cycle requires one measure of detergent, add 1/2 measure for the Pre-wash option. Main Wash Detergent Compartment This compartment holds laundry detergent for the main wash cycle. Either powdered or liquid detergent may be used in this compartment. • The detergent is added to the load at the beginning of the cycle. Always use HE (High-Efficiency) detergent with your washer. • Do not exceed the maximum fill line. Using too much detergent can result in detergent buildup in clothing and the washer. • Liquid or powdered color-safe bleach may be added to the main wash compartment with detergent of the same type. Do not mix liquids and powders. • If the dispenser has a liquid detergent cup and insert: - Make sure they are in place when using liquid detergent. - Make sure to remove them when using powdered detergent. Powdered detergent will not dispense with the liquid detergent cup and insert in place. • If you use a detergent that does not dissolve easily or a detergent with high viscosity, it will leave a residue and clog the dispenser.",

"What is the liquid bleach compartment guidance for LG Washer and Dryer (Model WM3998HBA)?" : "Liquid Bleach Compartment This compartment holds liquid bleach, which is dispensed automatically at the proper time during the wash cycle. The dispenser is activated twice to ensure complete dispensing of the bleach. Any liquid remaining in the dispenser at the end of the cycle is water, not bleach. WARNING • Do not mix chlorine bleach with ammonia or acids such as vinegar or rust/scale remover. Mixing chemicals like these can produce a lethal gas, resulting in severe injury or death.",

"What is the fabric softener compartment guidance for LG Washer and Dryer (Model WM3998HBA)?" : "Fabric Softener Compartment This compartment holds fabric softener, which is automatically dispensed during the final rinse cycle. Either powdered or liquid fabric softener may be used. • Do not exceed the maximum fill line. Using too much fabric softener may stain clothes or cause buildup on fabrics or in the washer. • Dilute concentrated fabric softeners with warm water. • Never pour fabric softener directly onto the load or into the drum.",

"What wash cycles are available on LG Washer and Dryer (Model WM3998HBA), and what are they designed for?" : "Wash Cycles The wash cycles are designed for specific types of wash loads. Select the cycle that best matches the load contents for maximum wash performance and fabric care. See Sorting Laundry section for best results, and follow the fabric care labels on your garments. For a guide to fabric care symbols, see Sorting Laundry section. Cycle Guide Turn the knob or press the button to select the desired cycle. When you select a wash cycle, the light for the corresponding wash cycle will turn on. NOTE • Whenever load weights are mentioned, assume 1 lb (0.45 kg) = 1 thick bath towel (dry). • Temperature indicator lights up when one of Tap Cold, Cold, Warm, Hot or Extra Hot is selected. • Spin indicator lights up when one of No Spin, Low, Medium, High or Extra High is selected. Cycle Normal Description Use to wash all normal items such as cotton, linen, shirts, jeans or mixed loads, except delicate fabrics such as wool or silk. • Pressing the Start/Pause button without selecting a cycle will cause the Normal cycle to begin immediately, using the default settings. Wash Temp. Default: Warm Available: All Spin Speed Default: High Available: All Soil Level Default: Normal Available: All Cycle Heavy Duty Description Suitable for washing heavily soiled laundry, such as cotton fabrics, using more powerful wash motions. • When washing large loads, there will be brief periods of 2 minutes or more without agitation. These soak periods are part of the cycle's design, and are normal. Wash Temp. Default: Warm Available: All Spin Speed Default: Extra High Available: All Soil Level Default: Heavy Available: All Cycle Bedding Description Suitable for washing blankets or bulky items which have difficulty absorbing water, such as pillows, blankets, comforters, sheets or pet bedding. • Do not use this cycle to wash a mixed load of bedding and non-bedding items. • Do not mix large/bulky items with smaller articles of clothing. • Do not wash excessively large items. If large/bulky items do not fit easily into the tub, there may not be enough room for them to move during washing. 26 OPERATION Wash Temp. Default: Warm Available: Hot, Warm, Cold, Tap Cold Spin Speed Default: Medium Available: Medium, Low, No Spin Soil Level Default: Normal Available: All Cycle Bright Whites TMD Description This cycle is for washing white items only. (less than 15 lb (6.8 kg)) Wash Temp. Default: Hot Available: Hot, Warm, Cold, Tap Cold Spin Speed Default: High Available: All Soil Level Default: Normal Available: All Cycle Sanitary Description Washes clothes at a high temperature. Wash Temp. Default: Extra Hot Available: Extra Hot Spin Speed Default: High Available: All Soil Level Default: Normal Available: All Cycle Allergiene TMD Description This cycle is a powerful, high-temperature cycle designed specifically to reduce certain allergens. NOTE • Selecting this cycle automatically incorporates steam into the wash cycle. • This cycle can significantly reduce allergens in bedding and clothing. • This cycle helps reduce dust mite populations and helps reduce allergens. Due to the higher energy and temperatures used, this cycle is not recommended

for wool, silk, leather, or any other delicate or temperature sensitive items. Spin Speed Default: High Available: All Cycle Tub Clean Description This is a special cycle designed to clean the inside of the washer. Cycle Delicates Description Suitable for washing dress shirts/blouses, nylons, lingerie, or sheer and lacy clothes which can easily be damaged. (less than 8 lb (3.63 kg)) Wash Temp. Default: Cold Available: Warm, Cold, Tap Cold Spin Speed Default: Medium Available: Medium, Low, No Spin Soil Level Default: Normal Available: All Cycle Perm. Press Description Use this cycle to minimize wrinkles when washing tablecloths or "wrinkle-free" clothes. Cycle Bedding 27 OPERATION ENGLISH Wash Temp. Default: Warm Available: Hot, Warm, Cold, Tap Cold Spin Speed Default: Medium Available: High, Medium, Low, No Spin Soil Level Default: Normal Available: All Cycle Towels Description Use this cycle for washing towels, shirts, jeans and mixed loads. Wash Temp. Default: Warm Available: Hot, Warm, Cold, Tap Cold Spin Speed Default: Extra High Available: All Soil Level Default: Normal Available: All Cycle Sportswear Description Washes special garments like sports and outdoor wear. • Use for water-repellent fabric laminate used on clothing. Wash Temp. Default: Warm Available: Warm, Cold, Tap Cold Spin Speed Default: Medium Available: Medium, Low, No Spin Soil Level Default: Normal Available: All Cycle Speed Wash Description Quickly washes lightly soiled clothing and small loads. For high wash and rinse efficiency, wash small loads of 2-3 lightly soiled garments. (less than 3 lb (1.36 kg)) • Use very little detergent in this cycle. To add an extra rinse, use the Extra Rinse option. Wash Temp. Default: Hot Available: Hot, Warm, Cold, Tap Cold Spin Speed Default: Extra High Available: All Soil Level Default: Light Available: All Cycle Drain+Spin Description This cycle is for draining and spinning without the wash and rinse cycle, or for removing the load from the washing machine in the middle of the cycle. • You can change the spin speed by pressing the Spin button repeatedly until the desired speed is selected. Wash Temp. Default: Cold Available: All Spin Speed Default: High Available: All Cycle Downloaded (Small Load) Description You can use a smartphone to download a specialized cycle to this cycle position. • The default cycle is Small Load, used for normally soiled loads with a few items. This cycle is also available for download. • Refer to the LG ThinQ application to see the cycles available for download. Cycle Perm. Press 28 OPERATION Available Options † This option is automatically included in the cycle and cannot be deselected. NOTE • Delay Wash, Extra Rinse, Fresh Care and Add Item can be selected for every cycle in this table. • Steam and Cold Wash cannot be selected at the same time. • If the Turbo Wash™ option is on, you cannot select No Spin as your Spin. Wash Temp. Default: Warm Available: Hot, Warm, Cold, Tap Cold Spin Speed Default: High Available: All Soil Level Default: Normal Available: All Cycle Steam Dry Turbo Wash™ Cold Wash Pre-wash Normal ## #† ## Heavy Duty ## #† ## Bedding ##### Bright Whites™ #### #Sanitary #### #Allergiene™ #† ## Delicates ## Perm. Press ##### Towels ##### Sportswear Speed Wash ### Drain+Spin #Cycle Downloaded (Small Load) 29 OPERATION ENGLISH",

"What does the Steam option do on LG Washer and Dryer (Model WM3998HBA)?" :

"Steam Adding this option to a wash cycle helps provide superior cleaning performance.

Using steam gives fabrics the cleaning benefits of a very hot wash. • Steam may not be clearly visible during steam cycles. This is normal. Too much steam could damage clothing. • Do not use steam with delicate fabrics such as wool and silk, or easily discolored fabrics. WARNING •

Do not touch the door during steam cycles. The door surface can become very hot and can cause severe burns. Allow the door lock to release before opening the door. • Do not attempt to override the door lock mechanism or reach into the washer during a steam cycle. Steam can cause severe burns.",

"How do I use Fresh Care on LG Washer and Dryer (Model WM3998HBA)?" : "Fresh Care Use this function when you will not be able to unload your clothes immediately after the wash cycle ends. • The drum will tumble periodically for up to 19 hours to prevent wrinkles. 1 Turn on the power. 2 Select the desired cycle. 3 Press and hold the Steam button for 3 seconds to select this function. 4 Press the Start/Pause or Power button at anytime to unload laundry.",

"How do I use the Pre-wash option on LG Washer and Dryer (Model WM3998HBA)?" : "Using the Pre-wash Option This option adds a pre-wash (for about 15 - 17 minutes) for improved cleaning of heavily soiled or stained clothing. NOTE • If you select Pre-wash after putting the detergent directly in the drum, the detergent may be washed away, reducing the washing performance.",

"What does Turbo Wash do on LG Washer and Dryer (Model WM3998HBA)?" : "Turbo Wash™ Adding this option reduces the cycle time while still providing similar wash performance to the same cycle without Turbo Wash™. NOTE • This option cannot be used with all cycles. • This option defaults to on for Normal, Heavy Duty and Perm. Press wash cycles.",

"What does Cold Wash do on LG Washer and Dryer (Model WM3998HBA)?" : "Cold Wash Press the Cold Wash button to save energy by using cooler water. It will increase the wash and rinse times to maintain wash performance. • Wash time will increase up to several minutes with this option. • For best wash results, only wash small loads (less than 8 lb) with this option.",

"What does Extra Rinse do on LG Washer and Dryer (Model WM3998HBA)?" : "Extra Rinse This option adds an extra rinse to the selected cycle. Use this option to help ensure the removal of detergent or bleach residue from fabrics. • Press the Extra Rinse button to add additional rinses to the cycle.",

"How do I use Rinse+Spin on LG Washer and Dryer (Model WM3998HBA)?" : "Rinse+Spin Select this option to rinse and spin a load separately from a regular cycle. This can be helpful in preventing fresh stains from setting in fabrics. 1 Press the Power button to turn on the washer. • Do not select a cycle. 2 Press the Rinse+Spin button. • You can change the spin speed by pressing the Spin button. 3 Press the Start/Pause button.",

"What does Withings Body+ do and what can I track with it?" : "Withings Body+ Description Overview The Withings Body+ allows you to easily track your weight and monitor your progress. Additionally, it calculates your fat mass, muscle mass, bone mass and water mass by bioelectric impedance to inform you about your body composition. Of course that's not all your Withings Body+ does. If you activate the Weather screen, you also get your daily weather report everytime you weigh in. Because the Withings Body+ is a connected scale, its true potential is achieved when you use it along with the Withings Health Mate® app. Beside allowing you to install your scale, the Withings Health Mate® app allows you to customize its display, to set a weight goal, and to check the entire history of your weight data. Thanks to its in-app activity tracking feature and the numerous partner apps you can connect it to, the Withings Health Mate® app helps you reach your health goals faster by helping you track your activity and check your calorie balance.

Box contents (A) Withings Body+ (C) AAA batteries already inserted (B) Carpet feet EN - 6 Withings Body+ v4.1 | October 2020

Product description (A) Display (D) Pairing and units button (B) Electrodes (E) Battery compartment (C) Feet

Scales screens description You can select a number of screens to be displayed on your Withings Body+: •Weight: Displays your weight. This screen cannot be disabled. •Fat mass: Displays your percentage of fat mass. •Water: Displays your percentage of water. •Bone mass: Displays the weight of your bones. •Muscle mass: Displays the weight of your muscles. •Weather 1: Displays the weather for the day. •Weight Trend 1: Displays a graph with your last 8 weight measurements. •Steps 1, 2: Displays the number of steps you did the previous day. You can disable or change the order of these screens as you like after you

EN - 7 Withings Body+ v4.1 | October 2020

install your Withings Body+. Otherwise, they will appear in the default order. Refer to "Changing the screen order" on page 23 for more information. 1 This screen can only be used if you set up your Withings Body+ in Wi-Fi. 2 You either need to own a Withings tracker, or to use the in-app tracking of the Withings Health Mate® app to display your number of steps on this screen. If you don't have a Withings tracker, tap on Activity in your Dashboard in the Withings Health Mate® app and tap Activate now. Your mobile device will then start tracking your steps. EN - 8 Withings Body+ v4.1 | October 2020",

"What screens can be displayed on Withings Body+ and what do they show?" : "Scales screens description You can select a number of screens to be displayed on your Withings Body+: •Weight: Displays your weight. This screen cannot be disabled. •Fat mass: Displays your percentage of fat mass. •Water: Displays your percentage of water. •Bone mass: Displays the weight of your bones. •Muscle mass: Displays the weight of your muscles. •Weather 1: Displays the weather for the day. •Weight Trend 1: Displays a graph with your last 8 weight measurements. •Steps 1, 2: Displays the number of steps you did the previous day. You can disable or change the order of these screens as you like after you

EN - 7 Withings Body+ v4.1 | October 2020

install your Withings Body+. Otherwise, they will appear in the default order. Refer to "Changing the screen order" on page 23 for more information. 1 This screen can only be used if you set up your Withings Body+ in Wi-Fi. 2 You either need to own a Withings tracker, or to use the in-app tracking of the Withings Health Mate® app to display your number of steps on this screen. If you don't have a Withings tracker, tap on Activity in

your Dashboard in the Withings Health Mate® app and tap Activate now. Your mobile device will then start tracking your steps. EN - 8 Withings Body+v4.1 | October 2020",

"How do I change the configuration of Withings Body+ (Wi-Fi network or Wi-Fi/Bluetooth mode)?" : "Changing the configuration of your Withings Body+ You may need to change the configuration of your Withings Body+: • If you want to use a different Wi-Fi network, • If you've changed the name or password of the Wi-Fi network you use, • If you want to switch from a Bluetooth configuration to a Wi-Fi configuration, • If you want to switch from a Wi-Fi configuration to a Bluetooth configuration. To change your configuration, perform the following steps: 1. Open the Withings Health Mate® app. 2. Go to Devices. 3. Tap Body+. 4. Tap Update Wi-Fi Configuration. EN - 20 Withings Body+v4.1 | October 2020 5. Press the pairing button at the back of the scale and tap Next. 6. Tap Next. 7. To switch to a Wi-Fi configuration or to update the Wi-Fi network: a. Tap Quick setup to use the same Wi-Fi network as your mobile device or Setup another network to use another one. EN - 21 Withings Body+v4.1 | October 2020 b. Tap Allow. 8. To switch to a Bluetooth configuration, tap I don't have a Wi-Fi Network. 9. Tap Done. EN - 22 Withings Body+v4.1 | October 2020",

"How do I change the weight unit on Withings Body+?" : "Changing the weight unit You have the choice between three weight units: kilogram (kg), stone (stlb) and pound (lb). To change the units on your Withings Body+, perform the following steps: 1. Press the button at the back of your Withings Body+. 2. Check the screen of your scale to view the unit currently selected. 3. Press the button again to move the arrow to the correct unit. The unit change is confirmed a few seconds after you stop pressing the button.",

"How do I change the temperature unit used for the Weather screen for Withings Body+?" : "Changing the temperature unit While you can change the weight unit directly from your Withings Body+, the temperature unit (used in the Weather screen) can only be changed from the Withings Health Mate® app. By default, the temperature unit is based on the language of the app. To change the temperature unit, perform the following steps: 1. Open the Withings Health Mate® app. 2. Go to Profile > Settings. 3. Tap Units. 4. Select the temperature unit you want. You can also change the weight unit from this screen but it will only affect the display in the Withings Health Mate® app. The weight unit on the Withings Body+ can only be changed from the scale itself. Refer to "Changing the weight unit" on page 22 for more information. 5. Tap the back button to confirm. You will need to weigh in once more before the change is taken into account on your scale. EN - 23 Withings Body+v4.1 | October 2020",

"How do I change the screen order on Withings Body+?" : "Changing the screen order You can change the order of the screens of your Withings Body+, for example if you want to display the Weather screen first. To do so, perform the following steps: 1. Open the Withings Health Mate® app. 2. Go to Devices. 3. Tap Body+. 4. Tap Screens customization. 5. Tap the user profile for which you want to change the screen order. 6. Select the screens you want to display: EN - 24 Withings Body+v4.1 | October 2020 - Tap the dark circles on the left to hide a screen. - Tap the empty circles on the left to display a screen. 7. Tap and hold the icon on

the right to drag a screen up or down.8. Tap the back button to confirm.9. Weigh yourself once to synchronize your Withings Body+ with your app and finalize the change. The change will take effect upon your next weigh-in.",

"How do I change the location of my Withings Body+ scale for correct weather?" : "Changing the location of your scale
The location of your scale is used to provide you with the correct weather forecast if you have activated the Weather screen. It is based on your IP address but it is not always accurate. If the preset location of your scale happens to be incorrect, you are free to change it anytime you want. To do so, perform the following steps: 1. Open the Withings Health Mate® app. 2. Go to Devices. 3. Tap Body+. 4. Tap Location of your scale. EN - 26 Withings Body+ v4.1 | October 2020. Enter the correct location of your scale and tap OK.",

"How do I disable body composition measurements on Withings Body+?" : "Disabling body composition measurements
You can disable body composition measurements (fat mass, muscle mass, bone mass and water mass) if you choose to. This is recommended for pregnant women and mandatory for anyone wearing a pacemaker. The body composition measurements, including fat mass, muscle mass, bone mass and water mass, should not be used by people wearing a pacemaker. Users with any other internal medical device should not use these functions of the Withings Body+ scale without consulting a medical professional. To disable these measurements, perform the following steps: 1. Open the Withings Health Mate® app. 2. Go to Devices. 3. Tap Body+. EN - 27 Withings Body+ v4.1 | October 2020. Tap Fat mass measurement. 5. Tap the back button to confirm.",

"How do I use Athlete mode with Withings Body+?" : "Using the Athlete mode
Athletes generally have a different body type which requires a specific fat mass calculation algorithm. If you work out more than 8 hours a week and have a resting heart rate below 60 bpm, you may need to use the Athlete mode. To do so, perform the following steps: 1. Open the Withings Health Mate® app. 2. Go to Profile. 3. Tap Settings. EN - 28 Withings Body+ v4.1 | October 2020. Tap Athlete. EN - 29 Withings Body+ v4.1 | October 2020",

"How do I track weight and body composition using Withings Body+?" : "Tracking your weight and body composition
Overview
The Withings Body+ allows you to track your weight and lets you see how your weight trend changes over time. Beside your weight, it also allows you to check your body composition (fat mass, muscle mass, bone mass and water mass) which gives you a better idea of your level of fitness. Make sure you follow the recommendations below to get accurate and representative weight measurements: • Make sure you always weigh yourself around the same time to improve the consistency of your measurements. • Wait five seconds before weighing yourself if you have just moved your scale. • If your scale is on a carpet, make sure you're using the carpet feet. Refer to "" on page 47 for more information. Weighing yourself
Thanks to the Position Control™ technology, getting an accurate weight measurement has never been easier. If your weight is not properly distributed on your Withings Body+, arrows are displayed on the scale to indicate in which direction you should lean to stabilize your weight. If several users have a similar weight, the following screen can be displayed: EN - 30 Withings Body+ v4.1 | October

2020 Simply lean left or right to select the correct name. Your measurements will then be affected to the correct user. If you want to get information regarding your body composition as well, make sure that:

- Body composition measurements are enabled. Refer to “Disabling body composition measurements” on page 26 for more information.
- All the body composition screens are enabled. Refer to “Changing the screen order” on page 23 for more information.
- You step on the scale barefoot.
- You stay as still as possible during the measurement.
- You are recognized by your Withings Body+, with your name appearing on the screen display.”

"How do I weigh myself correctly on Withings Body+?" : "weighing yourself if you have just moved your scale.

- If your scale is on a carpet, make sure you're using the carpet feet. Refer to "" on page 47 for more information.

weighing yourself Thanks to the Position Control™ technology, getting an accurate weight measurement has never been easier. If your weight is not properly distributed on your Withings Body+, arrows are displayed on the scale to indicate in which direction you should lean to stabilize your weight. If several users have a similar weight, the following screen can be displayed:

EN - 30 Withings Body+v4.1 | October 2020

Simply lean left or right to select the correct name. Your measurements will then be affected to the correct user. If you want to get information regarding your body composition as well, make sure that:

- Body composition measurements are enabled. Refer to “Disabling body composition measurements” on page 26 for more information.
- All the body composition screens are enabled. Refer to “Changing the screen order” on page 23 for more information.
- You step on the scale barefoot.
- You stay as still as possible during the measurement.
- You are recognized by your Withings Body+, with your name appearing on the screen display.”

"How do I retrieve and view my weight data from Withings Body+?" : "Retrieving your weight data As soon as you weigh yourself, your weight is displayed on the display of your scale. If you've activated the Weight Trend screen, you'll also see a graph showing your eight last measurements as well as the difference between the latest measurement and the previous one. Refer to “Changing the screen order” on page 23 for more information. To see detailed graphs about your weight and body composition, and see your full history, you have to check your data on the Withings Health Mate® app. You can access your graphs:

- By tapping the Weight widget on your Dashboard.
- By tapping any weight measurement item in your Timeline.

Once you're viewing the weight graph, you can view your body composition graphs and your BMI graph.

EN - 31 Withings Body+v4.1 | October 2020",

"How do I change my weight goal for Withings Body+?" : "Changing your weight goal To change your weight goal, perform the following steps:

1. Open the Withings Health Mate® app.
2. Select a weight measurement in the Timeline.
3. Tap the three dots at the top right of the screen.

EN - 32 Withings Body+v4.1 | October 2020

4. Tap Set your target weight.
5. Tap and slide up or down to select your target weight.
6. Tap Next.
7. Tap and slide up or down to select the pace at which you want to achieve your weight goal.

EN - 33 Withings Body+v4.1 | October 2020

8. Tap OK.”

"How do I retrieve and assign unknown measurements from Withings Body+?" : "Retrieving unknown measurements
If your Withings Body+ doesn't recognize you when you weigh in, your weight measurements will be listed as unknown measurements. To assign them to a user, perform the following steps: 1. Open the Withings Health Mate® app. 2. Go to Devices. 3. Select the Unknown measurement. EN - 34 Withings Body+v4.1 | October 2020 4. Tap the user you want to assign the measurement to. Your measurements are now assigned to the correct user. Your Withings Body+ will also be able to automatically assign your measurements the next time you weigh in. EN - 35 Withings Body+v4.1 | October 2020",

"How do I set reminders in the Withings Health Mate app for Withings Body+?" : "Setting reminders
The Withings Health Mate® app allows you to set reminders to make sure you weigh yourself regularly. To do so, perform the following steps: 1. Open the Withings Health Mate® app. 2. Go to Profile. 3. Tap Add. 4. Select the type of reminder you want to set. EN - 36 Withings Body+v4.1 | October 2020 5. Select the time and recurrence of the reminder. 6. Tap Add. EN - 37 Withings Body+v4.1 | October 2020",

"How do I check the weather on Withings Body+?" : "Checking the weather
Overview You can check the local weather forecast for the day directly on your Withings Body+ if the following conditions are met: • Your Withings Body+ is set up in Wi-Fi. Refer to "Changing the configuration of your Withings Body+" on page 19 for more information on how to switch to a Wi-Fi configuration. • The Weather screen is enabled. Refer to "Changing the screen order" on page 23 for more information. Retrieving weather information All you have to do to retrieve weather information on your Withings Body+ is to step on the scale and wait for the Weather screen to be displayed. The Weather screen provides you with information about the average weather and temperature for the morning (between 6:00 AM and 12:00 PM) and for the afternoon (between 12:00 PM and 9:00 PM). If you weigh yourself in the morning, the weather and temperature of the day is displayed. If you weigh after 7:00 PM, the weather and temperature of the next day is displayed. EN - 38 Withings Body+v4.1 | October 2020",

"How do I use Baby mode on Withings Body+?" : "Using Baby mode
Baby mode allows you to find out the weight of your baby by weighing yourself on the scale while holding your baby. To use this mode, you must create a profile for your baby in the Withings Health Mate® app. Then enter the height and weight of your baby and weigh yourself while holding your baby in your arms. The weight of your baby will be automatically detected by the scale. Important: your baby must weigh between 7 and 33 lbs (3 and 15 kg) to be detected by the scale. As Baby mode is enabled by default on the Withings Body+, you do not need to enable it in the Withings Health Mate® app. Follow the steps below to use Baby mode: 1. Create a profile for your baby in the Withings Health Mate® app. 2. Enter the height and weight of your baby. 3. Weigh yourself on your own. Your weight will be displayed on the screen of the Withings Body+. 4. Weigh yourself with your baby (within 5 minutes of first weighing yourself). The scale will display your weight plus your baby's weight, followed by the weight of your baby on its own. EN - 39 Withings Body+v4.1 | October 2020 For best results, we recommend you to weigh yourself when your baby is calm. Note: you can use Baby mode for several members of your family. For example, you may wish to add a profile for your baby to

your account or create a separate account for your baby. Please note that you can add up to 8 users to your Withings account. EN - 40 Withings Body+v4.1 | October 2020",

"How do I activate Pregnancy Tracker for use with Withings Body+?" : "Using Pregnancy Tracker Pregnancy Tracker provides an enriched Health Mate experience for pregnant women, offering advice, tips, and easy weight tracking throughout pregnancy. Pregnant women will receive the following information on a weekly basis in their Health Mate Timeline: •an overview of the week with the current stage of pregnancy and cumulative weight gain, along with how it compares with your personalized recommendations. •health-related and obstetrician-reviewed information relevant to the current week of pregnancy. Activating Pregnancy Tracker Pregnancy Tracker can be activated by any woman at any time during pregnancy. To do so, perform the following steps: 1 ♦ Open the Withings Health Mate® app ♦ 2. Go to Wellness Programs. 3. Tap Learn more. EN - 41 Withings Body+v4.1 | October 2020 4. Tap Join. EN - 42 Withings Body+v4.1 | October 2020",

"How do I link my Withings Body+ account to MyFitnessPal?" : "Linking your account to MyFitnessPal Overview When you monitor your weight, it can also be useful to monitor your calorie intake with apps such as MyFitnessPal to help you reach your weight goal. Once you link both accounts, your Withings account will be able to retrieve your daily calorie intake from MyFitnessPal. You can then check the MyFitnessPal widget from your Dashboard to see your calorie balance. MyFitnessPal can also retrieve information from your Withings account: your weight and your calorie outtake. Your calorie outtake is based on any activity data coming from a Withings activity tracker or the in-app tracking feature of the Withings Health Mate® app. Note that tracking your activity can be a great way to help you achieve your weight goal. Connecting to MyFitnessPal To connect your Withings account to your MyFitnessPal account, perform the following steps: 1. Open the Withings Health Mate® app. 2. Tap Profile. 3. Tap MyFitnessPal. 4. Tap Open. 5. Log in to your MyFitnessPal account. You can unlink your MyFitnessPal account and your Withings account anytime you want from your Profile. EN - 43 Withings Body+v4.1 | October 2020",

"How does data syncing work for Withings Body+?" : "Syncing Your Data Data from your Withings Body+ is automatically synced, without any action required on your part. Your weight data is synced with the Withings Health Mate® app within a few minutes after you weigh in. Note that if you sync your data in Bluetooth, it is necessary that a paired device is within range of the scale. The Withings Health Mate® app also needs to be running on your device. EN - 44 Withings Body+v4.1 | October 2020",

"How do I dissociate Withings Body+ from my account?" : "Dissociating Your Withings Body+ All data that wasn't synced before dissociating your Withings Body+ will be lost permanently. Dissociating your Withings Body+ allows you to remove it from your account. Dissociating your Withings Body+ will not remove any of the data that was synced from the Withings Health Mate® app. To dissociate your Withings Body+, perform the following steps: 1. Open the Withings Health Mate® app. 2. Go to Devices. 3. Tap Body+. 4. Tap Dissociate this product. EN - 45 Withings Body+v4.1 | October 2020 5. Tap Remove from my

account.6. Perform a factory reset of your Withings Body+. Refer to “Performing a Factory Reset of Your Withings Body+” on page 46 for more information.EN - 46Withings Body+v4.1 | October 2020”,

"How do I perform a factory reset of Withings Body+?" : "Performing a Factory Reset of Your Withings Body+All data that wasn't synced before factory resetting your Withings Body+ will be lost permanently.Factory resetting your Withings Body+ allows you to delete the data stored on it.Factory resetting completes the dissociation process.Factory resetting your Withings Body+ will not remove any of the data from the Withings Health Mate® app.1.Go to the Bluetooth settings of your device and “forget” your Withings Body+.from the list of Bluetooth devices.2.Remove one of the batteries for ten seconds.3.Put the battery back.4.When “Hello” appears on the display of your scale, press and hold the button at the back of the scale until the factory reset gauge fills.The scale's screen will display the word “Factory”, confirming the reset.At this time, you can start the installation process for the Withings Body+. Refer to “Setting Up the Withings Body+” on page 8 for more information.EN - 47Withings Body+v4.1 | October 2020”,

"How do I update Withings Body+?" : "Updating your Withings Body+We regularly offer updates so that you can benefit from the latest features we add to our products. When new internal software is available, it is automatically installed without any prompt from the Withings Health Mate® app if your scale is installed in Wi-Fi.However, you can check if updates are available and force their installation whenever you want. To do so, perform the following steps:1.Open Withings Health Mate® app.2.Go to Devices.EN - 49Withings Body+v4.1 | October 20203. Tap Body+.4. Tap Check for updates.5. Press the button at the back of the scale and tap Next.6. Tap Upgrade.7. Tap Close when the upgrade is complete.EN - 50Withings Body+v4.1 | October 2020Note: You can check which firmware version your Withings Body+ uses in Devices > Withings Body+.",

"How do I view Arlo Ultra camera feeds in Arlo Ultra Series 4K UHD Wire-Free Security Camera System (Arlo Ultra Camera and SmartHub)?" : "View your camera feeds1. Open the Arlo app.2. Tap the camera feed.The camera feed updates and camera feed icons display.3. To stop viewing and listening to the live feed, tap the Stop icon .",

"How does local live 4K streaming work for the Arlo Ultra camera in Arlo Ultra Series 4K UHD Wire-Free Security Camera System (Arlo Ultra Camera and SmartHub)?" : "Local live 4K streamingYou can live stream in 4K from Arlo Ultra if you use the Arlo app on a mobile device that's on the same local network as the Arlo SmartHub. If you enable 4K live streaming in your Arlo Ultra video settings, 4K live video streams when you tap Play on the camera stream in the Arlo app. You can also manually record in 4K by tapping the play button and then tapping Record .To enable local live 4K streaming:1. Open the Arlo app.2. Tap Settings > My Devices.3. Select the camera.4. Tap Video Settings.5. Tap Local 4K Live Streaming to toggle live streaming on and off.",

"How do I pan and zoom video in the Arlo app for Arlo Ultra Series 4K UHD Wire-Free Security Camera System (Arlo Ultra Camera and SmartHub)?" : "Pan and zoom video You can pan and zoom to focus in on the high-def details of any live or recorded video. Just pinch and drag any image as you do with photos on your smartphone.1. Open the Arlo app.2. Tap Library.3. Tap any live video or prerecorded video from your Arlo library.4. To pan and zoom using a mobile device:• Pinch to zoom in and out of the video.• Touch and drag to move around the zoomed-in frame.5. To pan and zoom using a computer:• Click the Zoom icon.• Use your mouse to move around the frame.20Arlo Ultra BasicsUltra Series 4K UHD Wire-Free Security Camera SystemUser Manual",

"How do I use Smart Zoom for live stream recordings on Arlo Ultra Series 4K UHD Wire-Free Security Camera System (Arlo Ultra Camera and SmartHub)?" : "Pan and zoom live video with Smart Zoom When you're viewing a live stream recording, Smart Zoom lets you zoom into any area of the recording up to 8x. The image quality of the zoomed-in area doesn't deteriorate, allowing you to view a zoomed-in image with true 1080p video resolution. When Smart Zoom is activated, your Arlo Ultra camera can zoom in on an object and track its movement when it detects motion in its field of view. Smart Zoom requires an Arlo Smart plan and you must turn it on for each camera. See Turn on Smart Zoom on page 54.1. Open the Arlo app.2. Tap Play on the camera feed. On a mobile device, use the pinch gesture to zoom, and touch and drag to move around the zoomed-in frame. On a computer, double-click to zoom. Left-click and hold and drag to move around the zoomed-in frame. After zooming in, the image stops and buffers for about five seconds to improve the quality of video. When the buffering stops, your zoomed-in video renders in high quality.",

"How does Look back video work on Arlo Ultra Series 4K UHD Wire-Free Security Camera System (Arlo Ultra Camera and SmartHub)?" : "Look back video When plugged in, your Arlo Ultra camera records continuously, but discards the video after three seconds if no motion is detected. This means that your motion-triggered video recordings start before any motion happens; you don't miss a thing.1. Plug in your Arlo Ultra camera.2. Make sure the camera is using a motion-detection mode such as Armed.",

"How do I record clips from live video on Arlo Ultra Series 4K UHD Wire-Free Security Camera System (Arlo Ultra Camera and SmartHub)?" : "Record clips from live video 1. Open the Arlo app.2. Tap the camera feed image.3. Tap Record to begin recording. This icon turns red to indicate that you are recording the live feed.4. To stop recording, tap Record again.",

"How do I take a snapshot from live video on Arlo Ultra Series 4K UHD Wire-Free Security Camera System (Arlo Ultra Camera and SmartHub)?" : "Take a snapshot from live video 1. Open the Arlo app.2. Tap the camera feed image.3. Tap Snapshot .The snapshot is saved in your library.",

"How do I use Talk and Listen on the Arlo Ultra camera for Arlo Ultra Series 4K UHD Wire-Free Security Camera System (Arlo Ultra Camera and SmartHub)?" : "Use Talk and Listen 1. Open the Arlo app.2. Tap the camera feed image.3. Tap Talk and Listen .4. The first

time you use Talk and Listen, allow Arlo to use your phone's microphone.5. Tap the microphone button.Two-way audio automatically opens, allowing you to use Talk and Listen.",

"How do I turn the camera spotlight on and off and adjust brightness on Arlo Ultra Series 4K UHD Wire-Free Security Camera System (Arlo Ultra Camera and SmartHub)?" : "Turn the camera spotlight on and offYou can use your Arlo Ultra camera spotlight at night for better video quality.When your camera is armed and detects motion at night the spotlight turns onautomatically. You can also adjust the spotlight behavior and turn it on and off.Turn the spotlight on and off from the camera feed1. Open the Arlo app.2. Tap the camera feed.3. Tap Spotlight .4. To adjust the brightness, tap and hold the icon and adjust the slider.22Arlo Ultra BasicsUltra Series 4K UHD Wire-Free Security Camera SystemUser Manual5. To turn off the spotlight, tap Spotlight .For information about how to customize the spotlight settings, see Change thecamera spotlight settings on page 57.",

"How do I turn the camera siren on and off on Arlo Ultra Series 4K UHD Wire-Free Security Camera System (Arlo Ultra Camera and SmartHub)?" : "Turn the camera siren on and off1. Open the Arlo app.2. Tap Siren on the upper right.3. Tap Activate Siren.If you have multiple Arlo Ultra cameras, you are prompted to select one.4. Swipe the siren icon to the right.The camera siren turns on.5. To turn off the siren, tap the slider at the top of the Devices page.",

"How do I customize the camera feed image, including camera order and rotation, on Arlo Ultra Series 4K UHD Wire-Free Security Camera System (Arlo Ultra Camera and SmartHub)?" : "Customize your camera feed imageIf you use more than one camera, you can change the order in which the camerafeeds display on the Devices page. You can also zoom, invert, or rotate the camerafeed image.Change the camera order1. Open the Arlo app.2. Tap Settings.3. Under SYSTEM, tap Device Order.4. If you are using a smartphone or tablet, tap Edit at the top of the page.A list icon displays.5. Tap and hold the list icon and drag each device to the correct position on the list.6. Tap Save.Invert a Camera FeedYou can invert the video feed image.1. Open the Arlo app.23Arlo Ultra BasicsUltra Series 4K UHD Wire-Free Security Camera SystemUser Manual2. Tap Settings > My Devices.3. Select the camera.4. Tap Video Settings.5. Rotate the image.If you're using an iOS device, tap Rotate Image 180°.If you're using an Android device, tap the slider to OFF and then rotate the image.",

"How do I add, change, or delete motion detection activity zones on Arlo Ultra Series 4K UHD Wire-Free Security Camera System (Arlo Ultra Camera and SmartHub)?" : "Motion detection activity zonesYou can designate zones within the camera view where you want the camera to detectand record motion. After you create the zones, you can select which zone or zonesdetect motion.Add an activity zone1. Open the Arlo app.2. Tap Settings > My Devices.3. Select the camera.4. Under VIDEO, tap Activity Zones.5. Tap +.An activity zone box displays in the camera feed image.6. Move the zone to the desired position in the camera feed image.7. To change the size or shape of the zone, drag the 8-points on the edges of thezone.8. To reposition the zone, tap and hold the zone and move it.9. To customize the zone name, tap Edit and enter a name.If you're using a web browser, click > next to the zone name.10. Tap Save.Change an activity zone1. Open the Arlo app.2. Tap Settings > My

Devices.24Arlo Ultra BasicsUltra Series 4K UHD Wire-Free Security Camera SystemUser Manual3. Select the camera.4. Under VIDEO, tap Activity Zones.5. Tap a zone to select it.6. Move the zone to the desired position in the camera feed image.7. To change the size or shape of the zone, drag the 8-points on the edges of the zone.8. To reposition the zone, tap and hold the zone and move it.9. To customize the zone name, tap Edit and enter a name. If you're using a web browser, click > next to the zone name.10. Tap Save.Delete an activity zone1. Open the Arlo app.2. Tap Settings > My Devices.3. Select the camera.4. Under VIDEO, tap Activity Zones.5. Tap a zone to select it.6. Delete the device. On an iOS device, slide the motion detection zone to the left and tap Delete. On an Android device, slide the motion detection zone to the left.",

"How do I view recordings and snapshots and access cloud recordings for Arlo Ultra Series 4K UHD Wire-Free Security Camera System (Arlo Ultra Camera and SmartHub)?" : "View recordings and snapshotsYour Arlo Ultra camera stores recordings and snapshots in the library. You can use the filter and the calendar to find and view specific recordings. Access cloud recordingsArlo Ultra cameras record when they are in an armed mode and they detect motion or sound. Your Arlo recordings are sent to your Arlo account in the cloud and stored in your library. Recordings are encrypted with your user name and password. You can access your recordings from the Arlo app on your mobile device or by using a web browser to visit <https://my.arlo.com/#/login>. You can",

"How do I download recordings from the Arlo library for Arlo Ultra Series 4K UHD Wire-Free Security Camera System (Arlo Ultra Camera and SmartHub)?" : "Download recordings1. Open the Arlo app.2. Tap Library.3. Tap a recording.4. Tap Download.5. Tap OK to confirm.",

"How do I mark recordings as favorite and share recordings for Arlo Ultra Series 4K UHD Wire-Free Security Camera System (Arlo Ultra Camera and SmartHub)?" : "Make a recording a favorite1. Open the Arlo app.2. Tap Library.3. Tap a recording.4. Tap Favorite. Share recordings1. Open the Arlo app.2. Tap Library.3. Tap a recording.4. Tap Share.5. Share the file.",

"How do I donate recordings for research and delete recordings for Arlo Ultra Series 4K UHD Wire-Free Security Camera System (Arlo Ultra Camera and SmartHub)?" : "Donate recordings for researchYou can donate video or snapshot files to Arlo to use for research and development of Arlo products.1. Open the Arlo app.2. Tap Library.3. Tap a recording.4. Tap Donate.5. Tap OK to confirm.27Arlo Ultra BasicsUltra Series 4K UHD Wire-Free Security Camera SystemUser ManualDelete recordings1. Open the Arlo app.2. Tap Library.3. Tap a recording.4. Tap Delete.5. Tap OK to confirm.",

"What is High Dynamic Range (HDR) and how does it work on the Arlo Ultra camera in Arlo Ultra Series 4K UHD Wire-Free Security Camera System (Arlo Ultra Camera and SmartHub)?" : "High Dynamic Range (HDR)HDR solves the problem with over- or under-exposed images of scenes with both bright and dark areas in the same picture. Your

Arlo Ultra camera automatically determines when to use HDR. HDR is optimized for outdoor environments. Your Ultracamera comes set to use HDR automatically, but you can turn it on and off. See Turn Auto HDR on and off on page 56."

"What does local 4K streaming and recording mean for Arlo Ultra Series 4K UHD Wire-Free Security Camera System (Arlo Ultra Camera and SmartHub)?" : "Local 4K streaming and recording 4K means you can see more details in every image, even when zoomed in. Your Arlo Ultra camera outputs 3840 x 2160 resolution at a 16 x 9 aspect ratio. Your Arlo Ultra camera streams 4K while providing: • 180-degree diagonal field of view that does real-time image de-warping • Real-time high dynamic range (HDR) • An integrated spotlight with dual noise-cancelling microphones The Arlo Ultra system does all of this processing in parallel and in real time. Efficient video encoding and battery optimization algorithms between the camera and the SmartHub allow 4K to work when your camera is running on battery power. To use 4K streaming, you need an Arlo Ultra camera paired with an Arlo SmartHub. For basic use of 4K, we recommend an average upload bandwidth speed of 3 Mbps per Ultra camera. You can stream 4K content without a subscription. You can use 4K by local livestreaming or recording 4K motion content onto a microSD card in the SmartHub. You can also purchase an add-on service to store 4K, motion-activated clips to the Arlo Cloud for access anywhere your mobile app has a data connection."

"What devices support HEVC 4K playback for the Arlo app used with Arlo Ultra Series 4K UHD Wire-Free Security Camera System (Arlo Ultra Camera and SmartHub)?" : "HEVC 4K playback supported devices High Efficiency Video Coding (HEVC) is a video compression standard that enables you to download and stream 4K videos with ease. To use HEVC on the Arlo app, you must use a supported device and meet the minimum requirements. Your device must: • Run iOS 9.0 or higher (Apple devices) • Run Android 5.0 or higher (Android devices) • Have the latest version of the Arlo app (for mobile) • Use a web browser that supports HEVC Note: To check if your web browser supports HEVC, visit <https://caniuse.com/#feat=hevc>. HEVC is supported on: • iPhone 7/7 Plus or newer • iPad Pro or newer • Samsung Galaxy S7/S7 Plus or newer • Galaxy Note 8 or newer • Google Pixel/Pixel XL or newer • Huawei P9 or newer • Xiaomi Mi 5 or newer • LG G5 or newer • HTC U10 or newer • Sony Xperia X or newer • Moto Z or newer • OnePlus 3 or newer."

"How do I start 4K streaming for the Arlo Ultra camera in Arlo Ultra Series 4K UHD Wire-Free Security Camera System (Arlo Ultra Camera and SmartHub)?" : "Start 4K streaming You can view live video in 4K from your Arlo Ultra camera if: • Your computer or mobile device is connected to the same local network as your Arlo SmartHub or base station. This lets you live stream 4K content. • You inserted a microSD card into your SmartHub and selected 4K video recording. This lets you record all motion events in 4K quality. See Turn local 4K recording off and on on page 61. 30 Image Quality Features Ultra Series 4K UHD Wire-Free Security Camera System User Manual • You subscribed to the Arlo Premier Video add-on service to store motion recordings in 4K quality to the Arlo Cloud to access wherever you have a mobile data connection."

"How do I turn local live streaming off and on for the Arlo Ultra camera in Arlo Ultra Series 4K UHD Wire-Free Security Camera System (Arlo Ultra Camera and SmartHub)?" : "Turn local live streaming off and on1. Open the Arlo app.2. Tap Settings > My Devices.3. Tap the camera.4. Tap Video Settings.5. Tap Local 4K Live Streaming.Local live streaming toggles off and on.",

"How do I turn 4K video recording off and on for Arlo Ultra Series 4K UHD Wire-Free Security Camera System (Arlo Ultra Camera and SmartHub)?" : "Turn 4K video recording off and on1. Open the Arlo app.2. Tap SmartHub/Base Station/Bridge > Storage Settings.3. Tap 4K Video Recording.4K recording toggles off and on.",

"How do I optimize connectivity when running multiple 4K streams for Arlo Ultra Series 4K UHD Wire-Free Security Camera System (Arlo Ultra Camera and SmartHub)?" : "Optimize multiple 4K streamsYou might experience connectivity issues if you're running multiple 4K live streams on your Arlo app. To optimize connectivity, check your network environment and adjust your Arlo Ultra camera settings as needed.Check your network environment:• If you're using a mobile device, make sure you're connected to your home router through the 5 GHz WiFi band.• Make sure your average bandwidth speed is at least 3 Mbps per Ultra camera.Note: To check your Internet speed, visit www.speedtest.net. The result of the Internet speed test might change, depending on varying amounts of traffic. For accurate results, run the speed test several times.If you're still experiencing connectivity issues after checking your WiFi connection and Internet speed, do the following tasks until your connection is back to normal.31Image Quality FeaturesUltra Series 4K UHD Wire-Free Security Camera SystemUser ManualAdjust your Arlo Ultra camera settings in the Arlo app:1. Change the power management settings on each camera to Optimized.Note: Do this on one camera at a time.See Change the video quality and battery usage on page 55.2. Change the power management settings on each camera to Best Battery Life.See Change the video quality and battery usage on page 55.3. Turn off 4K microSD card recording.See Turn SD card recording off and on on page 61.4. Turn off 4K local live streaming.See Turn local live streaming off and on on page 30.",

"What is Auto Zoom and Tracking and how does it work on Arlo Ultra Series 4K UHD Wire-Free Security Camera System (Arlo Ultra Camera and SmartHub)?" : "Auto Zoom and TrackingTo use Auto Zoom and Tracking and local live streaming, you need an Ultra Camera paired with an Arlo SmartHub.When your Ultra Camera detects motion, cloud motion recording is triggered. When Auto Zoom and Tracking is on, your Ultra Camera zooms in on the object and tracks its movement while the motion is within its field of view.If you're viewing a live stream recording, you can zoom in to any point of the Auto Zoom and Tracking recording. Your Ultra Camera uses its advanced image sensor to enhance the image quality of the zoomed-in area. (The zoomed-in image is in 1080p video resolution.)Your Ultra Camera automatically creates a curated Auto Zoom and Tracking clip. To access Auto Zoom and Tracking clips, tap Library in the Arlo app to view your library.",

"How do I use Auto Zoom and Tracking when live streaming for Arlo Ultra Series 4K UHD Wire-Free Security Camera System (Arlo Ultra Camera and SmartHub)?" : "Use Auto Zoom

and Tracking when you're live streaming1. Open the Arlo app.2. Tap the camera feed.3. Pinch and drag to zoom in to any area you would like to see enhanced.4. Let go after you have zoomed in.An indicator on the live feed shows that Arlo is enhancing the image.",

"What modes are available and what do modes and rules do for Arlo Ultra Series 4K UHD Wire-Free Security Camera System (Arlo Ultra Camera and SmartHub)?" : "Modes, Rules, and AlertsModes and rules let you tell your Arlo system what to do in different situations. Forexample, you can set your Arlo system to record a video when it detects motion andsend you an email alert.ModesArlo modes give you control over how your cameras respond to motion or sound Forexample, you probably don't want to receive an alert about motion in the living roomwhile you're doing yoga there. You might want to turn on a different mode whenyou're away on vacation than when you're out at the store for an hour. Modes let youtell your Arlo cameras to respond differently at different times.You can create your own modes, but the Arlo app comes with these modes:Armed. Detection is on for this camera.Disarmed. Detection is off for this camera.Schedule. Manage detection based on a schedule.Geofencing. You can arm, disarm, or resume a schedule mode when youarrive at, or leave, a given location based on your mobile device location.You can customize the Armed and Schedule modes and you can add new modes. Youmight want to create a mode in which some motion sensors and cameras are activebut others aren't. For example, when you're sleeping, you might want your exteriorcameras to be active, but your interior cameras to be inactive.Note: You can create different modes for the same camera, but the camera can onlyuse one mode at a time.34Modes, Rules, and AlertsUltra Series 4K UHD Wire-Free Security Camera SystemUser Manual",

"How do I select a mode for Arlo Ultra Series 4K UHD Wire-Free Security Camera System (Arlo Ultra Camera and SmartHub)?" : "Select a modeYou can select a mode or set modes to activate according to a schedule.1. Open the Arlo app.2. Tap Mode.3. Tap the SmartHub.A list of modes displays.4. Tap a mode to activate it.The mode that you selected turns on immediately. The mode stays active until youchange it.",

"How do I mute notifications and unmute notifications for Arlo Ultra Series 4K UHD Wire-Free Security Camera System (Arlo Ultra Camera and SmartHub)?" : "Mute NotificationsMute Notifications temporarily silences push notifications to your mobile device,while videos continue to be recorded. This is great for a party when you don't need tobe notified of friends in your backyard.You can mute notifications from the Arlo app. If you use Arlo Smart, you can alsoactivate Mute Notifications directly from push notifications.To mute notifications:1. Open the Arlo app.2. Tap Settings > Mute Notifications.3. Select the length of time to mute notifications.A message displays confirming that you are muting notifications. The MuteNotification status shows the amount of remaining time until notifications resume.To unmute notifications1. Open the Arlo app.2. Tap Settings > Mute Notifications > Unmute.The Mute Notifications status changes to Off.35Modes, Rules, and AlertsUltra Series 4K UHD Wire-Free Security Camera SystemUser Manual",

"What are rules for modes and how do trigger and action devices work on Arlo Ultra Series 4K UHD Wire-Free Security Camera System (Arlo Ultra Camera and SmartHub)?" : "Rules for

modes Each mode uses one or more rules to control your Arlo system. You can set these options.

- Trigger device. The trigger device is the camera that detects motion or sound. You can adjust the motion and sound sensitivity to minimize false alarms.
- Action device. The action device responds to motion or sound detection on the trigger device. For example, you might want your backyard camera or your driveway camera to trigger your door camera to start recording video. You decide what action each Arlo Ultra Camera takes when motion or sound is detected.
- Notifications. When a trigger is detected, the Arlo can send you push notifications, email alerts, or both. You can also send email alerts to friends, family members, pet sitters, or anyone who might need to respond when a camera is triggered.

"How do I change motion sensitivity for Arlo Ultra cameras in Arlo Ultra Series 4K UHD Wire-Free Security Camera System (Arlo Ultra Camera and SmartHub)?" : "Change motion sensitivity You can edit a rule to change the motion sensitivity level for your Arlo Ultra cameras.

1. Open the Arlo app.
2. Tap Mode.
3. Tap the SmartHub.
4. Tap Edit next to the mode.
5. Tap Edit next to the rule.
6. Under If the following, tap Edit next to Motion is detected.
7. Move the slider to adjust the sensitivity level for motion detection for this camera. If you used a mobile device to specify the settings, your settings are saved.
8. If you used a browser to specify the settings, click Save.

"How do I control whether the spotlight turns on when motion is detected at night for Arlo Ultra Series 4K UHD Wire-Free Security Camera System (Arlo Ultra Camera and SmartHub)?" : "Control whether the spotlight turns on when motion is detected at night Unless you changed its settings, your Arlo Ultra camera automatically turns on its spotlight when it detects motion at night. Your camera detects motion when it's in Armed mode or another mode that uses a rule for detecting motion. When the spotlight turns on at night, it allows your Arlo Ultra camera to record video in color. Note: You can also turn the spotlight on and off from the camera feed. (See Turn the camera spotlight on and off on page 21. To control whether the spotlight turns on when motion is detected, you can change the low-light settings for your camera.

1. Open the Arlo app.
2. Tap Settings > My Devices.
3. Tap the Arlo Ultra camera.
4. Tap Video Settings > Low Light Settings.
5. Tap Spotlight to toggle the setting off and on.

"How do I change audio sensitivity for Arlo Ultra Series 4K UHD Wire-Free Security Camera System (Arlo Ultra Camera and SmartHub)?" : "Change audio sensitivity

1. Open the Arlo app.
2. Tap Mode.
3. Tap the SmartHub.
4. Tap Edit next to the mode.
5. Under If the following, tap Edit next to Audio is detected.

37 Modes, Rules, and Alerts Ultra Series 4K UHD Wire-Free Security Camera System User Manual

6. Move the slider to the desired level of audio detection. If you used a mobile device to specify the settings, your settings are saved.
7. If you used a browser to specify the settings, click Save.

"How do I manage alerts (push notifications and email alerts) for Arlo Ultra Series 4K UHD Wire-Free Security Camera System (Arlo Ultra Camera and SmartHub)?" : "Manage alerts Arlo can push notifications to your smartphone, send you email alerts, or do both. To receive Arlo notifications on your phone, you must install the Arlo app on your

phone. Note: If you log out of the Arlo app on your smartphone or mobile device, you will stop receiving push notifications. 1. Open the Arlo app. 2. Tap Mode. 3. Tap the SmartHub. 4. Tap Edit next to the mode. Note: The Disarmed mode does not send alerts. 5. Under Alert, tap Push Notification to turn alerts on and off for your mobile device. 6. Under Alert, tap Email Alerts to turn email notifications on and off. 7. To specify an email address, tap Edit next to Email Alerts and enter the email address. For information about Arlo Smart Alarm Detection, see Arlo Smart Alarm Detection on page 43.",

"How do I schedule camera rules and add or edit schedules for Arlo Ultra Series 4K UHD Wire-Free Security Camera System (Arlo Ultra Camera and SmartHub)?" : "Schedule your camera rules You can set a schedule to arm and disarm cameras automatically. Schedules recur weekly. For example, the schedule for Tuesday repeats every Tuesday as long as the schedule is turned on. Your cameras are automatically set with this schedule: • Monday through Friday, 8:00 a.m. to 5:00 p.m. All motion sensors are on. • All other times. All motion sensors are off. Edit a schedule 1. Open the Arlo app. 2. Tap Mode. 3. Tap the SmartHub. 4. Tap Schedule. 5. Tap Edit next to Schedule. 6. Tap a green box. 7. Change the start and stop times and tap Save.",

"How do I set up Arlo Geofencing for Arlo Ultra Series 4K UHD Wire-Free Security Camera System (Arlo Ultra Camera and SmartHub)?" : "Set up Arlo Geofencing Geofencing is a virtual fence around a location called a zone. You can use Arlo Geofencing to arm, disarm, or resume schedule modes when your mobile device is in zone or out of zone. To set up geofencing, you must use your mobile device and allow the Arlo app to use your location. 39 Modes, Rules, and Alerts Ultra Series 4K UHD Wire-Free Security Camera System User Manual",

"How accurate is geofencing and how do I prepare my mobile device for geofencing on Arlo Ultra Series 4K UHD Wire-Free Security Camera System (Arlo Ultra Camera and SmartHub)?" : "Geofencing accuracy For accuracy, geofencing uses a combination of GPS, cellular data, and WiFi data. The local environment affects geofencing: • In urban environments, where the cell towers and WiFi routers are more dense, geofencing accuracy can reach 100–200 meters. Note: If you live in a skyscraper, geofencing might not work reliably due to GPS inaccuracies. Using the Large radius setting might help. • In rural areas, where cell towers and WiFi routers are sparse, geofencing accuracy can reach several hundred meters. To improve geofencing accuracy, make sure that your mobile device meets these conditions: • WiFi is turned on. • GPS or location services are turned on. Prepare your mobile device for geofencing 1. Enable GPS or location services so that Arlo can locate your device. 2. Enable WiFi. 3. Download the Arlo app and log in on each mobile device that you plan to enable for geofencing. For Arlo Geofencing to work on your device, you must adjust the settings on your Android or iOS mobile device as follows: Android devices • Location permission = On • Location services = On • Battery saver = Off • Data limit = Off • Airplane mode = Off iOS (Apple) devices • Share my location = On • Location services = Always • Airplane mode = Off 40 Modes, Rules, and Alerts Ultra Series 4K UHD Wire-Free Security Camera System User Manual",

"How do I set up geofencing for the first time and set up home/away modes for Arlo Ultra Series 4K UHD Wire-Free Security Camera System (Arlo Ultra Camera and SmartHub)?" : "Set up geofencing for the first time and set up modes1. Open the Arlo app.2. Tap Mode.3. Tap the SmartHub.4. Tap Geofencing .5. Allow the Arlo app to use your mobile device's location.Geofencing works only if Arlo can locate your mobile device. The LocationAddress page displays your current address.6. To change the radius setting, tap Radius and select a radius size.Radius size sizes are Small, Medium, and Large (approximately 150 meters, 250meters, and 500 meters, respectively).7. Tap Device Location and enter a name for your location.8. Tap Away Mode and select a mode.Your camera uses the Away mode when your mobile device is outside the radiusof your camera's location. Most people select Armed, Schedule, or Custom Modeso that the camera detects motion while they're gone.9. Tap Home Mode and select a mode.Your camera uses this mode when your mobile device is within the radius of yourcamera's location. Most people select Disarmed while they're home.If you use more than one enabled mobile device, you might be asked to select anArlo device to connect it to.10. To select the preferred mobile device, tap the device and then tap Next.11. Tap Save.For troubleshooting tips, see Troubleshoot Arlo Geofencing on page 71.",

"How do I enable or disable geofencing for friends' mobile devices for Arlo Ultra Series 4K UHD Wire-Free Security Camera System (Arlo Ultra Camera and SmartHub)?" : "Enable or disable geofencing for friends' mobile devices1. Open the Arlo app.2. Tap Mode.3. Tap the SmartHub.4. Tap Edit next to Geofencing.5. Tap Enabled Devices.A list of mobile devices displays. A check mark appears next to the device namewhen geofencing is enabled.6. Tap one or more mobile devices.42Modes, Rules, and AlertsUltra Series 4K UHD Wire-Free Security Camera SystemUser ManualThe device location displays as either In Zone, Out of Zone, or Unavailable (ifthere's an issue contacting that device).7. To disable geofencing, tap the mobile device again.The check mark disappears when geofencing is disabled.For more information, see Set up geofencing on page 38.",

"How do I add custom modes and add a mode for Arlo Ultra Series 4K UHD Wire-Free Security Camera System (Arlo Ultra Camera and SmartHub)?" : "Custom modesYou can add modes in addition to the modes that come with the Arlo app and givethe new modes custom names, such as Vacation. You can create one rule for eachmode.You can create multiple rules within the same mode so that each camera performsdifferent actions and sends different alerts. You can also use Schedule mode toactivate modes automatically at different times of the day or week. (See Add aschedule on page 37.)Add a mode1. Open the Arlo app.2. Tap Mode.3. Tap the SmartHub.4. Tap Add a Mode.5. Enter the mode name and tap Next.6. Select the trigger device and tap Next.This is the camera that detects motion and/or sound.7. Enter the trigger device settings for the When motion is detected and Whenaudio is detected sections and then tap Next.8. Use the slider to set the motion sensitivity for the trigger device and tap Next.Higher motion sensitivity settings usually trigger your camera to capture videosmore frequently.9. Set the audio sensitivity for the trigger device and tap Next.10. Select an action device and tap Next.43Modes, Rules, and AlertsUltra Series 4K UHD Wire-Free Security Camera SystemUser ManualThis is the Arlo device that performs an action when the trigger device detectsmotion or sound. You can select the same Arlo device

you're using as a trigger or a different Arlo device. 11. Select an action and tap Next. For an Arlo Ultra camera, you can select Record video, Turn alarm ON, or Do nothing. If you're using a computer web browser, you can also specify the recording time setting. 12. Select the notifications for Arlo to send when motion or audio is detected and then tap Next. 13. Review your settings and tap Save."

"How does Arlo Smart Alarm Detection work and what alarms are compatible for Arlo Ultra Series 4K UHD Wire-Free Security Camera System (Arlo Ultra Camera and SmartHub)?" :
"Detect audio alarms with your Ultra camera To use Alarm Detection, you need an Arlo Smart subscription. For information about Arlo Smart, visit What are the available Arlo subscription plans and how much cloud recording is available?. Arlo Smart Alarm Detection notifies your Arlo app when your camera detects the sound of a smoke or carbon monoxide (CO) alarm going off. Your camera records until activity stops or for the length of time you specify (up to a maximum of 300 seconds). Compatible alarms We recommend that you test the compatibility of your alarm with the Alarm Detection feature. The Alarm Detection feature recognizes these alarms: • Smoke detectors with industry-standard T3 alarms (three intermittent beeps, followed by a period of silence). • Carbon monoxide (CO) detectors with industry-standard T4 alarms (four intermittent beeps, followed by a period of silence). The Alarm Detection feature doesn't detect alarms with other patterns. Newer smoke detectors tend to emit a T3 alarm (three intermittent beeps followed by a period of silence), and carbon monoxide detectors emit a T4 alarm (four intermittent beeps followed by a period of silence). 4.4 Modes, Rules, and Alerts Ultra Series 4K UHD Wire-Free Security Camera System User Manual Some examples of detector models that emit compatible T3 and T4 signals include: • Kidde i9050 • USI 5304 • First Alert 0827 • First Alert P1210 • First Alert SC05 To determine your detector's alarm pattern, see the instructions that came with your detector or search online for product information."

"How do I prepare and test my alarm for compatibility with Alarm Detection for Arlo Ultra Series 4K UHD Wire-Free Security Camera System (Arlo Ultra Camera and SmartHub)?" :
"Prepare a location to test your alarm compatibility We recommend that you test your alarm to find out if it is compatible with the Arlo Alarm Detection feature. Before beginning a test, make sure that: • Your smoke and carbon monoxide detectors can emit a continuous T3 or T4 pattern for 30 seconds during the test. If you're not sure if the test button on your alarm can do this, check the instructions that came with your alarm or search online for product information. • The alarm location doesn't generate echoes and doesn't have sounds that are louder than the alarm. • There won't be motion in your camera's field of view while you conduct the alarm test. If the camera detects motion during the test, it might not be clear whether the camera also detected the alarm. Test your alarm for compatibility with Alarm Detection 1. During the test, place your Arlo Pro 3 Camera within two feet of your alarm. After a successful compatibility test, you can move your camera to a different location and test the Alarm Detection range. 2. Open the Arlo app. 3. Make sure that your Pro 3 Camera is in Armed mode or another mode in which it can detect sound and motion. 4. Tap Settings > Smart Notifications. 5. Select an Arlo Pro 3 camera. 6. In the Audio Alerts section, select Smoke/CO Alarm and make sure that Other Audio is turned off. 4.5 Modes, Rules, and

Alerts Ultra Series 4K UHD Wire-Free Security Camera System User Manual 7. Close the Arlo app, but don't log out. 8. Use the test button on your smoke or carbon monoxide detector to activate the alarm for 30 seconds. Compatible alarms sound continuously for 20 seconds in one of these patterns:

- Smoke detectors with industry-standard T3 alarms emit three intermittent beeps, followed by a period of silence.
- Carbon monoxide (CO) detectors with industry-standard T4 alarms emit four intermittent beeps, followed by a period of silence."

"What do the Alarm Detection test results mean for Arlo Ultra Series 4K UHD Wire-Free Security Camera System (Arlo Ultra Camera and SmartHub)?" : "Alarm Detection test results The following sections explain the test results. Alarm Detection is working You received an Audio Alert push notification from the Arlo app on your mobile device and a video clip labeled Smoke/CO alarm? is saved in your Arlo Library. This means that your camera is within range of your alarm, and your alarm is compatible with the Alarm Detection feature. Note: Arlo cameras use battery power every time they record, so it's important that you're aware when you have audio alert options turned on. You can purchase spare batteries and the Arlo Dual Battery Charging station, sold separately, if desired. Arlo recorded a video but didn't notify you If you don't receive an Audio Alert push notification, but video clip labeled Audio is saved in your Arlo Library, your camera is within range of your smoke or CO detector, but it did not recognize the sound pattern as a smoke or CO alarm. You might not be notified for these reasons:

- Your smoke or CO detector did not emit a continuous T3 or T4 alarm pattern.
- There is too much background noise or an echo where your camera is located.
- Your alarm is not compatible with the Alarm Detection feature.

We recommend that you perform the test again to confirm the results. Arlo didn't notify you or record a video The camera too far from the alarm to detect it. Move your Arlo camera closer to your alarm and perform the test again.

46 Modes, Rules, and Alerts

Ultra Series 4K UHD Wire-Free Security Camera System User Manual

Test the Alarm Detection range

After a successful compatibility test, we recommend that you test the Alarm Detection range when you move your camera to a different location.

1. Place your Arlo Pro 3 Camera in the desired location.
2. Open the Arlo app.
3. Make sure that your Pro 3 Camera is in Armed mode or another mode in which it can detect sound and motion.
4. Make sure that you selected Smoke/CO Alarm in the Audio Alerts setting for your camera and that Other Audio is turned off.
5. Close the Arlo app, but don't log out.
6. Use the test button on your smoke or carbon monoxide detector to activate the alarm for 30 seconds.
7. After a successful test, aim the camera toward the area of highest interest so that you can view the relevant videos when you get a notification."

"How do I turn off audio detection and push notifications after using audio detection for Arlo Ultra Series 4K UHD Wire-Free Security Camera System (Arlo Ultra Camera and SmartHub)?" : "Turn off audio detection Audio detection must be turned on if you're using audio alerts so that your camera wakes up when there is a sound. To turn off audio detection, you must first turn off Audio Alerts.

1. Open the Arlo app.
2. Tap Settings > Smart Notifications.
3. Select a camera.
4. In the Audio Alerts section, deselect the slider next to Smoke/CO Alarm and All Other Audio settings.
5. Return to Settings.
6. Tap Smart Notifications, and deselect the slider next to Detects Audio.

To turn off push notifications:

- 1.

Open the Arlo app.2. Tap Mode.3. Tap the SmartHub.4. Tap Edit next to the mode.5. Tap Edit next to the rule.6. Tap Push Notifications to turn it off and on.",

"How do I use SD card storage with the SmartHub for Arlo Ultra Series 4K UHD Wire-Free Security Camera System (Arlo Ultra Camera and SmartHub)?" : "Use SD Card StorageYou can insert a microSD card into your Arlo SmartHub and store your Arlo recordingsboth in the cloud and on the SD card. If the SmartHub isn't connected to the Internet,recordings continue to be saved on the microSD card. If you have an active livestream connection between an Arlo Ultra camera and a SmartHub, you can record to a microSD card. Your Arlo app notifies you when the SD card is low on storage spaceor is full.",

"What microSD card formats and recommendations apply to the SmartHub for Arlo Ultra Series 4K UHD Wire-Free Security Camera System (Arlo Ultra Camera and SmartHub)?" : "MicroSD card formatYour SmartHub accepts SDHC or SDXC microSD cards. We recommend usingmicroSD cards with a minimum of 16 GB capacity, Speed Class 10, UHS-I, V10. YourArlo SmartHub supports up to Class 10 UHS-3 V90.If your microSD card isn't formatted or is formatted with an incompatible file system,you can use your Arlo app to format the microSD card. See Format a microSD card onpage 62.",

"How do I insert a microSD card into the SmartHub for Arlo Ultra Series 4K UHD Wire-Free Security Camera System (Arlo Ultra Camera and SmartHub)?" : "insert a microSD card into your Arlo SmartHub and store your Arlo recordingsboth in the cloud and on the SD card. If the SmartHub isn't connected to the Internet,recordings continue to be saved on the microSD card. If you have an active livestream connection between an Arlo Ultra camera and a SmartHub, you can record to a microSD card. Your Arlo app notifies you when the SD card is low on storage spaceor is full.MicroSD card formatYour SmartHub accepts SDHC or SDXC microSD cards. We recommend usingmicroSD cards with a minimum of 16 GB capacity, Speed Class 10, UHS-I, V10. YourArlo SmartHub supports up to Class 10 UHS-3 V90.If your microSD card isn't formatted or is formatted with an incompatible file system,you can use your Arlo app to format the microSD card. See Format a microSD card onpage 62.Insert a microSD card1. Insert the microSD card into the slot on the bottom of the SmartHub.2. Press the edge of the microSD card until it's completely seated in the slot.",

"How do I view SD card status and available storage for Arlo Ultra Series 4K UHD Wire-Free Security Camera System (Arlo Ultra Camera and SmartHub)?" : "View the SD card status1. Open the Arlo app.2. Tap SmartHub/Base Station/Bridge.3. Check the SD card icon . When a microSD card is inserted in the SmartHub, thisicon is amber .4. To view more information about the microSD card status, under LOCAL STORAGE,tap Storage Settings.The SD Card Status displays GOOD or indicates if the SD card needs to beformatted, or is full. The Arlo app also notifies you if this occurs.View available SD card storageThe Arlo app notifies you if the SD card is getting full, but you can also view theavailable storage.1. Open the Arlo app.2. Tap SmartHub/Base Station/Bridge > Storage Settings.The Available Storage field displays the amount of storage available on the SDcard.",

"How do I turn SD card recording and local 4K recording off and on for Arlo Ultra Series 4K UHD Wire-Free Security Camera System (Arlo Ultra Camera and SmartHub)?" : "Turn SD card recording off and on.1. Open the Arlo app.2. Tap SmartHub/Base Station/Bridge.3. Select the SmartHub.4. Tap Storage Settings > SD Card Recording.SD card recording toggles off and on.Turn local 4K recording off and onThe SmartHub recordings saved onto the SD card are 1080p, but you can change this setting and save 4K recordings onto the SD card.1. Open the Arlo app.2. Tap SmartHub/Base Station/Bridge",

"How do I change the SD card overwrite setting for Arlo Ultra Series 4K UHD Wire-Free Security Camera System (Arlo Ultra Camera and SmartHub)?" : "Change the SD card overwrite settingBy default, if the SD card fills up, the oldest Arlo recording is erased to make room for new recordings. Files on the SD card that aren't in the Arlo folder aren't deleted to make room for Arlo recordings. You can change the setting so that no Arlo recordings are automatically erased.1. Open the Arlo app.2. Tap Base Station & Bridge > Storage Settings.3. Tap Overwrite Automatically.The overwrite setting toggles off and on.",

"How do I format and safely eject a microSD card for Arlo Ultra Series 4K UHD Wire-Free Security Camera System (Arlo Ultra Camera and SmartHub)?" : "Format a microSD cardYour SmartHub accepts micro SD cards, SDHC or SDXC only, file format FAT32. The Arlo app displays a message to let you know if you need to format the SD card. The SmartHub can format the SD card.1. Open the Arlo app.2. Tap SmartHub/Base Station/Bridge > Local Storage.3. Tap the red Format SD Card button.Safely eject an SD cardIt's important to safely remove the microSD card from your SmartHub. If you remove an SD card while information is being recorded on it, the SD card might become permanently unusable or the files on the card might be corrupted.1. Open the Arlo app.2. Tap SmartHub/Base Station/Bridge > Local Storage.3. Tap Safely Eject SD Card.4. Wait for the Unmounting SD Card progress message to close.5. Remove the SD card from your SmartHub by pressing in on the edge of the card.6. Use SD Card StorageUltra Series 4K UHD Wire-Free Security Camera System User Manualuntil it ejects.Do not interrupt power to the SmartHub or remove the SD card while unmounting the SD card.6. The SD card icon changes from amber to gray indicating that no microSD card is in the slot.Arlo SD card recording is disabled until you insert another SD card.",

"How do I view videos on a microSD card for Arlo Ultra Series 4K UHD Wire-Free Security Camera System (Arlo Ultra Camera and SmartHub)?" : "View videos on a microSD cardTo view Arlo videos saved on a microSD card, you must remove the microSD card from your SmartHub and use a microSD card reader.The microSD card reader can be part of your computer or a memory card reader with a USB or micro USB connector. If you purchase an SD card reader, make sure that you choose one that can read microSD cards.1. Safely eject the microSD card.For more information, see Safely eject an SD card on page 62.2. Insert the microSD card into the slot in your card reader.3. Wait for the microSD card to appear in the list of available drives on your computer, and then open the drive folder to view the files on your microSD card.4. Open the Arlo folder.Recorded videos are saved in this folder in MP4 format. Video files are named according to this system: camera serial number_video

number_date_video cliptag. Dates are in the format YYYYMMDD. Note: If you're unable to play MP4 files on your computer, update your media player software to the latest version and try again. You can also download a free universal multimedia player, such as VLC."

"How do I use Arlo with Amazon Alexa for Arlo Ultra Series 4K UHD Wire-Free Security Camera System (Arlo Ultra Camera and SmartHub)?" : "Use Arlo with Amazon Alexa With the Arlo Skill and Alexa, you can access your Arlo devices using voice commands and view a live camera feed on your Echo Show, Fire TV, or Fire tablet. Alexa can also notify you when motion is detected by your Arlo cameras. To use the Arlo Skill, you need a connected Ultra Camera and one of these Amazon devices: • Echo Show • Echo Spot • Echo Dot • Echo, Echo Plus • Fire tablets (7th generation or newer) • Fire TV (all generations) • Fire TV stick (second generation only) • Fire TV Edition smart TVs Enable the Arlo Skill Make sure that your Ultra Camera is powered on and connected to the cloud. Enable the Arlo skill in one of these ways: • Ask Amazon Alexa "Alexa, enable Arlo skill" to receive instructions in your Alexa app to link your Arlo account with your Alexa account. • In the Alexa app, search for the Arlo Skill and select Enable Skill to link your Arlo account with your Alexa account. 65 Arlo Connect Ultra Series 4K UHD Wire-Free Security Camera System User Manual Use the Arlo Skill After you enable the Arlo Alexa Skill, you can try using these commands: • "Alexa, show me <camera name>." Start streaming a camera live. • "Alexa, stop." Stop an activity and return to your device's home screen. • "Alexa, hide <camera name>." Stop streaming from a camera and return to your device's home screen. • "Alexa, go home." Return to your device's home screen. • "Alexa, show the last motion detected by my <camera name>." To use this command, your Arlo subscription must include viewing past video clips for your camera. Set up Alexa to notify you when a camera detects motion You can use either of these methods: • In the Smart Home section of the Alexa app, turn on Announcements for your Arlo camera. • Create an Alexa Routine from the Alexa app main menu."

"How do I add Arlo devices to the Apple Home app for Arlo Ultra Series 4K UHD Wire-Free Security Camera System (Arlo Ultra Camera and SmartHub)?" : "Add Arlo devices to the Apple Home app For the best experience, add your Arlo devices to your Arlo account before you add them to the Apple Home app. When you add your SmartHub (model VMB5000) to the Apple Home app, all Arlo devices that are paired to the SmartHub are available in the Home app. There are two different ways to add your Arlo SmartHub to the Home app, depending on whether your SmartHub has a HomeKit sticker. Add a SmartHub with a HomeKit sticker to the Home app 1. Locate the HomeKit setup code. The code is on a sticker located on the back or the bottom of your Arlo SmartHub. Sample HomeKit setup code 66 Arlo Connect Ultra Series 4K UHD Wire-Free Security Camera System User Manual 2. Open the Apple Home app. 3. Tap + at the top of the page on the Home tab and then tap Add Accessory. Your Apple mobile device's camera launches and you're prompted to scan or enter the HomeKit setup code. 4. Scan the HomeKit setup code using your mobile device's camera. If you have trouble scanning the code, tap Don't Have a Code or Can't Scan? and then enter the code. 5. Tap Done on the top right. After you add the SmartHub, all Arlo devices that are paired with the SmartHub are available in HomeKit. For live video, tap the camera screen shot. Add a SmartHub without a HomeKit sticker to the Home app If your SmartHub does not

have a sticker with a HomeKit setup code, use this method. Note: This method doesn't work if your SmartHub has a HomeKit setup code. To add the SmartHub:

1. Open the Arlo app.
2. Tap Settings > My Devices.
3. Tap the SmartHub.
4. Tap HomeKit.
5. Select a Home or tap Add New Home.
6. Select a Room or tap Add a New Room.
7. Tap Continue to add cameras or other devices to HomeKit.

After you add the SmartHub, all Arlo devices that are paired with the SmartHub are available in HomeKit.

8. Follow the onscreen instructions to name each device.

Note: The name that you give each device is used for Siri commands. Choose a unique name that is easy to remember and pronounce.

9. Complete the set up for your devices and then tap Finish.

67 Arlo Connect Ultra Series 4K UHD Wire-Free Security Camera System User Manual",

"How do I add Arlo Ultra to the Google Assistant app for Arlo Ultra Series 4K UHD Wire-Free Security Camera System (Arlo Ultra Camera and SmartHub)?" : "Add Arlo Ultra to the Google Assistant app To use your Ultra Camera with Google Assistant, you need:

- A Google Home Hub, a Chromecast device, a TV with Chromecast, or a media player with Chromecast
- The Google Assistant app on your mobile device. This app is included with most Android devices, but you can also download it from the Apple App Store on iOS devices.

To connect your Arlo cameras to the Google Assistant app:

1. If you plan to use a voice-enabled speaker with the Google Assistant, set up that device.
2. Open the Google Assistant app to the home page.
3. Tap the + icon.
4. Tap Set up Device > Have something already set up?
5. Select the Arlo icon from the list of device options. You can search for Arlo or scroll down to find Arlo on the list of devices.
6. Sign in with your Arlo account. Your camera is added to Google Assistant.
7. To test your camera, say "Hey Google, show [name of room where camera is placed] on [name of Google device]."
8. To end the stream, say "Hey Google, stop [name of Chromecast device]."

For more information, see Google Assistant Help: Control smart home devices.",

"How do I use Arlo with IFTTT for Arlo Ultra Series 4K UHD Wire-Free Security Camera System (Arlo Ultra Camera and SmartHub)?" : "Use Arlo with IFTTT You can use the Arlo app with IFTTT (If This Then That), a free cloud-based service that connects smart home devices and applications. To add Arlo to your IFTTT app, visit ifttt.com/arlo. To learn more about Arlo and IFTTT, visit arlo.com/community.",

"How do I change the Arlo camera name and view camera settings for Arlo Ultra Series 4K UHD Wire-Free Security Camera System (Arlo Ultra Camera and SmartHub)?" : "camera settings.

7. Tap Done.

Delete a friend

1. Open the Arlo app.
2. Tap Settings.
3. Under ACCOUNT, tap Grant Access.
4. Select the friend, and tap Edit.
5. Tap Delete Friend.
6. Tap Yes.

Change the time zone

1. Open the Arlo app.
2. Tap Settings > My Devices.
3. Tap the SmartHub.
4. Tap Time Zone.
5. Tap a time zone. If you're using a mobile device, your settings are saved.
6. If you're using a computer, click Save.

Camera settings You can view or change the settings for each camera using either of these methods:

- Tap Settings > My Devices and select the camera
- Tap the Menu icon or the Device Settings icon below the camera feed.

55 Change Your Settings

Ultra Series 4K UHD Wire-Free Security Camera System User Manual

Change the camera name

1. Open the Arlo app.
2. Tap Settings > My Devices.
3. Tap the camera.
4. Tap Edit

next to the camera name.5. Enter a new name that reminds you of the camera's location, such as Garage or Front Door. Camera names are limited to 32 characters.6. Tap Save.",

"How do I change video quality and battery usage and adjust low light settings for Arlo Ultra Series 4K UHD Wire-Free Security Camera System (Arlo Ultra Camera and SmartHub)?" :

"Change the video quality and battery usage You can set the video resolution as Best Video, Optimized, or Best Battery Life. Using the Best Battery Life setting reduces the WiFi bandwidth that is required.1. Open the Arlo app.2. Tap Settings > My Devices.3. Tap the camera.4. Tap Video Settings > Power Management.5. Tap to select Best Battery Life, Optimized, or Best Video. Turn color video recording at night off and on.1. Open the Arlo app.2. Tap Settings > My Devices.3. Tap the camera.4. Tap Video Settings > Low Light Settings.5. Tap Color. The Color setting toggles on and off. Turn night vision on and off. When night vision is enabled, the camera automatically turns on infrared (IR) LEDs to record in low-light conditions. We recommend that you turn off night vision if the camera is facing reflective surfaces, such as windows.1. Open the Arlo app.2. Tap Settings > My Devices.3. Tap the camera.4. Tap Video Settings > Low Light Settings.5. Tap Night Vision. If you're using an Android device, tap the slider.57 Change Your Settings Ultra Series 4K UHD Wire-Free Security Camera System User Manual Turn Auto HDR on and off.1. Open the Arlo app.2. Tap Settings > My Devices.3. Tap the camera.4. Tap Video Settings.5. Tap Auto HDR. If you're using an Android device, tap the slider.",

"How do I change camera audio settings and spotlight settings for Arlo Ultra Series 4K UHD Wire-Free Security Camera System (Arlo Ultra Camera and SmartHub)?" :

"Change the camera audio settings You can adjust the settings to reduce wind noise, turn the microphone off and on, and adjust the speaker.1. Open the Arlo app.2. Tap Settings > My Devices.3. Tap the camera.4. If you're using a mobile device, tap Audio Settings.5. Adjust the settings: • Reduce Wind Noise toggle turns this feature off and on. • Microphone toggle turns the microphone off and on. • Speaker toggle and volume. To turn the speaker off and on, tap Speaker. To change the speaker volume, move the Speaker Volume slider. Customize the camera spotlight settings Your Arlo Ultra camera spotlight is set to automatically turn on when your camera detects motion at night. The spotlight improves video quality and allows your camera to record color video at night. You can turn the spotlight on and off and you can adjust the spotlight behavior and brightness. Turn the spotlight on and off You can turn the spotlight on and off at any time from the camera feed by tapping Spotlight. See Turn the spotlight on and off from the camera feed on page 23.58 Change Your Settings Ultra Series 4K UHD Wire-Free Security Camera System User Manual You can also control whether the spotlight comes on automatically when your Arlo Ultra camera detects motion at night.1. Open the Arlo app.2. Tap Settings > My Devices.3. Tap the camera.4. Tap Video Settings > Low Light Settings.5. Tap Spotlight. The Spotlight setting toggles off and on. When the Spotlight setting is set to the On position, the spotlight automatically turns on when your Arlo camera detects motion at night.",

"How do I change SmartHub settings, restart the SmartHub, and view device information for Arlo Ultra Series 4K UHD Wire-Free Security Camera System (Arlo Ultra Camera and

SmartHub)?" : "Change your SmartHub settingsYou can view or change your SmartHub settings.Change the SmartHub name1. Open the Arlo app.2. Tap Settings > My Devices.3. Tap the SmartHub.4. Tap Editnext to the SmartHub name.5. Enter a new name for the SmartHub.6. Tap Save.Adjust the SmartHub flicker settingThe combination of certain artificial light sources and the camera shutter speed mightresult in flickering in recorded video. The default setting for the SmartHub is Auto, butyou can change the flicker adjustment.1. Open the Arlo app.2. Tap Settings > My Devices.3. Tap the SmartHub.59Change Your SettingsUltra Series 4K UHD Wire-Free Security Camera SystemUser Manual4. Tap Flicker Adjustment.5. Tap a setting.Restart the SmartHub1. Open the Arlo app.2. Tap Settings > My Devices.3. Tap the SmartHub.4. Scroll down and tap Restart.View device informationYou can view the firmware version, hardware version, and the serial number.1. Open the Arlo app.2. Tap Settings > My Devices.3. Tap the device.4. Tap Device Info.",

"How do I remove a device from my Arlo account for Arlo Ultra Series 4K UHD Wire-Free Security Camera System (Arlo Ultra Camera and SmartHub)?" : "Remove a device from your account1. Open the Arlo app.2. Tap Settings > My Devices.3. Tap the camera.4. Scroll down and tap Remove Device.",

"How do I control the screen on Google Nest Hub (Google Nest display)?" : "C. Control your Google Nest displayYour Google Nest display screen shows a wealth of information like notifications, weatherforecast, activities, and alarms. For most actions, you can control the screen with your handsor your voice.",

"How do I use the screen controls on Google Nest Hub (Google Nest display) (wake, go back, home control, photo frame, turn off screen)?" : "Use your screen• Wake up your screen: Tap it or say 'Hey Google.'• Go back to the previous screen: From the left edge of the screen, swipe right or say 'HeyGoogle, go back.'• Go to Home Control: From the top of the screen, swipe down.• Start Photo frame: On the Home screen, swipe right.• Turn off your screen: To make the screen dark, say 'Hey Google,' then 'off' or 'turn off.'• (US only) Show apps: While on the Photo frame screen, from the bottom of the screen, swipeup to find apps for your display. To find all apps, tap See all. To close, from the top of thescreen, swipe down.",

"How do I use pages and the navigation menu on Google Nest Hub (Google Nest display)?" : "Use pagesYour screen can display pages with touch controls and important information about your day,your linked devices, and more.To open the page's Navigation menu, tap the display screen when it shows photos or whenit's in Ambient mode.• Tap the name of the page you want to open.• Or, from the right edge of the screen, swipe left.Available pages• Your morning, your afternoon, or your evening: This page shows you your schedule, theweather and more. The title and content of the page changes depending on the time of day.• Wellness: Shows Sleep Sensing info about your last night's sleep, weekly sleep trends,suggested sleep schedules, and personalized coaching and tips. The "Wellness" page iscurrently available only on Nest Hub (2nd gen).• Home control: Use this page to control smart devices that are linked in the Google Homeapp.• Media: This page shows you music, videos, podcasts, news recommendations and yourongoing media activities. You can control

media from this page. • Communicate: You can make voice and video calls, broadcast messages to other speakers and displays in your home, and check your household contacts from this page. • Discover: Discover relevant content and new features on this page.",

"How do I remove cards from the screen on Google Nest Hub (Google Nest display)?" :

"Remove cards To remove cards from your screen, press and hold a card. Note: You can dismiss some cards, but not all of them. If you dismiss cards for alarms, timers and local media playback sessions on your Nest display, you end these activities. If you dismiss cards for remote playback sessions on other speakers or smart displays, you don't end the playback session. When you're ready, you can end the playback session on the remote device, or you can retrieve the media controls through the Media page. Or, on the Home control page, tap the "Speakers and TVs" card to control media that plays on any device in your home.",

"How do I adjust brightness and Ambient EQ on Google Nest Hub (Google Nest display)?" :

"Brightness From the top of the screen, swipe down to open the Quick settings menu, then tap Brightness . To adjust the brightness, swipe the slider left or right. To turn Ambient EQ on or off, tap Brightness again.",

"How do I adjust volume for media and alarms on Google Nest Hub (Google Nest display)?" :

"Volume From the top of the screen, swipe down to open the Quick settings menu, then tap Volume. To adjust the media volume, swipe the slider left or right. To change alarm volume, tap Expand , then swipe the alarm slider left or right. You can also adjust media volume with voice commands such as 'Hey Google, turn it up' or 'Hey Google, turn it down.' Additionally, you can adjust the volume with the buttons on the back of your Nest display's screen.",

"How do I silence incoming calls and notifications using Do Not Disturb on Google Nest Hub (Google Nest display)?" : "Silence incoming calls and notifications From the top of the screen, swipe down to open the Quick settings menu, then tap Do Not Disturb . You should find missed notifications on the home screen. Note:",

"How do I set an alarm and manage alarms on Google Nest Hub (Google Nest display)?" :

"Alarms and timers still work when Do Not Disturb is on. Alarms Set an alarm From the top of the screen, swipe down to open the Quick settings menu, then tap Alarms Set an Alarm select the time tap Set. You can customize your alarm to make the alarm repeat, change the alarm tone, include a sunrise alarm, or play your morning routine. When finished, tap Done. Set alarm defaults From the top of the screen, swipe down to open the Quick settings menu, then tap Alarms Settings . Adjust alarm volume Swipe up, then tap Volume Expand adjust the volume of your alarm. Set and manage alarms",

"How do I turn Sleep Sensing on or off on Nest Hub (2nd gen)?" : "E. Turn Sleep Sensing on

or off On Nest Hub (2nd gen) displays, you can quickly pause and unpauses Sleep Sensing. This will prevent Sleep Sensing from activating when you are in your sleep spot. Sleep Sensing must be set up and calibrated to pause Sleep Sensing on your display. 1. From the

bottom of your display, swipe up. 2. Tap Sleep Sensing . Tap again to turn it back on. If instead, you'd like to deactivate Sleep Sensing, learn how to change Sleep Sensing settings.",

"What does Fitbit Aria Wi-Fi Smart Scale measure and what does it do with the data?" :

"Getting started The Fitbit Aria® Wi-Fi Smart Scale measures body weight and body fat percentage and automatically uploads this data to your online Fitbit dashboard. Intended use The Aria Wi-Fi Smart Scale is a body analyzer that measures body weight and uses bioelectrical impedance analysis (BIA) technology to estimate body fat percentage in generally healthy individuals 10 years of age or older. It is intended for home use only. What's included Your Fitbit Aria Scale box includes: • The Fitbit Aria Wi-Fi Smart Scale • 4 AA batteries, already installed • Aria Quick Start Guide Power on your scale Your Aria scale is shipped with 4 AA batteries that have been previously installed. Pull the small plastic tab sticking out of the battery compartment to remove the tab and power on your scale. WARNING • Do not use if you have a pacemaker or any other internal medical device. • Do not use if you are pregnant. • Not intended for use by children under the age of 10. • Aria should not be used to diagnose or treat any medical condition. Always consult your physician to determine what is ideal for you. CAUTION • Slippery when wet.",

"What is the intended use of Fitbit Aria Wi-Fi Smart Scale?" : "Intended use The Aria Wi-Fi Smart Scale is a body analyzer that measures body weight and uses bioelectrical impedance analysis (BIA) technology to estimate body fat percentage in generally healthy individuals 10 years of age or older. It is intended for home use only.",

"How do I view my weight and body fat data after using Fitbit Aria Wi-Fi Smart Scale?" :

"Viewing your data When you have weighed yourself and your Aria has synced, you can view the measured data on your Fitbit.com Dashboard. After logging into your account, go to <http://www.fitbit.com/weight>. From this page you can view your recorded weight data on a graph. You can also view a full listing of the weights attributed to your account as well as delete or manually enter a weight.",

"How do I invite other users to use Fitbit Aria Wi-Fi Smart Scale?" : "Inviting other users to use the scale Up to eight users can associate their Fitbit.com accounts with a single Aria scale. If someone who does not have an account linked with the scale steps on the Aria, only their weight will display (body fat % will not appear) and the data will not be shared with anyone or attributed to a user account. To invite other users to join your Aria scale: 1. Make sure that you've connected your scale to your Fitbit.com account. 2. Click the gear icon at the top-right of your dashboard and select the scale from the drop-down menu. 3. Click the pink Invite People button and enter the email address of the person you'd like to invite. If that person already has a Fitbit account, you'll want to use the same email address that they use with Fitbit. 4. An email will be sent to the user at this address. Upon accepting the invitation, their measurements on the scale will automatically sync with their Fitbit account. If they do not yet have an account, they will be prompted to create one to begin using the scale.",

"How do I reassign a measurement to the correct user on Fitbit Aria Wi-Fi Smart Scale?" : "Reassigning a measurementIf two users on the same scale are close in weight (within 8 lbs.), the Aria will prompt you to select the correct user, noted by their identifying initials. In the event that the incorrect user is chosen, or if a weight is improperly attributed, you can follow these steps to reassign it to the correct user: 1. Click the gear icon at the top-right of your Fitbit.com dashboard and select the scale from the drop-down menu. Aria User Manual Rev C 114-0019 52. Click the Measurements tab to see a listing of all measurements synced from the scale. 3. Locate the weight you would like to reassign and choose the appropriate user from the drop-down "People" menu. This weight should now appear correctly on the user's account.",

"How do I choose Regular or Lean modes on Fitbit Aria Wi-Fi Smart Scale?" : "Choosing Regular or Lean modes "Lean" mode is intended for professional or very high-level athletes like marathon runners or body builders. Individuals with exceptionally low body fat relative to their muscle mass may want to consider lean mode to improve the scale's accuracy; however, many very fit and active people still get more accurate readings in "Regular" mode, which is appropriate for most users. To change this setting: 1. Log into your Fitbit.com dashboard and click the gear icon in the top right. 2. Click the image of the scale to open the Devices page. 3. Choose "Regular" or "Lean." The next time you weigh yourself and Aria syncs, the mode will switch.",

"What sensors and specifications are described for Fitbit Aria Wi-Fi Smart Scale?" : "Fitbit Aria General Info & Specifications Sensors Four load cells measure weight. Body fat information is measured through electrical impedance and calculated based on weight and user account data. The scale measures body mass using bioimpedance analysis. Indium tin oxide (ITO) electrodes form a pattern on the top of scale and send a small, safe signal through the body to measure impedance. Limitations • The Aria will accurately measure the weight of children and adults over 20 lbs. (9 kg). • The maximum weight limit for the Aria is 350 lbs. (158 kg). Batteries and power • 4 AA standard 1.5V size AA batteries included (Operating max: 3.3V, 0.1A / 300mW) • No power cord necessary Size and weight Length Width Depth Weight Aria Scale 12.3in 31.2cm 12.3in 31.2cm 1.3in 33.4mm 4lbs, 4.3oz 1.93kg",

"What limitations (minimum and maximum weight limits) apply to Fitbit Aria Wi-Fi Smart Scale?" : "Limitations • The Aria will accurately measure the weight of children and adults over 20 lbs. (9 kg). • The maximum weight limit for the Aria is 350 lbs. (158 kg).",

"What battery and power information is provided for Fitbit Aria Wi-Fi Smart Scale?" : "Batteries and power • 4 AA standard 1.5V size AA batteries included (Operating max: 3.3V, 0.1A / 300mW) • No power cord necessary",

"What environmental conditions are specified for operating and storing Fitbit Aria Wi-Fi Smart Scale?" : "Environmental conditions Operating Temperature 41° to 113° F (0° to 45° C) Aria User Manual Rev C 114-0019 7 Relative Humidity 0% - 95% Aria is designed to operate in a humid bathroom environment. Storage and Transportation -30°C - 60°C 90%

rHNOTE: You will see the most consistent and reliable readings when placing your Ariascale on a hard, flat surface.",