


Quickstart of 750-8215

You have to use three separate Networks



The PROFINET stack is **not active** without an e!COCKPIT Application!




 $The \ Generic_PROFINET_Controller \ activates \ the \ stack.$

Minimum PROFINET RT Interval is 4ms




Add modules for data transfer.




Tipp

You can define reserve modules. Unused modules are not reported as an error.










Tipp

If you modify the transfer data modules you can update the new GSDML in TIA easily.





Diagnosis in e!COCKPIT

Library: WagoSysProfinet

```
fbGetPNStatus: WagoSysProfinet.FbProfinetDevice_GetApplicationStatus;

END_VAR

//Diagnosis
fbGetPNStatus( xTrigger := xGetDiag,
xBusy =>xBusy,
xDone => xDone,
typPnAppState =>typPnAppState);
```