Home Quick Start

Getting Started



Welcome to the Quick Start Guide

Prerequisites

You should be comfortable navigating through your Radio Handset firmware (OpenTX/EdgeTX) and setting up models, as the guide on this website mainly covers setting up your radio for you to be able to use ExpressLRS.

Likewise, you should also be comfortable with your Flight Controller firmware (Betaflight, INAV, etc), as the guide only covers setting up your ExpressLRS receiver to work with your flight controller firmware.

What should I do first?

So you got your ExpressLRS Hardware, be it a new Radio Handset with an Internal ExpressLRS module, or an External ExpressLRS Module; and a set of ExpressLRS Receivers in a bundle or a Bind-and-Fly drone with the Receiver already wired up. Where do you start?

Here's our recommendation:

Transmitter Side

- 1. Setup your Radio
- 2. Check the TX Firmware Version

3. Update the TX Module

Receiver Side

- 1. Wire your Receiver
- 2. Configure your Flight Controller
- 3. Check the Receiver Firmware Version
- 4. Update the Receiver Firmware

After both of these, you can then proceed with the following:


- Bind
- Do the Bench Test
- Other Radio and Flight Controller Configuration
- Fly!

How to Use or Navigate through the Guide


This User Guide is organized to cater to both new and seasoned users of the system. The navigation menu on the left is arranged to start with getting the ExpressLRS Configurator installed, an Explanation of the Options available, Steps concerning the Radio and TX module, FC and Receiver setup, a "Before you Fly" page and a Troubleshooting page.


Quick Start Getting Started Installing the Configurator Firmware Options The Web UI Transmitters Radio Preparation Checking FW Version Typical Updating Steps **Updating Transmitters** Using The Lua Script Receivers Receiver Wiring Configuring FC Checking FW Version Typical Updating Steps **Updating Receivers** Post-Flash **LED Status** Binding ExpressLRS Before First Flight Ardupilot Setup Troubleshooting Unbricking

You can also use the Footer Navigation shown below to go through these steps:




For a specific hardware flashing guide, the pages are either in the Updating Receivers or Updating Transmitters sections organized semi-alphabetically.






You can also use the Search Bar for any topic or info you are after:



Longer pages have a **Table of Contents** menu found on the right-hand side of the page.

Each Updating Method available for a device can be accessed by clicking on their respective Tab.



We hope these pages will help you get started with ExpressLRS and experience one of the best and most innovative RC links in the hobby.

If you have other questions or concerns, or maybe you need further help that isn't covered by this Guide, head over to our Discord Channel!

ExpressLRS Discord 🕮

Where are the Video Guides?

Due to the current fast pace of development, video guides often end up outdated faster than intended. Specific hardware guides sometimes use pre-release firmware targets or targets intended for different hardware which can confuse when specific firmware targets are added.

We will be adding a separate videos section soon, but for now, until we find high-quality, relevant and applicable guides, you are on your own. Please take note of the publication date for these videos to make sure they are still relevant.





