
UniPlug-FPGA核心板 用户手册





2021年9月

目录

1	简介	2
2	扩展IO说明	3
3	引脚分配表	4
4	相关软件与驱动	6
K	cof(Ouortus项目配置文件)引用约束	,

1 简介

UniPlug-FPGA是一款体积小、低成本、易用、扩展性强的FPGA核心板。可以用作原型设计,或设计底板,添加DRAM、以太网、USB、ADC/DAC、音频、VGA、摄像头等外设,以完成定制化的功能。它的系统框图见图1和图2。它拥有以下特点:

- FPGA 型号为Altera Cyclone IV EP4CE6E22, 拥有6kLE 的逻辑资源和270kbit 的内置存储。
- 集成USB-Blaster (FPGA下载调试器),不需要额外准备USB-Blaster 就能使用。
- 集成的外设包括:
 - USB-UART (CH340E), 用于和上位机通信。
 - 8MB SPI-flash (W25Q64) 用户闪存。
 - Micro SD 卡槽。
 - 4 个用户LED 灯。
- 三组扩展IO: IOA, IOB, 和IOC, 共62 个普通IO。




图 1: UniPlug-FPGA核心板系统框图




图 2: UniPlug-FPGA核心板部件图

2 扩展IO说明

扩展IO 如图3,包括3个双排2.54mm间距排针:IOA,IOB和IOC。其中:

- IOA 为固定3.3V 的14 个普通IO。
- IOB 可配置为24 个普通IO, 或6 对LVDS, 电平可用跳线配置为1.8V、2.5V 或3.3V。
- IOC 可配置为24 个普通IO, 或5 对LVDS, 电平可用跳线配置为1.8V、2.5V 或3.3V。
- 注:核心板上并不带LVDS端接电阻,若用到LVDS,需要用户自行在底板上加端接电阻。调整IOB的电平的方法是用跳线帽将VIOB连接到某一个电源电压上:
 - IOB 的3,4 号引脚用跳线帽短接时, IOB 的电平=1.8V。
 - IOB 的5,6 号引脚用跳线帽短接时, IOB 的电平=2.5V。
 - IOB 的7,8 号引脚用跳线帽短接时, IOB 的电平=3.3V。

同理,调整IOC 的电平的方法是用跳线帽将VIOC 连接到某一个电源电压上:

- IOC 的3,4 号引脚用跳线帽短接时, IOC 的电平=1.8V。
- IOC 的5,6 号引脚用跳线帽短接时, IOC 的电平=2.5V。
- IOC 的7.8 号引脚用跳线帽短接时, IOC 的电平=3.3V。

注意:即使不用IOB 和IOC,也需要把VIOB 和VIOC 用跳线帽连接到任意电平上,VIOB 和VIOC 不能悬空,否则FPGA 将无法成功上传程序。

另外,如图3,IOB的1,2 号引脚的上方还有2 个引脚,它们是可选的5V 供电输入。可以给它们输入5V 来给核心板供电。核心板有二极管保护,外部供电和USB 供电不冲突,可以同时存在。




图 3: UniPlug-FPGA核心板扩展IO 示意图

3 引脚分配表

表 1: FPGA 的引脚分配

	衣 I: FPG	A 的引脚分配		
外设	信号名称	FPGA 引脚号	电平	类型
		- 41/41 3		(对于FPGA)
EPCS4	EPCS_ASDO	$PIN_{-}6$		输出
FPGA 配置芯片	EPCS_NCS	PIN_8	3.3V	输出
(配置闪存)	EPCS_DCLK	$PIN_{-}12$	0.0 V	输出
(EPCS_DATA0	PIN_13		输入
50MHz 时钟	CLK50M	$PIN_{-}24$	3.3V	输入
27MHz 时钟	CLK27M	PIN_90	3.3V	输入
USB 转串口	$UART_{-}RX$	$PIN_{-}23$	3.3V	输入
	$UART_{-}TX$	PIN_10		输出
W25Q64	$FLASH_CS$	PIN87	9 917	输出
SPI-flash	${\rm FLASH_SCK}$	$PIN_{-}75$		输出
	${\rm FLASH_MOSI}$	$PIN_{-}74$	3.3V	输出
(用户闪存)	${\rm FLASH_MISO}$	PIN84		输入
	SD_CLK	PIN_32		输出
	$\mathrm{SD}\text{-}\mathrm{CMD}$	PIN_31		双向
CD上槽	SD_DAT0	PIN_33	0.017	双向
SD卡槽	SD_DAT1	$PIN_{-}34$	3.3V	双向
	SD_DAT2	PIN_28		双向
	SD_DAT3	$PIN_{-}30$		双向
	LED0	PIN_1	3.3V	输出
用户LED灯	LED1	$PIN_{-}2$		输出
H) TEDV	LED2	PIN_3		输出
	LED3	$PIN_{-}7$		输出
	IOA0	$PIN_{-}105$		双向
	IOA1	$PIN_{-}106$		双向
	IOA2	PIN_103		双向
	IOA3	$PIN_{-}104$		双向
	IOA4	$PIN_{-}99$		双向
	IOA5	$PIN_{-}100$		双向
IOA	IOA6	$PIN_{-}98$	9 977	双向
(扩展接口A)	IOA7	$PIN_{-}86$	3.3V	双向
	IOA8	$PIN_{-}85$		双向
	IOA9	PIN83		双向
	IOA10	PIN_80		双向
	IOA11	$PIN_{-}77$		双向
	IOA12	$PIN_{-}76$		双向
	IOA13	$PIN_{-}73$		双向

表 2: FPGA 的引脚分配(续)

外设	信号名称	其它功能	FPGA 引脚号	电平	类型 (对于FPGA
	IOB0	LVDS-p	PIN_38		双向
	IOB1	LVDS-n	PIN_39		双向
	IOB2	_,	PIN_42		双向
	IOB3		PIN_46		双向
	IOB4		PIN ₋ 43		双向
	IOB5		PIN ₋ 44		双向
	IOB6	LVDS-p	PIN_49		双向
IOB (扩展接口B)	IOB7	LVDS-n	PIN_50		双向
	IOB8		PIN_51		双向
	IOB9		PIN ₋ 58		双向
	IOB10	LVDS-p	PIN ₋ 52		双向
	IOB11	LVDS-n	PIN_53	用跳线调整	双向
	IOB12	LVDS-p	PIN_54	1.8V/2.5V/3.3V	双向
	IOB13	LVDS-n	PIN ₋ 55	, ,	双向
	IOB14	LVDS-p	PIN ₋ 59		双向
	IOB15	LVDS-n	PIN ₋ 60		双向
	IOB16		PIN_64		双向
	IOB17		PIN_65		双向
	IOB18		PIN_66		双向
	IOB19		PIN ₋ 67		双向
	IOB20		PIN ₋ 68		双向
	IOB21		PIN_69		双向
	IOB22	LVDS-p	PIN_70		双向
	IOB23	LVDS-n	PIN_71		双向
	IOC0	LVDS-p	PIN_144		双向
	IOC1	LVDS-n	PIN ₋ 143		双向
IOC (扩展接口C)	IOC2		$PIN_{-}142$		双向
	IOC3		PIN_141		双向
	IOC4		PIN ₋ 138		双向
	IOC5		PIN ₋ 137		双向
	IOC6		PIN ₋ 136		双向
	IOC7		PIN ₋ 135		双向
	IOC8	LVDS-p	PIN ₋ 133		双向
	IOC9	LVDS-n	$PIN_{-}132$		双向
	IOC10	LVDS-p	PIN_129		双向
	IOC11	LVDS-n	PIN_128	用跳线调整	双向
	IOC12	LVDS-p	$PIN_{-}127$	1.8V/2.5V/3.3V	双向
	IOC13	LVDS-n	$PIN_{-}126$		双向
	IOC14		$PIN_{-}125$		双向
	IOC15		PIN_124		双向
	IOC16	LVDS-p	PIN_121		双向
	IOC17	LVDS-n	PIN_120		双向
	IOC18		PIN ₋ 119		双向
	IOC19		PIN_115		双向
	IOC20		PIN_113		双向
	IOC21		PIN_112		双向
	IOC22		PIN_111		双向
	IOC23		PIN ₋ 110		双向

4 相关软件与驱动

- Quartus 标准版或精简版 (需要版本号>11.0):
 - $-\ \mathtt{https://www.intel.cn/content/www/cn/zh/software/programmable/quartus-prime/download.html}$
 - Quartus 安装后会自带USB-blaster 驱动
- CH340&CH341 USB-UART 驱动 (用于进行UART通信,可选):
 - $-\ \mathtt{http://www.wch.cn/downloads/CH341SER_EXE.html}$
- Putty (用于进行UART通信,可选):
 - https://www.chiark.greenend.org.uk/~sgtatham/putty/

5 .qsf(Quartus项目配置文件)引脚约束

set_location_assignment PIN_90 -to CLK27M set_location_assignment PIN_1 -to LED[0] set_location_assignment PIN_2 -to LED[1] set_location_assignment PIN_3 -to LED[2] set_location_assignment PIN_7 -to LED[3] set_location_assignment PIN_10 -to UART_TX set_location_assignment PIN_23 -to UART_RX set location assignment PIN 6 -to EPCS ASDO set_location_assignment PIN_8 -to EPCS_NCS set_location_assignment PIN_12 -to EPCS_DCLK set_location_assignment PIN_13 -to EPCS_DATA0 set_location_assignment PIN_87 -to FLASH_CS set_location_assignment PIN_75 -to FLASH_SCK set_location_assignment PIN_74 -to FLASH_MOSI set_location_assignment PIN_84 -to FLASH_MISO set_location_assignment PIN_28 -to SD_DAT[2] set_location_assignment PIN_30 -to SD_DAT[3] set_location_assignment PIN_31 -to SD_CMD set_location_assignment PIN_32 -to SD_CLK set_location_assignment PIN_33 -to SD_DAT[0] set_location_assignment PIN_34 -to SD_DAT[1] set_location_assignment PIN_105 -to IOA[0] set_location_assignment PIN_106 -to IOA[1] set_location_assignment PIN_103 -to IOA[2] set_location_assignment PIN_104 -to IOA[3] set_location_assignment PIN_99 -to IOA[4] set_location_assignment PIN_100 -to IOA[5] set_location_assignment PIN_98 -to IOA[6] set_location_assignment PIN_86 -to IOA[7] set_location_assignment PIN_85 -to IOA[8] set_location_assignment PIN_83 -to IOA[9] set_location_assignment PIN_80 -to IOA[10] set_location_assignment PIN_77 -to IOA[11] set_location_assignment PIN_76 -to IOA[12] set_location_assignment PIN_73 -to IOA[13] set_location_assignment PIN_38 -to IOB[0] set_location_assignment PIN_39 -to IOB[1] set_location_assignment PIN_42 -to IOB[2] set_location_assignment PIN_46 -to IOB[3] set_location_assignment PIN_43 -to IOB[4] set_location_assignment PIN_44 -to IOB[5] set_location_assignment PIN_49 -to IOB[6] set_location_assignment PIN_50 -to IOB[7] set_location_assignment PIN_51 -to IOB[8] set_location_assignment PIN_58 -to IOB[9] set_location_assignment PIN_52 -to IOB[10] set_location_assignment PIN_53 -to IOB[11] set_location_assignment PIN_54 -to IOB[12] set_location_assignment PIN_55 -to IOB[13] set_location_assignment PIN_59 -to IOB[14] set_location_assignment PIN_60 -to IOB[15] set_location_assignment PIN_64 -to IOB[16] set_location_assignment PIN_65 -to IOB[17] set_location_assignment PIN_66 -to IOB[18] set_location_assignment PIN_67 -to IOB[19] set_location_assignment PIN_68 -to IOB[20] set_location_assignment PIN_69 -to IOB[21] set_location_assignment PIN_70 -to IOB[22] set_location_assignment PIN_71 -to IOB[23] set_location_assignment PIN_144 -to IOC[0] set_location_assignment PIN_143 -to IOC[1] set_location_assignment PIN_142 -to IOC[2] set_location_assignment PIN_141 -to IOC[3] set_location_assignment PIN_138 -to IOC[4] set_location_assignment PIN_137 -to IOC[5] set_location_assignment PIN_136 -to IOC[6] set_location_assignment PIN_135 -to IOC[7] set_location_assignment PIN_133 -to IOC[8] set_location_assignment PIN_132 -to IOC[9] set_location_assignment PIN_129 -to IOC[10] set_location_assignment PIN_128 -to IOC[11] set_location_assignment PIN_127 -to IOC[12] set_location_assignment PIN_126 -to IOC[13] set_location_assignment PIN_125 -to IOC[14] set_location_assignment PIN_124 -to IOC[15] set_location_assignment PIN_121 -to IOC[16] set_location_assignment PIN_120 -to IOC[17] set_location_assignment PIN_119 -to IOC[18] set_location_assignment PIN_115 -to IOC[19] set_location_assignment PIN_113 -to IOC[20] set_location_assignment PIN_112 -to IOC[21] set_location_assignment PIN_111 -to IOC[22] set_location_assignment PIN_110 -to IOC[23]