


NVIDIA JETSON NANO

TDG-09383-001_v1.1 | March 2019

Thermal Design Guide



DOCUMENT CHANGE HISTORY

TDG-09383-001_v1.1

Version	Date	Description of Change
1.0	February 1, 2019	Initial Release
1.1	March 4, 2019	 Minor changes throughout this thermal design guide Added reference to the platform adaptation guide for customizing fan control.

TABLE OF CONTENTS

Chapter 1.	Introduction	. 1
1.1 Custo	omer Requirements	. 1
1.2 Defin	itions	. 2
1.2.1	Total Module Power	. 2
1.2.2	Jetson Nano	. 2
1.2.3	Tegra X1 Temperature	. 3
Chapter 2.	Specifications	. 4
2.1 Ther	mal Specifications	. 4
Chapter 3.	Design Guidance	. 5
3.1 Ther	mal Information	. 5
3.1.1	Jetson Nano Thermal Performance	. 5
3.1.2	Jetson Nano Thermal Design Details	. 9
3.1.3	Customer Thermal Solution	10
3.1.4	Temperature Cycling	10
3.2 Mech	anical Information	11
3.2.1	Heat Sink Mounting Guidelines	11
3.2.2	Assembly Guidelines	12
Chapter 4.	Thermal Management	14
4.1 Temp	perature Monitoring	14
4.2 Fan (Control	14
4.3 Tegra	a X1 SoC Maximum Operating Temperature	16
4.4 Tegra	a X1 HARdware Thermal Throttling	17
4.5 Tegra	a X1 Shutdown Temperature	17

LIST OF FIGURES

Figure 1-1. Jetson Nano - Topside View
Figure 1-2. Jetson Nano Backside View
Figure 3-1. Thermal Resistance Network 6
Figure 3-2. Component Placement Map for Jetson Nano
Figure 3-3. Thermal Stack-Up Schematic
Figure 3-4. Module Board with Mounting Features
Figure 3-5. Module Board PCB Back Support Keepout Area
Figure 3-6. Jetson Nano System Assembly Example on System Board
Figure 4-1.Fan Control Algorithm
LIST OF TABLES
LIST OF TABLES
Table 2-1. Jetson Nano Thermal Specifications
Table 3-1. Jetson Nano Thermal Performance
Table 4-1. Default Fan Control Parameters

Chapter 1. INTRODUCTION

This document is the thermal design guide (TDG) for the NVIDIA® Jetson Nano™ (699-13448-0002-xxx) product.

The purpose of this thermal design guide is to provide the system-level thermal, mechanical and qualification requirements for the Jetson Nano.

Refer to the Jetson Nano module data sheet for detailed drawing and module dimensions.

1.1 CUSTOMER REQUIREMENTS

The customer requirements are as follows:

- Customers are responsible for reading and understanding this entire thermal design guide.
- ▶ Customers are responsible for implementing a thermal solution that maintains the NVIDIA® TEGRA® X1 temperatures below the specified temperatures in Table 2-1 under the maximum thermal load and system conditions for their use case.
- ▶ Customers are responsible for designing a system that delivers enough power to the Jetson Nano to sustain the maximum thermal load for their use case.
- ► Customers are responsible for qualification of the Jetson Nano in their system and are responsible for any issues related to failure to qualify the product properly.

1.2 DEFINITIONS

This section describes terminology that will be referenced throughout this thermal design guide.

1.2.1 Total Module Power

The total module power (TMP) represents the average board power dissipation while the system is running the target workload under the worst-case conditions in steady state. System designs must be capable of providing enough cooling for the Jetson Nano when operating at the TMP level.

1.2.1.1 TMP Conditions

TMP conditions for this design are defined under the following operating conditions:

- ► Worst-case Tegra temperature conditions
- ▶ Maximum power level for the product configuration
 - The TMP power level is based on the target workload
- ► Steady state average power

1.2.2 Jetson Nano

Figure 1-1 provides a topside view of the Jetson Nano while Figure 1-2 provides the backside view.




Figure 1-1. Jetson Nano - Topside View




Figure 1-2. Jetson Nano Backside View

The thermal solution of the customer's system design should attach to the module directly. Mounting holes are provided on the PCB to enable attachment of the customer's thermal solution. More details are provided in Section 3.2 "Mechanical Information." Customer's system thermal solution must provide adequate cooling to maintain all the components on the PCB including the Tegra X1 below the maximum temperature specifications as detailed in Section 2.1 and Section 3.1.

1.2.3 Tegra X1 Temperature

The Tegra X1 junction temperature (T_i) represents the Tegra X1 die temperature read from any of the internal temperature sensors. The on-die thermal sensors are used for high-temperature T_i management and many other temperature-dependent functions. Details regarding the software thermal mechanisms are described in Chapter 4.

Chapter 2. SPECIFICATIONS

2.1 THERMAL SPECIFICATIONS

On Tegra X1, there are multiple on-die temperature sensors that are placed close to dominant hotspots for high accuracy measurements of junction temperature. A built-in hardware controller is used to read the sensors and engage thermal protection mechanisms. Chapter 4 contains the details related to these sensors and the associated thermal protection mechanisms. The specifications in Table 2-1 must be followed in order to maintain the performance and reliability of the Jetson Nano module.

Table 2-1. Jetson Nano Thermal Specifications

Parameter	Value	Units
Maximum Tagra V1 approxing temperature1	T.cpu = 97	°C
Maximum Tegra X1 operating temperature ¹	T.gpu = 97.5	°C
To any V4 short down to an anatom 2	T.cpu = 103	°C
Tegra X1 shutdown temperature ²	T.gpu = 104	°C

Notes:

¹The Tegra X1 maximum operating temperature is the temperature below which the product will operate at the specified clock speeds. Software will apply clock speed reductions once this temperature is reached. Note that power fluctuations that induce T_j fluctuations above these thresholds will cause temporary clock reductions. See Section 4.1 for details.

²The Tegra X1 will shut down the Jetson Nano module once any of these software-imposed temperature limits are reached in order to maintain the reliability of the Tegra X1. See Section 4.5 for details.

Chapter 3. DESIGN GUIDANCE

This chapter provides design guidance in order to meet the Jetson Nano module specifications.

3.1 THERMAL INFORMATION

The design goal for system thermal management is to keep the Tegra X1 temperature below the limits specified in Section 2.1.

3.1.1 Jetson Nano Thermal Performance

The Jetson Nano module is not equipped with a system level thermal solution to dissipate the TMP thermal load into the ambient environment. It is the customer's responsibility to design an adequate thermal solution to maintain all the component temperatures below the de-rated limits as specified in Table 3-1. Figure 3-2 provides a map of the component placement on the Jetson Nano PCB as listed in Table 3-1. The thermal resistance network for the system thermal solution can be represented with the following equation:

$$\theta_{12} = \frac{T_1 - T_2}{P}$$

Where:

 θ_{12} The thermal resistance between Point 1 and Point 2

 T_n The temperature at Point n

P The heat load (i.e; dissipated power) transferred between Points 1 and 2

A simple example of a thermal resistance network is shown in Figure 3-1, where θ_{ja} represents the thermal resistance from T_j to the ambient of the system thermal solution. The thermal resistance of the system thermal solution may include multiple components including, but not limited to, thermal interface material, heat spreaders, and heat sinks.





Figure 3-1. Thermal Resistance Network

Jetson Nano enables a wide variety of applications that may exercise different components on the module. The variation between applications will cause variation in heat loads on the different components on the Jetson Nano and hotspots in different logical partitions of the Tegra X1. While the system thermal solution will help to spread the heat and make the thermal performance as consistent as possible, different applications will have different levels of thermal performance. The more evenly the module power is distributed across the Jetson Nano the higher the thermal performance will be.



Bottom Side

Figure 3-2. Component Placement Map for Jetson Nano

Table 3-1. Jetson Nano Thermal Performance

Components that will be contacted and need to be monitored

Components that must monitored

Miscellaneous

Comp # on Map	REFDES(s)	Description	Qty	Thermal Specifications Tcase
(Number)	(Name)		(Count)	(°C)
1	U7	TEGRA X1	1	Refer to Table 2-1
2	M1, M2	LPDDR4 Memory	2	85
4	U530	CPU Voltage Regulator	1	115
5	Q2	CPU HS MOSFET	1	115
6	Q5	CPU LS MOSFET	1	115
7	L29	CPU Inductor	1	100
8	C1217	CPU Output POSCAP	1	85
9	U526	GPU Voltage Regulator	1	115
10	Q1	GPU HS MOSFET	1	115
11	Q8	GPU LS MOSFET	1	115
12	L30	GPU Inductor	1	100
13	C344	GPU Output POSCAP	1	85
14	U4	PMIC	1	85
15	L4	PMIC SOC Inductor A	1	100
16	L11	PMIC SOC Inductor B	1	100
17	L3	PMIC VDD_DDR_1V1 Inductor	1	100
18	L12	PMIC VDD_PRE_REG_1V35 Inductor	1	100
19	L13	PMIC VDD_1V8 Inductor	1	100
20	U32	VIN->3V3 Supply Regulator	1	115
21	L31	VIN->3V3 Supply Inductor	1	100
22	U41	ENET, RTL8111GS	1	95
23	L502	ENET Reg Inductor	1	85



Note: Table 3-1 is subject to change.

The required system thermal performance can be determined based on the ambient temperature conditions and TMP level required by the customer. Consider the following example:

$$T.amb = 55^{\circ}C$$

 $T.cpu = 93^{\circ}C$ (Targeting $4^{\circ}C$ T.cpu headroom to account for sensor inaccuracy and possible T_i fluctuations resulting from workload variation)

$$P_{TMP} = 10W$$

The heatsink thermal performance requirement for the above conditions.

$$\rightarrow \theta_{ja} = \frac{93^{\circ}C - 55^{\circ}C}{10W} = 3.8 \frac{^{\circ}C}{W}$$

So, in this example, a 3.8 °C/W thermal solution is expected to be sufficient to maintain the Tegra X1 within the maximum temperature specification as detailed in Table 2-1. In addition to this, the customer is responsible to verify that this thermal solution is capable of maintaining all other components of the module within their maximum temperature specifications as detailed in Table 3-1.

3.1.2 Jetson Nano Thermal Design Details

The customer is responsible for the following items:

- ► Thermal Solution A system thermal solution capable of cooling the appropriate amount of TMP for the target workload.
- ▶ HS_TIM The customer is responsible for providing the thermal interface material between the Jetson Nano module and customer's system level thermal solution. For best thermal performance, the TIM should provide low thermal impedance within the mechanical, reliability, and cost constraints of the customer's product.
- ▶ Maximum Temperature To ensure that the maximum Tegra X1 operating temperature is less than the value specified in Table 2-1, and the maximum component temperatures on the PCB must not exceed the value specified in Table 3-1.

Example thermal stack up is shown in Figure 3-3.




Figure 3-3. Thermal Stack-Up Schematic

3.1.3 Customer Thermal Solution

The customer's thermal solution is the mechanical element that interfaces to the Jetson Nano module and provides cooling. A variety of thermal solution configurations are possible depending on the customer's chassis design. In all cases, however, the following recommendations are applicable:

- ▶ Good contact of the thermal solution to the Tegra TX1 is critical for maximizing the thermal performance of the Jetson Nano. The Tegra X1 consumes the majority of the TMP.
- ▶ Customer must determine if system thermal solution needs to contact all / select components on the PCB to make sure that they are maintained within the maximum temperature specifications listed in Table 3-1.

3.1.4 Temperature Cycling

Long-term reliability of all solder interconnects is negatively impacted by temperature cycling. It is the customer's responsibility to minimize the component's exposure to temperature cycling and to not exceed that which the component is qualified. NVIDIA's graphics and core logic components are qualified to JEDEC standard JESD47.



Note: NVIDIA recommends that customers refer to JESD94.01 (Application Specific Qualification Using Knowledge Based Test Methodology) for more information.

3.2 MECHANICAL INFORMATION

Refer to the Jetson Nano module Mechanical drawing for the exact module dimensions to determine how to interface the module board with the system thermal solution and ensure mechanical compatibility.

3.2.1 Heat Sink Mounting Guidelines

As noted in the thermal section, the mechanical design of the system must ensure good contact between the thermal solution, Tegra X1 and the module board. The module board is provided with mounting holes to accommodate mounting options for a suitable heat sink.




Figure 3-4. Module Board with Mounting Features

The following guidelines should be followed to ensure good mechanical and thermal contact between the chassis thermal solution and the Module board.

- ▶ Four holes (Ø 3.2mm) are provided near the Tegra X1 and two holes (Ø 2.75mm) on the edge opposite to edge connector.
- ▶ All holes are NPTH with annular ground pads. These holes can be used for system mount as well as Heatsink mount based on individual customer design intents.
- ▶ Shoulder screws can be used for all mounting hole locations to prevent thread damaging the board.
- ▶ Maximum Pressure on Tegra X1 should not exceed 60 psi

- ▶ Module board should not bow or bend to cause more than 500 micro-strain within 5mm of the Tegra X1.
- ▶ There is a keep-out area behind the module board to allow for back plate to support the board while heatsink is mounted from top side.
- ► Figure 3-5 illustrates where module provides room for backplate should the design require a backplate to assist in stiffening the board and for mounting/locking features. The outline shows the keep-out area for the back plate on backside of the module.




Figure 3-5. Module Board PCB Back Support Keepout Area

3.2.2 Assembly Guidelines

The Jetson Nano comes with JEDEC standard 260 DDR4 SODIMM 0.5MM pitch edge connector and are provided to interface with 260 PIN DDR SODIMM SOCKET WITH 0.5MM PICTH, based on SO-018.

Orientation of the unit is to be aligned with the connector and secured to the baseboard as shown in Figure 3-6. Suggested hardware for mounting the module to the baseboard is use of standoff between the two board, anchored with screw on each board.

Here are some suggested assembly guidelines.

- 1. Assemble the heat sink and fan if needed on the module board.
- 2. Install the Jetson Nano module
 - a) Baseboard with suitable standoff for as per SoDIMM connector height defined
 - b) Insert module at an angle of 25-35 degree into the SODIMM connector.
 - c) Arc down the module board until it latches to the SODMM connector

d) Secure the Jetson Nano module to the baseboard with screws onto the standoff/spacer. Figure 3-6 shows use of two standoff and screws to secure the module to the system/base-board.




Figure 3-6. Jetson Nano System Assembly Example on System Board

Chapter 4. THERMAL MANAGEMENT

4.1 TEMPERATURE MONITORING

The Tegra junction temperature can be directly read from sysfs nodes, as shown in the following example. Note that the name of each temperature zone is noted in the type node and that the temperature values are reported in units of m °C.

cat /sys/devices/virtual/thermal/thermal_zone1/type
cpu-therm

cat /sys/devices/virtual/thermal/thermal_zone1/temp
35000

4.2 FAN CONTROL

The Jetson Nano can be configured to control a system fan. Pulse width modulation (PWM) output and tachometer input are supported. Jetson Nano has configurable fan control of step-based speed control with hysteresis, as shown in Figure 4-1.




Figure 4-1. Fan Control Algorithm

The default fan curve settings are listed in Table 4-1. Note that PWM is configured on a 2⁸ scale, with 255 being equivalent to 100% duty cycle.

Table 4-1. Default Fan Control Parameters

CPU Temperature (°C)	PWM	Hysteresis ¹ (°C)
51	80	15
61	120	9
71	160	9
82	255	10

Note:

¹The hysteresis set for each trip point must be greater than the previous trip point. For example, 82 °C - 10 °C = 72 °C, which is greater than the 160 PWM trip point at 71 °C.

Custom fan settings can be implemented if needed. Refer to the "Platform Adaptation and Bring-up Guide" for details.

4.3 TEGRA X1 SOC MAXIMUM OPERATING TEMPERATURE

The recommended operating temperature limit is the threshold at which the module will operate without performance reduction. These temperatures are listed in Table 2-1 and cannot be adjusted. The customer's tolerance for performance reduction should determine the amount of T_j operating headroom in the thermal solution design in order to accommodate the temperature sensor accuracy of \pm 3 °C.

Software thermal management operates as follows:

- ▶ When the measured temperature is at or below the operating temperature threshold, software T_i thermal management is not engaged and the system is free to vary the system frequencies and voltages.
- ▶ When the measured temperature reaches the thermal management threshold, the internal thermal sensors generate an interrupt to software. At this point the software thermal management algorithm engages and begins periodically performing the following operations:
 - Polling temperature.
 - Running a thermal management control algorithm to calculating the throttle degree, indicating the amount of throttling to apply during the next time period.
 - Throttling the system to the level of throttling indicated by the throttling control algorithm. Throttling is applied through limits on the clock frequency of high-power units such as the CPU and graphics processing unit (GPU). Higher throttling degree results in lower frequency limits. DVFS policies operate within these frequency limits.
- ▶ Software thermal management remains in operation until the Tegra X1 temperature has returned to a value below the throttling threshold and throttling degree has returned to zero.



Note: Power fluctuations that induce T_i fluctuations above the software thermal management thresholds will cause temporary clock reductions. Power fluctuations in the target workload should be evaluated for their potential to cause temperature to fluctuate above the software threshold.

4.4 TEGRA X1 HARDWARE THERMAL THROTTLING

In the event that software thermal management is not able to maintain the Tegra X1 temperature, then hardware thermal throttling will engage in an attempt to prevent thermal shutdown. To help avoid thermal shutdown conditions without being overly conservative, Tegra X1 has hardware-engaged clock throttling mechanisms that are used as a last resort to prevent shutdown conditions. This will lower the Tegra X1 temperature, but it will also significantly reduce the overall Tegra X1 performance. The Tegra X1 throttle settings cannot be altered. These settings are implemented by NVIDIA to meet safety and reliability standards.

4.5 TEGRA X1 SHUTDOWN TEMPERATURE

Tegra X1 is rated to operate at a junction temperature not-to-exceed 105 °C. Tegra X1 has hardware shutdown mechanisms that enforce this limit by automatically halting the system when this temperature is exceeded.

The shutdown temperature should not be reached at any time during normal operation, but it may occur if cooling system components are broken, jammed, or otherwise unable to cool the Tegra X1 under worst-case conditions. If a thermal shutdown event is triggered, then a major fault in the Jetson Nano or system cooling solution has occurred. Thermal shutdown can be initiated by any of the sensors listed in Table 2-1. Using multiple sensors enables operation closer to the temperature limit without compromising reliability by reducing the uncertainty associated with the hotspot location.

The following thermal shutdown mechanisms have been implemented:

- ▶ Internal sensor-based shutdown. Failsafe thermal shutdown is guaranteed by using the SHUTDOWN signal directly from Tegra to the PMIC. After the failsafe shutdown the user will have to manually turn the system on by pressing the power button or equivalent input.
- ▶ T.diode/temperature-monitor-based shutdown. When the external temperature monitor detects that the T.diode temperature is above a pre-programmed Tshutdown, the monitor's THERM output signals the PMIC to shut down the system without any software control. This is a back-up mechanism to the internal sensor-based shutdown, so its Tshutdown is intentionally margined to a higher temperature to avoid contention with internal sensor-based shutdown.

The Tegra X1 shutdown settings cannot be altered. These settings are implemented by NVIDIA to meet safety and reliability standards.

Notice

The information provided in this specification is believed to be accurate and reliable as of the date provided. However, NVIDIA Corporation ("NVIDIA") does not give any representations or warranties, expressed or implied, as to the accuracy or completeness of such information. NVIDIA shall have no liability for the consequences or use of such information or for any infringement of patents or other rights of third parties that may result from its use. This publication supersedes and replaces all other specifications for the product that may have been previously supplied.

NVIDIA reserves the right to make corrections, modifications, enhancements, improvements, and other changes to this specification, at any time and/or to discontinue any product or service without notice. Customer should obtain the latest relevant specification before placing orders and should verify that such information is current and complete.

NVIDIA products are sold subject to the NVIDIA standard terms and conditions of sale supplied at the time of order acknowledgement, unless otherwise agreed in an individual sales agreement signed by authorized representatives of NVIDIA and customer. NVIDIA hereby expressly objects to applying any customer general terms and conditions with regard to the purchase of the NVIDIA product referenced in this specification.

Unless specifically agreed in writing by NVIDIA, NVIDIA products are not designed, authorized or warranted to be suitable for use in medical, military, aircraft, space or life support equipment, nor in applications where failure or malfunction of the NVIDIA product can reasonably be expected to result in personal injury, death or property or environmental damage. NVIDIA accepts no liability for inclusion and/or use of NVIDIA products in such equipment or applications and therefore such inclusion and/or use is at customer's own risk.

NVIDIA makes no representation or warranty that products based on these specifications will be suitable for any specified use without further testing or modification. Testing of all parameters of each product is not necessarily performed by NVIDIA. It is customer's sole responsibility to ensure the product is suitable and fit for the application planned by customer and to do the necessary testing for the application in order to avoid a default of the application or the product. Weaknesses in customer's product designs may affect the quality and reliability of the NVIDIA product and may result in additional or different conditions and/or requirements beyond those contained in this specification. NVIDIA does not accept any liability related to any default, damage, costs or problem which may be based on or attributable to: (i) the use of the NVIDIA product in any manner that is contrary to this specification, or (ii) customer product designs.

No license, either expressed or implied, is granted under any NVIDIA patent right, copyright, or other NVIDIA intellectual property right under this specification. Information published by NVIDIA regarding third-party products or services does not constitute a license from NVIDIA to use such products or services or a warranty or endorsement thereof. Use of such information may require a license from a third party under the patents or other intellectual property rights of the third party, or a license from NVIDIA under the patents or other intellectual property rights of NVIDIA. Reproduction of information in this specification is permissible only if reproduction is approved by NVIDIA in writing, is reproduced without alteration, and is accompanied by all associated conditions, limitations, and notices.

ALL NVIDIA DESIGN SPECIFICATIONS, REFERENCE BOARDS, FILES, DRAWINGS, DIAGNOSTICS, LISTS, AND OTHER DOCUMENTS (TOGETHER AND SEPARATELY, "MATERIALS") ARE BEING PROVIDED "AS IS." NVIDIA MAKES NO WARRANTIES, EXPRESSED, IMPLIED, STATUTORY, OR OTHERWISE WITH RESPECT TO THE MATERIALS, AND EXPRESSLY DISCLAIMS ALL IMPLIED WARRANTIES OF NONINFRINGEMENT, MERCHANTABILITY, AND FITNESS FOR A PARTICULAR PURPOSE. Notwithstanding any damages that customer might incur for any reason whatsoever, NVIDIA's aggregate and cumulative liability towards customer for the products described herein shall be limited in accordance with the NVIDIA terms and conditions of sale for the product.

ARM

ARM, AMBA and ARM Powered are registered trademarks of ARM Limited. Cortex, MPCore and Mali are trademarks of ARM Limited. All other brands or product names are the property of their respective holders. "ARM" is used to represent ARM Holdings plc; its operating company ARM Limited; and the regional subsidiaries ARM Inc.; ARM KK; ARM Korea Limited.; ARM Taiwan Limited; ARM France SAS; ARM Consulting (Shanghai) Co. Ltd.; ARM Germany GmbH; ARM Embedded Technologies Pvt. Ltd.; ARM Norway, AS and ARM Sweden AB.

Trademarks

NVIDIA, the NVIDIA logo, Jetson Nano, and Tegra are trademarks and/or registered trademarks of NVIDIA Corporation in the U.S. and other countries. Other company and product names may be trademarks of the respective companies with which they are associated.

Copyright

 $\ensuremath{\text{@}}$ 2019 NVIDIA Corporation. All rights reserved.

