

INSTRUC TION MANUAL

000

GAVASTO

STOP

**PLEASE DO NOT
RETURN THIS ITEM
BACK TO THE PLACE OF**

**PURCHASE Faulty
product? Missing parts?
Get a refund, repair, or
replacement.**

Simply send an email to

support@Gavasto.com

Or **scan** the QR code to open conversations

We will reply to **you** within 8 hours.

16/7

LIVE CHAT SUPPORT

SCAN ME

Facebook Messenger

Customer Service: support@Gavasto.com Facebook:
m.me/Gavasto

Website: www.Gavasto.com

support@Gavasto.com

5-YEAR LIMITED WARRANTY

Gavasto, at its option, will repair or replace this product or any component of the product was found to be defective during the warranty period. Replacement will be *made* with a new or remanufactured product or component. if the product is *no* longer available, a replacement may be made with a similar product of equal or greater value. This is your exclusive warranty. Do NOT attempt to repair or adjust any electrical or mechanical functions on this product. Doing so will void this warranty.

support@Gavasto.com

5-YEAR LIMITED WARRANTY

- This warranty is valid for the original retail purchaser from the date of the initial retail purchase and is not transferable. Keep the original sales receipt. Proof of purchase is required to obtain warranty performance. Gavasto dealers, service centers, or

retail stores selling Gavasto products do *not* have the right to alter, modify, or in any way change the terms and conditions of

this warranty.

- This limited warranty does not cover normal wear of parts or damage resulting from any of the following: negligent use or misuse of the product, use on improper voltage or current, use contrary to the operating

instructions, disassembly, repair, or alteration by anyone other than Gavasto or an authorized Gavasto service center., Further, this limited warranty does not cover: Acts of God, such as fire, flood, hurricanes, and tornadoes.

What are the limits on Gavasto's liability?

- Gavasto shall not be liable **for** any incidental or consequential damages caused by the breach of any express,

implied, or statutory warranty or condition. *Ex- cept* to the extent **prohibited by** applicable law, **any** implied warranty or condi- *tion of* merchantability or fitness **for a** particular purpose is limited in duration to the duration of the above warranty.

- Gavasto disclaims all other warranties, conditions, or representations, express, implied, statutory, *or* otherwise.
- Gavasto shall not be liable for any damages of any kind resulting from the purchase, *use or* misuse of, or inability to use the product including incidental, special, consequential, or similar damages or loss of profits, or for any breach of

contract, fundamental or otherwise, or for any claim brought against the purchaser by any other party.

support@Gavasto.com

5-YEAR LIMITED WARRANTY

. Some provinces, states, or jurisdictions do not allow the exclusion or limitation of incidental or consequential damages or limitations on how long an implied warranty lasts, so the above limitations or exclusion may not apply to you.

- This warranty gives you specific legal rights, and *you* may also have other rights that vary from province to province, state to state, or jurisdiction to jurisdiction.

If you are missing parts, receive defective items, or have any issues when operating the vacuum cleaner, please email support@Gavasto.com immediately. We will reply to you within 8 hours.

**PLEASE DO NOT RETURN THIS
PRODUCT TO
THE PLACE OF PURCHASE.**

For inquiries regarding recycling and proper disposal **of** this product, please contact your local waste management facility.

support@Gavasto.com

IMPORTANT SAFETY INSTRUCTIONS

This electrical appliance must

always **be** used according to the following **safety** instructions. Save **these instructions as this manual contains important safety and operating information.** When using an electrical **appliance**, basic precautions should **always be followed, including** the following:

READ ALL INSTRUCTIONS

CAREFULLY BEFORE USING THIS

APPLIANCE WARNING: To reduce the risk of fire, electric shock or injury:

1. Always turn off the unit before unplugging the vacuum.
2. Always unplug the appliance before cleaning or servicing it. Do not unplug by pulling the cord; to unplug, grasp the

plug, not the cord.

3. Do not let the vacuum be used as a toy.

Close attention is necessary when used near children. Do not use in Sensor Mode or leave appliance plugged in near small children or infants.

4. Do not pull or carry the appliance by the cord. Do not run the appliance over the cord, close a door on the cord, or pull the cord around sharp edges or corners. Keep the cord away from heated surfaces.

5. Do not use the appliance if the cord or plug is damaged.

6. Do not handle the plug or appliance with wet hands.

7. Do not use appliance on wet surfaces.

8. Do not be exposed to rain.

9. Do not use appliance to dispose of water or damp materials such as mud, tile

grout, plaster filler, or caulking. Do not use it to pick up any liquid or wet objects. 10. Do not use appliance to vacuum up flammable or combustible liquids, such

as gasoline. Do not use in areas where these liquids may be present.

11. Do not use this appliance to vacuum up burning or smoking materials, such as cigarettes, matches, or hot ashes.

12. Keep hair, loose clothing, and all parts of the body, especially fingers, away from openings and moving parts.

13. Do not put any objects into appliance openings, or use it with any openings blocked or plugged.

14. Do not use this appliance to pick up hard or sharp objects or other large surface litter. Pick these up by hand before

vacuuming.

15. Do *not* operate without the Dust Bin properly in place.

16. Use the appliance only as described in this Use and Care Guide.

support@Gavasto.com

17. Turn the appliance off and unplug before removing or replacing the Dust Bin or Filter.

18. Unplug the appliance before cleaning or maintenance.

19. If the appliance is not

working as it should, call for instructions on where to send it for repair. Do not attempt to repair it, as it will invalidate your warranty.

20. When cleaning the outside of the appliance, wipe with a damp cloth *to*

reduce the static electricity on the outer surface.

21. Never store the vacuum while it is still plugged in.

22. Never wrap the cord tightly around the appliance, use the Cord Storage area

on the back of the unit.

23. Do not put any stress on the cord where it enters the unit, as it could cause

the cord to wear and break.

To reduce the risk of electric shock, If the plug does not fit fully in the outlet, contact a qualified electrician to install the proper outlet. Do not change the plug in anyway.

SAVE THESE INSTRUCTIONS FOR HOUSEHOLD USE ONLY

support@Gavasto.com

DESCRIPTION OF

IN02 Dust Pan Vacuum

Control Panel

Dust Bin

Air inlet

LED display

Hose Connector
HEPA Filter

Cord Hook

BEFORE USING FOR THE FIRST TIME

1. Remove the unit from the packaging and set it upright on any non-carpeted flooring.

2. Plug the unit into any standard 120V AC electrical outlet.

3. Press the Power Button, and the unit will be on standby for auto cleaning.

Your Vacuum is now ready for use.

OPERATING INSTRUCTIONS

The IN02 has two modes of operation, Floor Mode for cleaning with a broom, and *Tool Mode* for cleaning with 1.37" inner diameter tools. To switch between the two cleaning modes, either pull or insert the hose connector from the rear hose cuff.

In Floor Mode, when the hose connector is inserted in the cuff:

1.Plug in the power cord and press the Power Button on the left. The floor mode *and* sense *icon* will illuminate solid white, indicating the vacuum is ready to *vacuum* debris through the floor inlet into the dust bin.

support@Gavasto.com

2.Use any broom to collect debris and sweep toward the air inlet, the vacuum's motion sensor will trigger it to start working for a programmed *period* of 6 seconds.

3. You can manually start the vacuum anytime by pressing the Activate Button,
OR you can hit the lower front of the unit by broom to turn on the vacuum as the unit is also equipped with a touch sensor. Manual triggered operation lasts for 6 seconds also. Depending on the amount of debris, multiple cleaning cycles may be necessary.

4. Pressing the mode switch button can disable the motion sensor, *to allow* the vacuum to be operated by pressing the Activate Button or hitting the front purposely.

In Tool Mode, when the hose connector is pulled out from the cuff.

5. Connect the power cord and press the power button. The tool mode icon will illuminate solid white, indicating the vacuum is ready to vacuum through the hose connector with a tool selected.

6. Press the Activate Button to initiate vacuuming. The power will start at low gear. Press the Mode Button again to increase the vacuum power to high gear when

necessary.

7. To pause the cleaning process, press the Activate Button again.

8. Reinserting the hose connector into the cuff will switch the Tool Mode back to the Floor Mode.

NOTE:

1.Plug in and press the Power Button before starting, press again to turn it off, and unplug from the power socket when the unit is for storage. 2.Regularly empty the dust bin to prevent debris buildup, ensuring optimal performance. The red indicator light flashes to signal a full bin or air channel blockage. If the light continues flashing without manual intervention, the *vacuum* will automatically power off after 10 seconds to prevent damage. To reset the dust full sensor and resolve the issue, remove, empty and reinstall the dust bin. This action resets the indicator light and restores the vacuum's functionality. Keeping the dust bin clear and addressing blockages promptly maintains the vacuum's efficiency.

support@Gavasto.com

CONTROL PANEL INSTRUCTIONS

肉
? =

1 2 3

Power Button: After plugging in the power, the vacuum is in a powered-off state by default. Press this button to enter standby mode. If the vacuum is running, pressing this button will stop its operation and turn off the power." **Activate Button:** In standby mode, pressing this button initiates the vacuum in any mode. In Floor mode, the vacuum starts and stops after 6 seconds; in Tool mode, it remains on after starting in low gear.

Mode Button: This button functions differently depending on the vacuum's mode to streamline functionality.

In Floor Mode (Auto/Manual): The default standby state is automatic mode. If you prefer the vacuum not to start automatically, you can deactivate the motion sensor by pressing the mode button then the vacuum can only start by the activate button or by hitting the front.

In Tool Mode (Low/Max): After detaching the rear hose from the hose cuff, pressing the start button initiates from low gear. Pressing mode button to increase to high gear.

support@Gavasto.com

DISPLAY PANEL INSTRUCTIONS TO ЯТНО

1 2 3 4 5

FLOOR Mode Indicator Light (Floor): Illuminates when the vacuum operates in floor mode, specifically designed for sweeping with a broom.

Tool Indicator Light (Tool): When lit in standby mode, it means the rear hose of the vacuum has been detached, and the vacuum is in tool mode. In tool mode, when the power button is turned off, this light will blink.

Sensor Indicator Light (Sense): when this light is on, it means the motion sensor is detecting a sweeper to start the vacuum.

Power Indicator Light (H/L): in floor mode when the vacuum is working, two bars will flash, indicating high gear operation. In tool mode, the vacuum starts from one bar steadily lit for low *gear*. Pressing the mode

button again to high gear, two bars will be steadily lit

Bin Indicator Light (Bin): When the dustbin is full or there are obstacles in the airflow, this light will flash red, and the power will shut off after 10 seconds. When the dust bin isn't installed, this light will flash white, then the vacuum won't start. Opening the dustbin during operation will immediately shut down the vacuum while this light flashes.

MAINTENANCE---CLEAN THE DUST BIN

1. To empty the dust bin, turn off the unit by pressing the Power Button.
2. Pull the dust bin outward from the front of the Bin Cavity. Grip the Dust Bin handle firmly and lift it out and away from the Main Unit.
3. Holding the Dust Bin firmly with one hand, releasing the dust bin locker with by the other hand so the debris and hair will fall into a bigger trash can.
4. Install back the dust bin to the unit, to avoid

dust leakage, make sure all filters are in position before
turning on the unit.

support@Gavasto.com

CLEAN THE DUST BIN

MAINTENANCE---CLEANING THE FILTERS

To maintain optimal performance, the filters will need cleaning whenever the suction is not strong.

The filters must be clean and free of elements, which might hinder the flow of air.

- 1.Switch off the unit and unplug the power cord.
- 2.Clean the dust bin filter located at the

bottom of the dust bin cover.

3. Clean the sponge and motor filter located underneath the dust bin cavity.

4. Clean the exhaust HEPA filter at the rear of the unit by pressing the plastic locker to release the filter.

O

B

Pull the dust bin outward

from the front of the Bin Cavity. Grip the Dust Bin handle firmly and lift it out and away from the Main Unit.,

D

CLEAN THE DUST BIN

○

Holding the Dust Bin firmly with one hand,
releasing the dust bin locker by the other

hand

so the debris and hair will fall into a bigger trash can

support@Gavasto.com

NOTE:

1. Removing the hair and large debris on the filters first, then vacuuming or shaking off the hidden dust

in the crevices of the filter.

2. Wash the filters by running cold or warm water, don't use chemical liquid *to* wash the filters at any

time.

3. Ensure the filters are completely dry before reinserting them.

4 Over time, consider replacing the filters as the suction power may diminish due *to aging* filters.

We offer a free replacement service for 5 years.

IMPORTANT! NEVER OPERATE THE VACUUM WITHOUT THE FILTERS PROPERLY INSTALLED IN PLACE.

Problem

Unit won't run

Does not pick up (Dust full light is blinking)

Auto mode is not working

TROUBLE SHOOTING

Possible cause

1. Not firmly plugged in
2. Unit is in the OFF position
3. Dust bin is not installed

No power in the wall plug

1. Dirt inlet is blocked
2. Back hose is blocked
3. Dust bin is full or the filters may be dirty

1. Unit is not in floor mode

or Sensor is deactivated 2. There is dirt or obstacle on the sensor window

Possible Solution

1. Plug in firmly on the power socket 2. Press the power button to standby 3. Install the dust bin to the unit 4. Check the house fuse or circuit breaker

1. Clean the path of dirt inlet and avoid sucking large debris

2. Pull the hose from the unit, turn on the vacuum and stretch the hose

3. Empty the dust bin and clean the filters

1. Check the hose connector to make sure it is inserted firmly into the cuff. In Floor mode, press the mode button to activate the sensor 2. Clean the sensor window and restart the

vacuum

Bin light is flashing white

1. The bin is not installed

properly

1.Re-attach the bin to the unit firmly

Specification Sheet

Model NO.
IN02

Rating Voltage
AC120V

Cleaner Rating

Rating Frequency
60Hz

Vacuum *KPA*

Dust Capacity

Power cord Specification&length

Net/Gross Weight
19.5KPA

$\geq 7L$

2.5m, 18AWG

4KG 5KG

GAVASTO

16/7LIVE CHAT

**SUPPORT Customer
Service:**

support@Gavasto.com

Facebook: m.me/Gavasto

Website: www.Gavasto.com

support@Gavasto.com