




复位电路
Reset circuit




BOOT设置
BOOT Settings




指示灯
Indicator light







AT32电源部分
AT32 Power supply



Type-C 接口
Type-C interface



SW 调试下载接口
SW debug download interface



5V -> 3.3V 电源转换
5V -> 3.3V Power conversion
5V: 3.3V - 6V

Title	WeAct Studio AT32F405CxTx Core Board	
Size: A3	Number	Revision: V1.0
Date: 7/18/2026	Sheet of	
File: H:\Work\..\WeAct-AT32F405CxCoreBoard\Drawing	Drawn By:	zhuyix

WeAct Studio