Quick Quide

Withus Platform
ROS2



WeGo

ROS Interfacing

ROS – Interface

WeGo

$rros2 run withus_control can_bringup.sh

To enable the CAN communication Interface

$ ros2 launch withus_control withus_control.launch.py

$ros2 topic pub /cmd _vel geometry_msgs/msg/Twist “linear:
x:3.0
y:0.0
z:0.0
angular:
x:0.0
y:0.0
z:20.0”

x - km/hr

angular z (steering) - degree

UI control

$rros2 run withus_control can_bringup.sh


To enable the CAN communication Interface

$ ros2 launch withus_control withus_control.launch.py

For UI control

$ cd ~/withus_ws/src

$ python3 pyqt_control.py





본사(기술연구소 및 사무실) : 16914 경기도 용인시 기흥구 구성로 357(청덕동)
용인테크노밸리 B동 513호
기술연구소(서울) : 04799 서울특별시 성동구 성수동2가 280-13, 삼환디지털벤처타워 401호

대표전화 : 031 – 229 – 3553
팩스 : 031 – 229 – 3554

제품문의: go.sales@wego-robotics.com
기술문의: go.support@wego-robotics.com