## SELECTION TABLE FOR STARTER/RELAY/FUSE/CABLE

$\simeq$	
$\mathbf{\mathcal{L}}$	
	١
MOTOR	
⋝	
◀	
h -	1
X	
DELT	١
A R	
1	
~	
JOR JOR	

al Cablo	Motor Side	1.5/2.5	1.5/2.5	1.5/2.5	1.5/2.5	2.5	2.5	4.0	0.9	0.9	10.0	16.0	16.0	16.0	25.0	35	35	35	50	50	70	70	120	150	185	185	185	225	300/400
	Supply Side	1.5/2.5	1.5/2.5	2.5	4	4	9	10	16	16	25	25	35	35	50	70	70	70	95	95	120	185	225	300/400	300/400	400	500	500	625
Typical Back up	HRC Fuse (AMPS)	10	20	25	25	35	50	63	63	100	100	100	125	125	125	160	160	160	200	200	250	250	300	350	400	400	400	500	700
		4	9	10	12	12	16	20	25	25	32	32	40	40	63	63	63	63	06	06	110	135	135	170	170	200	250	300	400
Relay Scale in	Amps	ı	1	,	ı		ı		ı	1		ı		1		ı		1			,	ı	ı	1	1	ı	,	ı	
S		1.5	$\epsilon$	9	9	∞	11	14	17	17	22	22	25	25	38	38	38	38	20	20	70	90	90	140	140	140	175	210	280
Star Delta Starter Contactor	Capacity in Amps Main/Delta Star	12	12	12	16	16	16	30	30	30	30	30	30	30	70	70	70	70	70	70	70	170	170	170	170	170	170	400	400
		12	12	12	16	16	16	30	30	30	38	38	70	70	70	70	70	70	105	105	160	170	170	300	400	400	400	400	400
Phase Current in	Amps	2.88	4.32	6.34	8.10	10.02	12.10	16.00	20.20	23.00	27.00	30.30	34.6	35.0	45	50	54	57.5	0.69	78.0	95.0	115	133	159	184.5	185	206	222	390
Approx Full load	Current in AMPS	5	7.5	11	14	18	21	28	35	40	47	55	09	99	80	87	94	100	120	135	165	200	230	275	320	323	360	385	500
KW 415 V	50 HZ	2.25	3.75	5.5	7.5	9.3	11	15	18.5	22	26	30	33.5	37	45	48.5	52	99	67.5	75	06	112	132	150	175	187.5	204	225	300
HP 3 Phase 415v	50 HZ	3	5	7.5	10	12.5	15	20	25	30	35	40	45	50	09	65	70	75	06	100	125	150	175	200	240	250	275	300	400