



NORMAL CHECKLIST

B737-X
July 2021

B737-X

PRE FLIGHT CHECKLIST

PARKING BRAKE **SET**
BATTERY **GUARD CLOSED**
STANDBY POWER **GUARD CLOSED**
L CENTER FUEL PUMP **AS REQUIRED**
L AFT FUEL PUMP **AS REQUIRED**
APU **START**
APU GEN **ON**
POS LIGHTS **STEADY**
LOGO LIGHT **AS REQUIRED**
CABIN LIGHTS **AS REQUIRED**
EMER EXIT LIGHTS **GUARD CLOSED**
PASSENGER SIGNS **ON**
PACKS **AUTO / HIGH**
IRS MODE SELECTORS **OFF > NAV**
FMC **SET**

Request Flight-plan Clearance

TRANSPONDER **SET**
IAS / MACH SPEED **SET**
HDG / TAKEOFF RWY **SET**
INITIAL ALT **SET**
YAW DAMPER **ON**
WINDOW HEAT **ON**
FLIGHT ALTITUDE **SET**
LANDING ALTITUDE **SET**
FLIGHT DIRECTORS **ON**
LNAV **AS REQUIRED**
VNAV **AS REQUIRED**
MINIMUMS REF **BARO or RADIO**
MINIMUMS **SET**
ALTIMETER REF **IN or HPA**
AUTO BRAKE **RTO**
COM RADIOS **SET**
DOORS **CLOSED**

BEFORE START CHECKLIST

Request Pushback & Startup Clearance

AUTOTHROTTLE **ARM**
L & R C FUEL PUMPS **AS REQUIRED**
A & F FUEL PUMPS **ON**
ELEC HYD PUMPS **ON**
ANTI COLL LIGHT **ON**
PARKING BRAKE **SET**
GROUND EQUIPMENT **REMOVED**
ENGINE AREA **CLEAR**

ENGINE START CHECKLIST

SEC DISPLAY UNIT **ENGINE**
PACKS **OFF**
ENGINE 1 START SWITCH **GND**
ENGINE 1 FUEL CONTROL LEVER **RUN**
ENGINE 2 START SWITCH **GND**
ENGINE 2 FUEL CONTROL LEVER **RUN**

BEFORE TAXI CHECKLIST

GENERATORS 1 & 2 **ON**
PROBE HEAT **ON**
WING ANTI ICE **AS REQUIRED**
ENGINE ANTI ICE **AS REQUIRED**
PACKS **AUTO**
ISOLATION VALVE **AUTO**
APU BLEED **OFF**
APU **OFF**
ENG START SWITCHES **CONT**
FLAPS **AS REQUIRED**
ELEVATOR TRIM **SET FOR TAKE-OFF**
FLIGHT CONTROLS **FREE AND CORRECT**
RECALL (737-800 only) **CHECK**
LOWER DISPLAY UNIT (DU) **OFF**

Request Taxi Clearance

TAXI LIGHTS **ON**
RWY TURN-OFF LIGHTS **AS REQUIRED**

TAXI CHECKLIST

TAXI to assigned runway **SPEED** Max. 20 knots

BRKS/GYRO/TURN COORDINATOR **CHECK during taxi**

BEFORE TAKE-OFF CHECKLIST

PARKING BRAKE **SET**
FUEL FLOW **RESET, then RATE**
C FUEL PUMPS **AS REQUIRED**
DE-ICE **AS REQUIRED**
CABIN LIGHTS **AS REQUIRED**
FLIGHT INSTRUMENTS **CHECK**
ENGINE INSTRUMENTS **CHECK**
TAKE-OFF DATA **(V1, VR, V2) CHECK**
NAV EQUIPMENT **CHECK**

Request Takeoff Clearance

LANDING LIGHTS **ON**
STROBE LIGHT **ON**
TAXI LIGHTS **OFF**
TRANSPONDER **TA/RA**
TFC **PUSH ON**
CLOCK **START**

AFTER TAKE-OFF CHECKLIST

POSITIVE RATE OF CLIMB **GEAR UP**
AUTO-BRAKE **OFF**
ENGINE START SWITCHES **OFF**
GEAR LEVER **OFF POSITION**
RWY TURN-OFF LIGHTS **OFF**
CABIN LIGHTS **AS REQUIRED**

CLIMB-OUT CHECKLIST

CMD A or B **ENGAGE** (when suitable)

Passing TA (Transition-Altitude)

ALTIMETER **PUSH TO SET STD** (29.92 / 1013)
BELOW 10'000FT **MAX. 250 KIAS**
ATC **AS REQUIRED**

Passing 10'000 ft

LANDING LIGHTS **OFF**
FASTEN SEAT BELTS **OFF**
C FUEL PUMPS **AS REQUIRED**

CRUISE & DESCENT PREPERATION

ENGINE & INSTRUMENTS **MONITOR**
FUEL QUANTITY **CHECK**
LIGHTS **AS REQUIRED**

Before TOD

ATIS / AIRPORT INFORMATION **CHECK**
ALTIMETER **CHECK**
RADIO **SET**
RESET MCP ALTITUDE **CHECK**
FMC APPR SPEED REF **SET**
LOCALIZER FREQ **SET**
ILS LOC COURSE **SET**

Descent

DE-ICE **AS REQUIRED**
LANDING ALT **CHECK**
RECALL (737-800 only) **CHECK**
RADIO ALT / BARO MIN **SET, CHECK**
AUTO BRAKE **AS REQUIRED**

Passing TA (Transition-Altitude)

ALTIMETER **RESET TO LOCAL**
Below 10'000 ft

SPEED **250 KIAS**
LANDING LIGHTS **ON**
PASSENGER SIGNS **ON**

Check Weather (ATIS, Flight Services)

APPROACH CHECKLIST

ALTIMETER **CHECK**
LOCALIZER FREQ **CHECK**
LOCALIZER COURSE **CHECK**
APP **ARM**
GLIDESLOPE ALIVE **GEAR DOWN**
FLAPS **15**
SPEED BRAKE **ARM**
2ND AUTOPILOT **ARM** (when ILS established)
ENGINE START SWITCHES **CONT**
LANDING FLAPS **SET**

LANDING CHECKLIST

GO-AROUND ALTITUDE **SET**
RWY TURN-OFF LIGHTS **ON**
LANDING GEAR **CHECK DOWN**
AUTOPILOT **AS REQUIRED**
AUTO-THRUST **AS REQUIRED**

After Touch-Down

THRUST REVERSE **ENGAGE**
AUTOPILOT **OFF**
AUTOTHURST **OFF**
AT 60 KTS **REV THRUST TO IDLE**
AT 30 KTS **AUTO-BRAKE DISENGAGE**

AFTER LANDING CHECKLIST

TRANSPONDER **OFF**
FLAPS **RETRACT**
SPEED BRAKE **DOWN**
LANDING LIGHTS **OFF**
STROBE LIGHTS **OFF**
TAXI LIGHTS **ON**
CABIN LIGHTS **AS REQUIRED**
ANTI ICE **AS REQUIRED**
APU **START / CHECK RUN**
PROBE HEAT **OFF**
ENG START SWITCHES **OFF**
AUTO-BRAKE **OFF**

Taxi to Assigned Gate / Parking *(Speed Max 20 knots)*

RWY TURNOFF LIGHTS **OFF**
APU GEN **ON / CHECK VOLTS**

Turning Into The Gate

TAXI LIGHTS **OFF**

PARKING / SHUTDOWN CHECKLIST

PARKING BRAKES **SET**
ENGINE FUEL CONTROL LEVERS **OFF**
GROUND CONTACT **ESTABLISH**
GROUND OPERATIONS **AS REQUIRED (FMC)**
PASSENGER SIGNS **OFF**
APU BLEED AIR **ON**
ANIT COLL LIGHT **OFF**
FUELPUMPS **OFF**
L AFT FUEL PUMP **ON**
ANTI-ICE **OFF**
ELEC HYD PUMPS **OFF**
ISOLATION VALVE **OPEN**
FLIGHT DIRECTOR **OFF**
ELECTRICAL POWER **ESTABLISH**
EXTERIOR LIGHTS **AS REQUIRED**
DOORS **OPEN**

SECURING AIRCRAFT

IRS MODE SELECTORS **OFF**
APU **OFF**
L AFT FUEL PUMP **OFF**
EMERGENCY EXIT LIGHTS **OFF**
WINDOW HEAT **OFF**
PACKS **OFF**
CABIN LIGHTS **OFF**
EXTERIOR LIGHTS **OFF**
STANDBY POWER **OFF**
BATTERY **OFF**