

PREFLIGHT

GROUND EQUIPMENT..... AS RQRD
GUST LOCK..... ON
BATTERIES..... ON
EXTERNAL POWER..... AS RQRD
AVIONICS..... ON
MAIN INV..... ON
TEMP..... L BAT
NAV LIGHTS..... ON
CABIN SIGNS..... ON
OXYGEN..... ON
FUEL & PAYLOAD..... SET
GPS..... SET
DOORS..... CLOSED & LOCKED
POWER COND LEVERS..... GRD IDLE/FUEL OFF
TRIMS..... SET
RADIO..... SET
TRANSPONDER..... SET/STBY
A/P PANEL..... SET
QNH..... SET

BEFORE START

BCN LIGHTS..... ON
EXTERNAL POWER..... AS RQRD
CHOCKS..... REMOVED

BEFORE TAXI

STBY PITOT..... ON
AUTO COARSEN..... ON
AVIONICS..... ON
GENERATORS L+R..... RESET/ON
EXTERNAL POWER..... DISCONNECTED/OFF
AIR COND..... SET
RECIRC..... ON
BLEED L+R..... RESET/AUTO
EMERGENCY LIGHTS..... ARMED
CONDITION LEVERS..... MAX
ICE PROTECTION..... SET/CHECK
FLAPS..... SET
FLIGHT CONTROLS..... CHECK
TAXI LIGHT..... ON

BEFORE TAKEOFF

CABIN CREW..... APPRISED
CTOT..... SET/ARM
TRANSPONDER..... ALT
CWP..... CHECK
GUST LOCK..... OFF
EXT LTS..... SET
T/O INHIBIT..... PUSH
CLOCK..... START

AFTER TAKEOFF

LANDING GEAR..... UP
ICE PROTECTION..... AS RQRD
AUTO COARSEN..... OFF
PROP SYNC..... ON
CTOT..... OFF
FLAPS..... UP
QNH..... SET

10.000 FT

EXT LTS..... OFF
SEATBELT SIGN..... AS RQRD

DESCENT

ATIS..... OBTAIN
ICE PROTECTION..... AS RQRD
LANDING DATA..... SET

APPROACH

EXT LTS..... ON
CABIN SIGN..... VERIFY ON
QNH..... SET
HP VALVES..... SET

LANDING

AUTO COARSEN..... ON
PROP SYNC..... OFF
CONDITION LEVERS..... MAX
LANDING GEAR..... DOWN/GREEN
FLAPS..... SET

AFTER LANDING

FLAPS..... UP
GUST LOCK..... ON
ICE PROTECTION..... AS RQRD
AUTO COARSEN..... OFF
EXT LTS..... SET
TRANSPONDER..... STBY

SHUT DOWN & SECURE

PARKING BRAKE..... SET
GROUND EQUIPMENT..... AS RQRD
ENG ANTI ICE..... OFF
EXT LTS..... OFF
SEAT BELT SIGN..... OFF
EMERGENCY LTS..... OFF
OXYGEN..... OFF
AVIONICS..... OFF
GENERATORS..... OFF
BATTERIES..... OFF

