



SUBMITTAL	ITEM TYPE	TITLE
GATE AUTOMATION	WIRING SCHEMATIC	FLB100-MINI FIRE DEPT ACCESS



SlideDriver II EFO ignores loops and entrapment sensors. SlideDriver II operators equipped with a VFD will run at the high speed setting when EFO is activated.



For EFO operation connect a hold to operate device to the Emergency input and program the input. Set to 1 (FIRE DEPARTMENT OPEN) for emergency open or 0 (EMERGENCY CLOSE) for emergency close

