




STEP-BY-STEP INSTALLATION

Choose either **1A Front Mounting Position (Standard)** or **1B Rear Mounting Position (Alternate)**.

1A OPERATOR PLACEMENT [STANDARD]

The gate must be properly installed and work freely in both directions prior to installation of the gate operator.

Operator in Front Position (Standard)



Concrete Depth Note: The heavier the gate, the deeper the concrete pad should be. At least **two feet** recommended for heavier gate.